

Lab 5 — Create Walls

Autodesk Revit Architecture Masterclass (C508) · Topic 02: Part Lists for Modeling in Revit · Tertiary Infotech Academy Pte Ltd

Goal

Work on different levels to add the exterior walls, interior partition walls and a corridor to the project, then tidy the joins with the Trim/Extend tool.

You'll build

A building shell with exterior walls, interior walls and a corridor opening on the lower level.

Tools: Revit · Wall: Architectural · Trim/Extend

Files in this lab

- ModelCreation.rvt (open in Autodesk Revit)

Step-by-step

1. Open the lower-level floor plan and start the architectural Wall tool.

Architecture ► Build ► Wall ► Wall: Architectural

2. Pick the wall type and set base/top constraints in the Properties palette.

Type Selector ► Basic Wall: Generic 200mm ► Top Constraint: Up to level 02

3. On the Options Bar set the Location Line and enable Chain, then draw the exterior walls clockwise.

Options Bar ► Location Line: Wall Centerline ► Chain ✓

4. Add the interior partition walls with a thinner wall type.

Type Selector ► Basic Wall: Interior 135mm Partition

5. Create the corridor by trimming the partition walls to form the opening.

Modify ► Trim/Extend to Corner ► click the two walls to keep

6. Check the shell in 3D and correct any wall join problems.

Default 3D View ► inspect ► Modify ► Wall Joins if needed

Test it

The lower level shows a closed exterior shell with interior partitions and a corridor; walls meet cleanly with no gaps or crossing lines. Compare with ModelCreation.rvt in the lab folder.