

Lab 6 — Place Doors and Windows

Autodesk Revit Architecture Masterclass (C508) · Topic 02: Part Lists for Modeling in Revit · Tertiary Infotech Academy Pte Ltd

Goal

Load door families into the project, then place interior and exterior doors and windows — flipping swing and orientation with the Spacebar and flip controls.

You'll build

A model with doors and windows placed and correctly oriented in the walls, each opening cut automatically.

Tools: Revit · Door tool · Window tool · Load Family

Files in this lab

- LittleHouse.rvt (open in Autodesk Revit)

Step-by-step

1. Open the entry-level floor plan and start the Door tool.

Architecture ► Build ► Door

2. Load additional door families from the library.

Modify | Place Door ► Mode ► Load Family ► Doors ► choose an entrance door

3. Enable tagging on placement so each door is numbered automatically.

Modify | Place Door ► Tag ► Tag on Placement

4. Hover over a wall, press Spacebar to flip the swing, then click to place the door.

Spacebar to flip ► click to place

5. Place windows on the exterior walls with the Window tool.

Architecture ► Build ► Window ► click the exterior walls

6. Fix any wrongly-placed component with the blue flip-control arrows.

Select the door/window ► click the flip arrows

Test it

Every door and window sits in a wall with its opening cut automatically, tags show sequential numbers, and all swings open the intended way.

© 2026 Tertiary Infotech Academy Pte Ltd · UEN: 201200696W