Lab 7 — Trim, Extend, Fillet and Chamfer

WSQ Technical Drawing with AutoCAD (TGS-2021005538) · Topic 03: Modifying Objects

Tertiary Infotech Academy Pte Ltd · UEN: 201200696W · Version v12 · 18 August 2026

Objective

LO2/LO3 — clean up and finish drawing geometry (A3, K3)

Goal

Complete practice drawing EX-5 by trimming overlapping construction geometry, extending short edges to their boundaries, and finishing corners with fillets and chamfers.

You'll produce

A clean EX-5 profile with every corner finished exactly as dimensioned on the sheet.

Commands / tools: TRIM (Quick/Standard), EXTEND, FILLET, CHAMFER, BREAK

Files in this lab

- ex5.dwg
- ex5-drawing-sheet.pdf
- ex5.png

Step-by-step

1. Open the EX-5 sheet (ex5-drawing-sheet.pdf) and rough out the profile with overlapping lines
2. Trim the overshoots in Quick mode — click or drag across the pieces to remove

   ```
   TR → click segments
   ```

3. Use Standard mode where you need explicit cutting edges: select boundaries, then objects

   ```
   TR → Enter (all edges) → pick
   ```

4. Extend the short edges to meet their boundary lines

```
EX → pick edges to extend
```

5. Fillet the rounded corners at the sheet radius, and chamfer the bevelled ones

```
F → R → 10 → pick 2 lines  ·  CHA → D → 5,5
```

6. Compare with ex5.dwg and save

```
SAVEAS ex5-mine.dwg
```

Check your work

No overshooting or dangling segments remain (zoom around the whole profile), and every fillet radius / chamfer distance matches the drawing sheet.

© 2026 Tertiary Infotech Academy Pte Ltd (UEN: 201200696W)