Lab 2 - Creating Lines and Coordinates

Course: WSQ Technical Drawing with AutoCAD (TGS-2021005538) | Topic 02: Technical Drawing with AutoCAD

Objective: LO2 - produce 2D technical drawings using AutoCAD (A2, K2)

Goal

Draw the outline of practice drawing EX-1 using the LINE and PLINE commands with absolute, relative and polar coordinate entry, working from its dimensioned drawing sheet.

You'll produce

The completed EX-1 profile drawn to size, matching the supplied solution DWG.

Commands / tools: LINE, PLINE, coordinate entry (@dx,dy | @dist<angle), ORTHO, dynamic input

Files in this lab

- ex1.dwg - AutoCAD drawing file
- ex1-drawing-sheet.pdf - drawing sheet / reference (PDF)
- ex1.png - reference image

Step-by-step

1. Open the EX-1 drawing sheet (ex1-drawing-sheet.pdf) and study the dimensions
2. Start a new acadiso drawing and draw the first edge with absolute coordinates

```
L → 0,0 → 100,0
```

3. Continue the profile with relative coordinates for each dimensioned edge

```
@0,50  |  @-30,0  |  @20<135
```

4. Use ortho (F8) and polar tracking (F10) for the horizontal and vertical segments

```
F8 | F10
```

5. Close the profile back to the start point and check it forms one closed loop

```
C (Close)
```

6. Compare your result against the solution file ex1.dwg, then save

```
OPEN ex1.dwg → SAVEAS ex1-mine.dwg
```

Check your work

Your outline closes exactly (LIST shows the final vertex at 0,0) and overlays the solution ex1.dwg with no visible deviation.