



Tertiary Infotech Academy Pte Ltd

UEN: 201200696W

LAB 6 — CREATE A PANEL LAYOUT WITH FOOTPRINTS

For

Technical Drawing with AutoCAD Electrical

TGS Ref No: TGS-2023037466

Conducted by

Tertiary Infotech Academy Pte Ltd

UEN: 201200696W

Version 6.0

AEF00TPRINT (Schematic List)

3. Place the footprints inside the panel outline; values (tag, location, description) copy over from the schematic.

Pick insertion points

4. Insert a nameplate from the Panel icon menu and associate it with a footprint.

Panel Icon Menu → Nameplate

5. Assign item numbers project-wide — components with the same catalog value receive the same item number.

AEPANELITEM

6. Add item balloons to the footprints and study the supplied blocks/attributes drawings to see how footprint blocks carry data.

AEBALLOON

Test it

Each footprint shows the same tag as its schematic parent, the nameplate carries the footprint's description, and balloons display consistent item numbers — the panel documents the design faithfully.