


Firmware Update Guidelines


➤ Software Installation

Double-click "LASER TOOL.zip" to decompress it, and the software will appear as shown in the figure below on the right




➤ Refresh the firmware


1. Turn on the machine and use the Type-C data cable to connect the computer to the machine.
2. Double-click to open the software "LaserTool", click item 1, as shown below.



3. As shown by the arrow below, select the firmware to be burned; select the port number connected to the machine, and other parameters can be as shown in the screenshot below.



COM port selection: The port number of the MAC platform starts with cu.wchusbserial to connect, as shown in the figure below.



4. After completing the above settings, click "Start" and wait a few minutes for the percentage progress to complete.



5. When the message shown in the figure below appears, the firmware update is

completed, please close the software and restart the machine.

