## **AIRBUS**

Volume **3**The Aerosoft Airbus A318/A319 in FSX

Version 01-03-001

## **RECORD OF REVISIONS**

revision n°	Issue date	Release	Description
001	Aug 20, 2014	1.00	completion

allun Dave

Aerosoft	Procedure Guide	Vol	03-01-1
Airbus X Extended	Procedure Guide	3	20 August 2014

COCKPIT PREPA	RATION
CONSOLE/FLOOR lights	AS RQRD
PFD/ND	CHECK
GPWS	TEST
Baro REF	SET
FD	CHECK ON
ILS	AS RQRD
ND Mode/Range	AS RQRD
VOR/ADF Sel	AS RQRD
SPD MACH	DASHED
HDG V/S / TRK FPA	HDG V/S
ALT Window	SET EXPECTED
STBY ASI	CHECK
STBY ALTI	CHECK
STBY Horizon	CHECK
Clock	CHECK/ADJUST
A/SKID NOSE WHEEL	ON
Exterior Lights	OFF
SWTG Rotary Sels	ALL NORM
ECAM STS	DEPRESS
Thrust Levers	CHECK IDLE
ENG MASTER Sws	CHECK OFF
ENG MODE Del	CHECK NORM
ATC MODE Sel	XPNDR
PARK BRAKE	AS RQRD
STROBE Lt	AUTO
BEACON Lt	CHEC OFF
WING, NAV, RWY TURN OFF	,
LAND, NOSE Lts	AS RQRD
SEAT BELTS	ON
NO SMOKING	AUTO
Cab Press LDG ELEV	AUTO
Pack ECON FLOW	AS RQRD
BAT	CHECK CHARGING
Fuel PUMPS	ALL ON
TO DATA	FILL
FMGS Inputs	CHECK
F-PLN A and B Pages	
<u> </u>	

FINAL COCKPIT PREPARATION			
TO DATA	X-CHECK/SIGN		
MCDU	TO CONFIG		
Fuel QTY	CHECK		
Preflight Briefing	PERFORM		
Cockpit Crew Checklist	COMPLETE		

BEFORE START/PUSHBACK			
ATC Clearance	. OBTAIN		
Windows/Doors	. CLOSED		
Start up/Pb clearance	. OBTAIN		
"N WHEEL STEERG DISC"			
ECAM Memo	. CHECK ON		
Parking Brake	. AS RQRD		
THR LEVERS	. IDLE		
APU BLEED	. ON		
Before Start Checklist	COMPLETE		

ENGINE START			
Engine (eng 2 first)	. START		
ENG MODE Sel	. IGN		
"ENG START 2"	. PF ANNOUNCE		
MASTER Sw 2	. ON		
ENG Parameters	. CHECK/MONITOR		
ENG Idle Parameters	. CHECK		
"Parameters Stabilized"	. PNF ANNOUNCE		
"ENG START 1"	. PF ANNOUNCE		
MASTER Sw 1	. ON		
"Parameters Stabilized"	. PNF ANNOUNCE		
ENG MODE Sel	. NORM		

AFTER START				
APU BLEED	OFF			
Ground Spoilers	ARM			
RUD TRIM	ZERO			
FLAPS Lever	SET			
Pitch Trim	SET			
ENG ANTI-ICE	AS RQRD			
WING ANTI-ICE	AS RQRD			
ECAM DOOR Page	DEPRESS			
ECAM STATUS	CHECK			
APU MASTER Sw	AS RQRD			
Ground Crew Clearance	RECEIVE			
After Start Checklist	COMPLETE			

Aerosoft	Procedure Guide	Vol	03-01-2
Airbus X Extended	Procedure Guide	3	20 August 2014

ΤΔ	KIING
Taxi Clearance	
Taxi Area	
EXT LT	AS RQRD
Clock ET	START
THR LEVERS	AS RQRD
Brakes	CHECK
Flight Controls	CHECK
Flight Instruments	CHECK
ATC Clearance	RECEIVE
TO Data/Conditions	REVIEW
FCU	SET
ATC Code	CONFIRM/SET
TO CONFIG Pb	PRESS
AUTO BRK	MAX
Take Off Briefing	COMPLETE
Cabin Report	OBTAIN
Taxiing Checklist	COMPLETE

BEFORE TAKE OFF			
TO or Line UP Clearance	OBTAIN		
Approach Path Clear	CHECK		
"Take Off Imminent"	ANNOUNCE		
EXT LT	AS RQRD		
ENG MODE Sel	AS RQRD		
PACK 1 and 2	AS RQRD		
TO MEMO	CK NO BLUE LINE		
Table	STOWED		
Before TO Checklist	COMPLETE		
"Ready for Take off"	ANNOUNCE		

TAKE OFF			
THR LEVERS	FLX OR TO/GA		
Clock CHRONO	START		
Direction Control	MAINTAIN		
TO N1	CHECK		
PFD and ENG Indications	SCAN		
V Speeds	ANNOUNCE		
Rotation	PERFORM		
Gear	RETRACT		
EXT LT	RETRACT/OFF		
A/P	AS RQRD		
THR LEVERS	CL		
PACK 1 and 2	ON		
FLAPS	RETRACT		
Ground Spoilers	DISARM		

CLIMB	
MCDUSET	

CRUISE	
ECAM MEMO	REVIEW
ECAM Sys	REVIEW
Cabin Temp	MONITOR
Flight Progress	CHECK
NAV ACCY	CHECK

DESCENT PREPARATION	
Landing Information RECEIVE	
Altimeters PRESET/SET	
LDG ELEVCHECK	
FMGS SET FOR LDG	
Min Safe Altitude(s)CHECK	
Approach and Ldg Briefing PERFORM	
Descent ChecklistCOMPLETE	
Descent Clearance OBTAIN	

DESCENT / APPROACH	
MCDU	SET
ANTI ICE Protect	AS RQRD
SPEED BRAKES	AS RQRD
NAV ACCY	CK
BARO REF	SET QNH
EXT LTS	AS RQRD

INITIAL APPROACH	
Cabin SIGNS	ON/AUTO
Cabin	SECURE FOR LDG
Marker	AUDIO ON
ECAM STATUS	CHECK
Landing Data	REVIEW
ND	SELECT MODE
ENG MODE Sel	AS RQRD
RAD NAV AIDS	CHECK
NAV ACCY	CHECK
ILS Pb	PRESS
APPR Phase	MONITOR
Managed Speed	CHECK
APPROACH Checklist	COMPLETE

Aerosoft	Procedure Guide	Vol	03-01-3
Airbus X Extended	Procedure Guide	3	20 August 2014

FINAL	
APP Pb On FCU	PRESS
A/P	BOTH ENGAGED
FLAPS 1	SELECT
ILS CAPTURE	MONITOR
FLAPS 2	SELECT
Landing Gear	EXTEND
ECAM WHEEL Page	CHECK
AUTO BRAKE	AS RQRD
EXT LTS	SET
FLAPS 3 / FULL	SELECT
Ground Spoilers	ARM
A/THR	CHECK
GO AROUND ALT	SET
LDG MEMO	CK NO BLUE LINE
Final Checklist	COMPLETE
Lctr/OM/DME Passage	MONITOR
Windshield Wipers	AS RQRD
A/P (if no AUTOLAND)	OFF

LANDING ROLL		
Flare	PERFORM	
THR LEVERS	IDLE	
REV	AS RQRD	
Ground Spoilers	CHECK	
Nosewheel Contact	ACHIEVE	
Directional Control	MAINTAIN	
Brakes	AS RQRD	
THR LEVERS	REV IDLE	
THR LEVERS	FWD IDLE	

AFTER LANDING	
Ground Spoilers	DISARM
FLAPS	RETRACT
ENG MODE Sel .	NORM
LAND Lights	RETRACT
ANTI ICE	AS RQRD
APU (if rqrd)	START
Brake Temeratu	re CHECK
Clock CHRONO.	STOP
After Landing Ch	necklistCOMPLETE

PARKING	
PARKING BRAKE	. ON
Ground Contact	. ESTABLISH
Electrical Power	. ESTABLISH
Clock ET	. STOP
ENG MASTER 1 and 2	. OFF
SEAT BELTS	. OFF
Slides Disarm, Doors Open	. ORDER
ANTI ICE	. OFF
APU BLEED	. AS RQRD
FUEL PUMPS	. ALL OFF
ECAM STS	. DEPRESS
Parking Checklist	. COMPLETE
Debriefing	. PERFORM

LEAVING THE AIRCRAFT	
ADIRS (1,2,3)	OFF
EXT LT	AS RQRD
APU BLEED	OFF
NO SMOKING	OFF
APU MASTER Sw	AS RQRD
EXT PWR	AS RQRD
BAT 1 and 2	AS RQRD
Leaving the Airplane Ck	list COMPLETE