

Moving Linux iSCSI hosts from MetroCluster FC to MetroCluster IP nodes

ONTAP MetroCluster

netapp-martyh, ntap-bmegan, zachary wambold April 17, 2021

Table of Contents

M	loving Linux iSCSI hosts from MetroCluster FC to MetroCluster IP nodes
	Setting up new iSCSI connections
	Adding the MetroCluster IP nodes as reporting nodes
	Removing reporting nodes and rescanning paths

Moving Linux iSCSI hosts from MetroCluster FC to MetroCluster IP nodes

After you transition your MetroCluster nodes from FC to IP, you might need to move your iSCSI host connections to the new nodes.

In this procedure IPv4 interfaces are created.

The host commands and examples given in these procedures are specific to LINUX operating systems.

Setting up new iSCSI connections

To move iSCSI connections, you must set up new iSCSI connections to the MetroCluster IP nodes.

1. Create iSCSI interfaces on the MetroCluster IP nodes and check ping connectivity from the iSCSI clients to the new IP interfaces on the MetroCluster IP nodes.

Creating network interfaces

All iSCSI interfaces from the SVM should be reachable by iSCSI client.

 On the iSCSI host or client, identify the existing iSCSI connections from the host to the MetroCluster FC node: iscsiadm -m session

```
[root@scspr1789621001 ~]# iscsiadm -m session

tcp: [1] 10.230.68.236:3260,1156 iqn.1992-
08.com.netapp:sn.58d7f6df2cc611eaa9c500a098a71638:vs.6 (non-flash)

tcp: [2] 10.230.68.237:3260,1158 iqn.1992-
08.com.netapp:sn.58d7f6df2cc611eaa9c500a098a71638:vs.6 (non-flash)
```

3. Verify the connections from the MetroCluster IP node: iscsi session show -vserver svm-name

4. List the iscsi interfaces in ONTAP for the SVM that contains the interfaces: iscsi interface show -vserver svm-name

```
sti8200mcchtp001htp siteA::*> iscsi interface show -vserver vsa 1
Logical Status Curr Curr
Vserver Interface TPGT Admin/Oper IP Address Node Port Enabled
_____
vsa 1 iscsi lf n1 p1 1156 up/up 10.230.68.236 sti8200mcc-htp-001 e0g
true
vsa 1 iscsi 1f n1 p2 1157 up/up fd20:8b1e:b255:805e::78c9 sti8200mcc-
htp-001 e0h true
vsa_1 iscsi_lf__n2_p1_ 1158 up/up 10.230.68.237 sti8200mcc-htp-002 e0q
true
vsa 1 iscsi lf n2 p2 1159 up/up fd20:8b1e:b255:805e::78ca sti8200mcc-
htp-002 e0h true
vsa 1 iscsi lf n3 p1 1183 up/up 10.226.43.134 sti8200mccip-htp-005 e0c
true
vsa 1 iscsi lf n4 p1 1188 up/up 10.226.43.142 sti8200mccip-htp-006 e0c
6 entries were displayed.
```

5. On the iSCSI client, run discovery on any one of the iSCSI IP addresses on the SVM to discover the new targets: iscsiadm -m discovery -t sendtargets -p iscsi-ip-address

Discovery can be run on any IP address of the SVM, including non-iSCSI interfaces.

```
[root@scspr1789621001 ~]# iscsiadm -m discovery -t sendtargets -p 10.230.68.236:3260

10.230.68.236:3260,1156 iqn.1992-
08.com.netapp:sn.58d7f6df2cc611eaa9c500a098a71638:vs.6

10.226.43.142:3260,1188 iqn.1992-
08.com.netapp:sn.58d7f6df2cc611eaa9c500a098a71638:vs.6

10.226.43.134:3260,1183 iqn.1992-
08.com.netapp:sn.58d7f6df2cc611eaa9c500a098a71638:vs.6

10.230.68.237:3260,1158 iqn.1992-
08.com.netapp:sn.58d7f6df2cc611eaa9c500a098a71638:vs.6
```

6. On the iSCSI client, login to all the discovered addresses: iscsiadm -m node -L all -T node-address -p portal-address -l

```
[root@scspr1789621001 ~]# iscsiadm -m node -L all -T iqn.1992-
08.com.netapp:sn.58d7f6df2cc611eaa9c500a098a71638:vs.6 -p
10.230.68.236:3260 -1

Logging in to [iface: default, target: iqn.1992-
08.com.netapp:sn.58d7f6df2cc611eaa9c500a098a71638:vs.6, portal:
10.226.43.142,3260] (multiple)
Logging in to [iface: default, target: iqn.1992-
08.com.netapp:sn.58d7f6df2cc611eaa9c500a098a71638:vs.6, portal:
10.226.43.134,3260] (multiple)
Login to [iface: default, target: iqn.1992-
08.com.netapp:sn.58d7f6df2cc611eaa9c500a098a71638:vs.6, portal:
10.226.43.142,3260] successful.
Login to [iface: default, target: iqn.1992-
08.com.netapp:sn.58d7f6df2cc611eaa9c500a098a71638:vs.6, portal:
10.226.43.134,3260] successful.
```

7. On the iSCSI client, verify the login and connections: iscsiadm -m session

```
[root@scspr1789621001 ~]# iscsiadm -m session

tcp: [1] 10.230.68.236:3260,1156 iqn.1992-
08.com.netapp:sn.58d7f6df2cc611eaa9c500a098a71638:vs.6 (non-flash)
tcp: [2] 10.230.68.237:3260,1158 iqn.1992-
08.com.netapp:sn.58d7f6df2cc611eaa9c500a098a71638:vs.6 (non-flash)
tcp: [3] 10.226.43.142:3260,1188 iqn.1992-
08.com.netapp:sn.58d7f6df2cc611eaa9c500a098a71638:vs.6 (non-flash)
```

8. From the MetroCluster node, verify the login and connection with the client: iscsi initiator show -vserver vsa 1

```
sti8200mcchtp001htp siteA::*> iscsi initiator show -vserver vsa 1
 Tpgroup Initiator
                      TSIH Name
Vserver Name
                                                  ISID
Igroup Name
_____
_____
vsa 1 iscsi lf n1 p1 4 iqn.2020-
01.com.netapp.englab.gdl:scspr1789621001 00:02:3d:00:00:01 igroup linux
vsa 1 iscsi 1f n2 p1 4 iqn.2020-
01.com.netapp.englab.gdl:scspr1789621001 00:02:3d:00:00:02 igroup linux
vsa 1 iscsi lf n3 p1 1 iqn.2020-
01.com.netapp.englab.gdl:scspr1789621001 00:02:3d:00:00:04 igroup linux
vsa 1 iscsi lf n4 p1 1 iqn.2020-
01.com.netapp.englab.gdl:scspr1789621001 00:02:3d:00:00:03 igroup linux
4 entries were displayed.
```

At the end of this tasks, the client can see all iSCSI interfaces (on the MetroCluster FC and MetroCluster IP nodes) and is logged in to all those interfaces.

LUNs and volumes are still physically hosted on FC nodes. Because LUNs are reported only on MetroCluster FC node interfaces, the client will show only paths over MetroCluster FC nodes. This can be seen in sanlun lun show -p and multipath -II -d command outputs. The next step is to add IP nodes as reporting nodes.

```
[root@scspr1789621001 ~] # sanlun lun show -p
ONTAP Path: vsa 1:/vol/vsa 1 vol6/lun linux 12
LUN: 4
LUN Size: 2q
Product: cDOT
Host Device: 3600a098038304646513f4f674e52774b
Multipath Policy: service-time 0
Multipath Provider: Native
-----
host vserver
path path /dev/ host vserver
state type node adapter LIF
_____
up primary sdk host3
                                   iscsi lf n2 p1
up secondary sdh host2 iscsi_lf__n1_p1_
[root@scspr1789621001 ~]# multipath -ll -d
3600a098038304646513f4f674e52774b dm-5 NETAPP ,LUN C-Mode
size=2.0G features='4 queue if no path pg init retries 50
retain attached hw handle' hwhandler='1 alua' wp=rw
|-+- policy='service-time 0' prio=50 status=active
\ - 3:0:0:4 sdk 8:160 active ready running
`-+- policy='service-time 0' prio=10 status=enabled
 `- 2:0:0:4 sdh 8:112 active ready running
```

Adding the MetroCluster IP nodes as reporting nodes

After setting up the connections to the new MetroCluster IP nodes, you must add new reporting nodes.

1. On the MetroCluster node, list reporting nodes for LUNs on the SVM: lun mapping show -vserver vsa_1 -fields reporting-nodes -ostype linux

The following reporting nodes are local nodes as LUNs are physically on FC nodes node_A_1-FC and node_A_2-FC.

2. On the MetroCluster node, add reporting nodes: lun mapping add-reporting-nodes -vserver svm-name -path /vol/vsa_1_vol*/lun_linux_* -nodes node1, node2 -igroup igroup linux

```
node_A_1-IP::*> lun mapping add-reporting-nodes -vserver vsa_1 -path
/vol/vsa_1_vol*/lun_linux_* -nodes node_A_1-IP,node_A_2-IP
-igroup igroup_linux

12 entries were acted on.
```

3. On the MetroCluster node, verify that the newly added nodes are present: lun mapping show -vserver svm-name -fields reporting-nodes -ostype linux vserver path igroup reporting-nodes

```
node_A_1-IP::*> lun mapping show -vserver vsa_1 -fields reporting-nodes
-ostype linux vserver path igroup reporting-nodes
------
vsa_1 /vol/vsa_1_vol1/lun_linux_2 igroup_linux node_A_1-FC,node_A_2-FC,node_A_1-IP,node_A_2-IP
vsa_1 /vol/vsa_1_vol1/lun_linux_3 igroup_linux node_A_1-FC,node_A_2-FC,node_A_1-IP,node_A_2-IP.
.
.
.
.
.
.
.
.
.
.
.
.
.
.
.
.
.
.
12 entries were displayed.
```

4. On the host, issue the following command to rescan the scsi bus on the host and discover the newly added paths:/usr/bin/rescan-scsi-bus.sh -a

```
[root@stemgr]# /usr/bin/rescan-scsi-bus.sh -a
Scanning SCSI subsystem for new devices
Scanning host 0 for SCSI target IDs 0 1 2 3 4 5 6 7, all LUNs
Scanning host 1 for SCSI target IDs 0 1 2 3 4 5 6 7, all LUNs
Scanning host 2 for SCSI target IDs 0 1 2 3 4 5 6 7, all LUNs
Scanning for device 2 0 0 0 ...

.
OLD: Host: scsi5 Channel: 00 Id: 00 Lun: 09
Vendor: NETAPP Model: LUN C-Mode Rev: 9800
Type: Direct-Access ANSI SCSI revision: 05
0 new or changed device(s) found.
0 remapped or resized device(s) found.
0 device(s) removed.
```

5. On the host, issue the following command to list the newly added paths: sanlun lun show -p Four paths are shown for each LUN.

```
[root@stemgr]# sanlun lun show -p
ONTAP Path: vsa 1:/vol/vsa 1 vol6/lun linux 12
LUN: 4
LUN Size: 2q
Product: cDOT
Host Device: 3600a098038304646513f4f674e52774b
Multipath Policy: service-time 0
Multipath Provider: Native
_____ ___
host vserver
path path /dev/ host vserver
state type node adapter LIF
up primary sdk host3 iscsi lf n2 p1
up secondary sdh host2 iscsi lf n1 p1
up secondary sdag host4 iscsi lf n4 p1
up secondary sdah host5 iscsi lf n3 p1
```

6. On the MetroCluster, move the volume/volumes containing LUNs from FC to IP nodes.

- 7. When the volume move is completed, on the MetroCluster, use the volume show command to confirm that the volume or LUN is online.
- 8. The iSCSI interfaces on the MetroCluster IP nodes where the LUN now resides are updated as primary paths. If the primary path is not updated after the volume move, run /usr/bin/rescan-scsi-bus.sh -a and multipath -v3 or simply wait for multipath rescanning to take place.

In the following example, the primary path is a LIF on the MetroCluster IP node.

```
[root@stemgr]# sanlun lun show -p
ONTAP Path: vsa 1:/vol/vsa 1 vol6/lun linux 12
LUN: 4
LUN Size: 2q
Product: cDOT
 Host Device: 3600a098038304646513f4f674e52774b
Multipath Policy: service-time 0
Multipath Provider: Native
______
host vserver
path path /dev/ host vserver
state type node adapter LIF
     primarysdaghost4iscsi_lf__n4_p1_secondarysdkhost3iscsi_lf__n2_p1_secondarysdhhost2iscsi_lf__n1_p1_
up
up
up
    secondary sdah host5 iscsi_lf__n3_p1_
up
```

Removing reporting nodes and rescanning paths

You must remove the reporting nodes and rescan the paths.

1. From the MetroCluster IP node, remove remote reporting nodes (the MetroCluster IP nodes) for the Linux LUNs: lun mapping remove-reporting-nodes -vserver vsa_1 -path * -igroup igroup linux -remote-nodes true

In this case, the remote nodes are FC nodes.

```
node_A_1-IP::*> lun mapping remove-reporting-nodes -vserver vsa_1 -path
* -igroup igroup_linux -remote-nodes true

12 entries were acted on.
```

2. From the MetroCluster IP node, check reporting nodes for the LUNs: lun mapping show -vserver vsa_1 -fields reporting-nodes -ostype linux

3. On the iSCSI host, rescan the scsi bus: /usr/bin/rescan-scsi-bus.sh -r

The paths that are removed are the paths from FC nodes.

```
[root@scspr1789621001 ~]# /usr/bin/rescan-scsi-bus.sh -r
Syncing file systems
Scanning SCSI subsystem for new devices and remove devices that have
Scanning host 0 for SCSI target IDs 0 1 2 3 4 5 6 7, all LUNs
Scanning host 1 for SCSI target IDs 0 1 2 3 4 5 6 7, all LUNs
Scanning host 2 for SCSI target IDs 0 1 2 3 4 5 6 7, all LUNs
sg0 changed: LU not available (PQual 1)
REM: Host: scsi2 Channel: 00 Id: 00 Lun: 00
DEL: Vendor: NETAPP Model: LUN C-Mode Rev: 9800
Type: Direct-Access ANSI SCSI revision: 05
sg2 changed: LU not available (PQual 1)
OLD: Host: scsi5 Channel: 00 Id: 00 Lun: 09
Vendor: NETAPP Model: LUN C-Mode Rev: 9800
Type: Direct-Access ANSI SCSI revision: 05
0 new or changed device(s) found.
O remapped or resized device(s) found.
24 device(s) removed.
[2:0:0:0]
[2:0:0:1]
```

4. On the iSCSI host, verify that only paths from the MetroCluster IP nodes are visible: sanlun lun show -p``multipath -ll -d

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.