
PickADisk QuickStart


- Adding a disc
- Find a disc
- Preferences
- Main window view
- License

1 Organize your disc collection



PickADisk is a application to store and index your disc collection into DC-101 and DC-300 carousels.


2 PickADisk Startup Window



This is the PickADisk startup window.


Some of the more non-obvious parts are described and will be discussed in later slides.

3 License Notice



Upon first startup of PickADisk you will receive this dialog. Click on the appropriate button.

4 Check for updates window




This dialog will be shown on the 2nd launch of the application.

Adding a disc

Basic steps for adding
Adding additional information


Basic steps for adding

1 PickADisk Startup Window




Click either add button to begin the process.

2 Select strorage device



Select a storage device to be used.


3 Select slot number



The next available slot number will be entered automatically.


If you desire a specific slot, you may enter the number in one of two ways.
Type in the slot number using the keyboard.
Click on the wheel and drag to select the number.
If the slot number already contains a disc you will see the title in the title box.
If you click on the arrow the device will go to the numbered slot and eject the disc.

4 Select disc




Select the disc to be added.
Use the popup menu to select the drive to be used, the title box will be filled in automatically.

5 Enter a title for the disc




Enter the title manually if you don't like the automatic generated name.

6 Select the type of disc



The type of disc is detected automatically.
If you prefer a different type, use the popup menu to select the type of disc.

7 Set the scanning level




Set the desired scanning level. This will control how much detail of the content of the disc will be included in the index.
The far left setting will only scan the top level content of the disc.

The far right setting will index the entire disc.

The settings default value can be controlled for different types of discs in the preferences panel.

8 Add the disc to the device




Click on the Add button to add the disc.

Repeat the steps to keep adding discs to the device.

Adding additional information


After adding a disc you may desire to add additional information to make subsequent search and retrieval easier.

1 Select storage device



To enter additional information, select the storage device from the side panel.
The contents of the device will be displayed.


2 Locate the disc



Since you generally add discs in incrementing values, click on the Slot column to sort the list by slot number.
If the most recent disc is not at the top, click the SSlot column again to sort in the opposite direction.


Select the disc you wish to add additional information.

3 Select the disc




Click and select the disc you wish to modify.

4 Select the Inspector panel



Open the Inspector panel


5 Inspector Panel




Change the indicated fields as you desire.

Find a disc

1 Enter search criteria




2 Select Result



Results are displayed.

Click on column headings to sort the results.

3 Retreive disc




Results are displayed.


Click on column headings to sort the results.

Preferences

1 General preference pane




2 Discovery pane




Controls behavior when discs are mounted and ejected

3 Discovery on Check In



If you have a recognized disc mount and you select Check In you may have the device go to the assigned slot or simply do nothing,

4 Discovery for Check Out



Controls behavior when you select Check Out.

5 Discovery for recognized discs




6 Discovery for unrecognized dics



7 Sidebar Pane




8 Update pane




Controls the automatic updating of the application.

9 Driver pane



The driver should be installed automatically, if for some reason know only to the Gods it is not, use this pane to install and remove the driver as directed by PickADisk support.


10 Scanning pane



Controls the depth of folder scanning for various types of files.
Left most setting is top level only, rightmost is entire content of disc (can be slow on large content discs)


Main window view

1 Window details




Widen the window if you have all columns turned on

2 Widened window to view data




3 Main window change values



4 Main window view contents




5 Main window contextual meu




License

1 Select license menu item



2 Enter License



There are several ways to enter your license.

Double click on the attachment in the license email (assumes you are using Apple Mail)
Double click on the license file (sent as an email attachment)
Drag the license file to the window
Click the **Choose** button and navigate to the license file.