THE STUMP GRINDING PLAYBOOK

Quick Field Formula & Quoting Cheat Sheet

1. THE CORE HYBRID QUOTING FORMULA

Final Quote = [(Diameter x Base Rate) x Wood x Flare x Access] - Discount + Travel

Rule: Final quote should NEVER fall below your minimum job fee ($150 starting point).

2. STANDARD ADJUSTMENT MULTIPLIERS (Starting Points)

Factor	Multiplier	Why it matters
Softwood (Pine, Poplar)	**0.90x**	Cuts fast, lighter tooth and fuel wear
Medium (Ash, Birch)	**1.00x**	Standard baseline cutting resistance
Hardwood (Oak, Hickory, Locust)	**1.15x**	Dull teeth quickly, uses more fuel
Moderate Root Flare	**1.10x**	Requires grinding 6" out from main trunk
Heavy Surface Roots	**1.25x**	Large roots running through turf; adds 20-40 min
Tight Yard Access (<36" gate)	**1.15x**	Requires smaller machine or track mats
Steep Slope (>15 degrees)	**1.20x**	Safety hazard, slower machine winching
High Rock / Gravel Risk	**1.15x**	High chance of chipped or broken teeth

3. THE 3 NON-NEGOTIABLE OPERATING RULES

1. ALWAYS call 811 before digging. Public utilities are free to locate. Unmarked private irrigation is not covered.
2. Probe the perimeter with a steel bar before spinning the wheel. One hidden river rock destroys $40 in teeth.
3. Quote in writing with grind depth stated (6" or 12"). State clearly whether wood chips are mounded or hauled.

For the full 30+ page manual, Excel Calculator & 12 Templates Pack, visit:
https://stump-grinding-playbook.vercel.app