CONTROL LAYOUT

Know your controls

Front view of the controller. L = LCD key • B = lower navigation button • K = rotary knob

SIX LCD KEYS + THREE NAVIGATION BUTTONS + THREE KNOBS



CHOSEN ROTARY FUNCTIONS

K1 / Main knob

Zoom in / zoom out

K3 / Lower-right knob

Horizontal scrolling

K2 and knob presses

K2 is the lower-left knob. Each knob also supports a press action, separate from its rotary function.

The recorded press assignments were proposed for Resolve. See page 5 for their application context.

B1 • B2 • B3 / DEFAULT NAVIGATION

Previous page • Home • Next page. The three lower buttons navigate pages/scenes. Undo/Redo, Copy and Paste belong to the LCD action catalog.

While working
Select the scene in the Ajazz software and keep the target application in the foreground.

SCENE / CANVA

Create, arrange and review

Original custom artwork in cyan, violet and magenta, with white symbols and the existing lower margins preserved.

C1-C10 are catalog references. The controller displays six LCD keys per page; the complete artwork collection is shown here for reference.

C1



Text

C2



Magic search

C3



Delete

C4



Bring layer forward

C5



Send layer backward

C6



Undo / Redo

C7



Undo

C8



Redo

C9



Copy

C10



Paste

Revision: the combined Undo/Redo artwork updates the initial Undo-only design. Separate Undo and Redo versions, plus Copy and Paste icons, are also included.

SCENE / CHROME

Your five quick links

Each service retains its own branding and color palette. These are the custom artworks already created for this scene.

R1



ChatGPT

White and green

R2



Gemini

Blue and violet

R3



Core Play IPTV

Yellow and red

R4



Mixkit

Cyan, pink and violet

R5



YouTube

Red and white

FIND AND OPEN

Identify the service by its icon and name. The corresponding key uses the website action assigned in the Ajazz Chrome scene.

References R1-R5
The numbers organize the catalog; they do not identify physical LCD key positions.

SCENE / WINDOWS

System and task controls

This scene uses blue tones, a soft glow and the Windows symbol.

W1



Windows Home

A blue house with the Windows symbol in the center.

ORIGINAL CUSTOM ART

W2



Close task

The task-closing action assigned in the Windows scene.

FUNCTION ILLUSTRATION

Check the action assigned in the profile. The destination of Windows Home and the command used for Close task depend on that assignment. The artwork identifies the function; it does not set the shortcut.

REFERENCE / KNOB PRESSES

Assignments and context

Use this page to distinguish the chosen functions from earlier application-specific suggestions.

KNOB PRESSES / EARLIER DAVINCI RESOLVE PROPOSAL

Control	Suggested press	Described function
K1 • Main knob	**Shift + Z**	Fit the view to the content.
K2 • Lower-left knob	**Space**	Play / pause.
K3 • Lower-right knob	**N**	Toggle snapping.

Scope: these presses were proposed for Resolve. Their assignment to Canva, Chrome and Windows scenes has not been confirmed.

OTHER RECORDED CONTROLS

K2 rotation: left/right arrow keys in the Resolve proposal.
Upper-right LCD key: circular shape / Ellipse, also in the Resolve context.

BUTTONS AND PAGES

B1-B3: previous page / Home / next page navigation, using the default scene setting.
L1-L6: physical positions. C, R and W codes are catalog references.

REFERENCE NOTES

Settings and artwork discussed on 20-21 September 2026. Diagram not to scale. Unofficial personal guide prepared with AI assistance. Close task is a vector illustration; the other icons are the earlier custom artworks. The PDF is a visual reference, not an installable profile.

Control and navigation reference: AJAZZ AKP03