
Agenda


- Notion of Signals
 - Continuous-time & Discrete-time
 - Analog & Digital
 - Certainty
- Notion of dynamical systems
 - Inputs, Outputs, States, Parameters
 - Time, Signal, Subsystem
- Type of System
 - State
 - Time
 - Linearity
 - Parameters
 - Certainty

สัญญาณ (เบื้องต้น) โดย ธนัชชา ชูพจน์เจริญ


นิยาม ดักษณะ ตัวอย่าง




ตัวแปรปริภูมิ x และ y เป็นตัวแปรอิสระ (independent variables) ซึ่งไม่ได้ขึ้นอยู่กับค่าอื่นๆ



$$x: \mathbb{R}_{\geq 0} \to \{a \in \mathbb{R} | -1 \leq a \leq 1\}$$



ตัวแปรปริภูมิ x และ y เป็นตัวแปรอิสระ (independent variables) ซึ่งไม่ได้ขึ้นอยู่กับค่า t และค่า t ก็เป็นตัวแปรอิสระเหมือนกัน




$$\mathbf{p}(t) = \begin{bmatrix} x(t) \\ y(t) \end{bmatrix} = \begin{bmatrix} v_x t \\ -\frac{1}{2}gt^2 + v_y t \end{bmatrix}$$

$$\mathbf{p}: \mathbb{R}_{\geq 0} \to \mathbb{R}^2$$

ว่าด้วยเรื่องของความต่อเนื่องของเวลา

สัญญาณมีค่าตลอดเวลาในช่วงเวลา




ตย. : ปริมาณของกระแสไฟที่ใหลเข้าเตาหมูกระทะไฟฟ้า

Continuous-time Signal $\mathbf{f}_c(t)$

$$\mathbf{f}_c \colon \mathbb{R} \to \mathcal{R}$$

เซ็ตของจำนวนจริง

สัญญาณมีค่าแค่บางจังหวะ



ตย.: อุณหภูมิในเรือนกระจกที่ถูกวัดทุกเที่ยงวัน

Discrete-time Signal $\mathbf{f}_d[n]$

$$\mathbf{f}_d \colon \mathbb{Z} \to \mathcal{R}$$

เซ็ตของจำนวนเต็ม

การจำลองสัญญาณในโปรแกรม

COMPUTER BELIKE



continuous-time signal



discrete-time signal

Example: 1


```
y(t) = A \sin(\omega t)
ประมาณเป็น
discrete-time


MATLAB Code:


>> t = (0:0.1:10)';
>> A = 1;
>> w = 2*pi* 0.5;
>> y = A*sin(w*t);
>> plot(t,y)
```


```
MATLAB Code:

>> t = (0:0.1:10)';
>> A = 1;
>> w = 1;
>> y = A*sin(w*t);
% y is a column vector
>> plot(t,y)
```









ว่าด้วยเรื่องขนาดและมิติของสัญญาณ (Scalar/Bus)

$$y(t) = \sin(t)$$

$$y: \mathbb{R}_{\geq 0} \to \mathbb{R}$$

สัญญาณแบบ scalar

ข้อควรระวัง: การเขียนโปรแกรมนั้นจะ ต่างกับการเขียนสมการทาง คณิตศาสตร์ ถ้าเราต้องให้เวลาอยู่ในมิติ ที่ 1 ช่องของสัญญาณแบบ bus จะไป อยู่ในมิติที่ 2 แทน

$$\mathbf{y}(t) = ec{y}(t) = egin{bmatrix} \sin(t) & \longrightarrow \ lpha \ \cos(t) \end{bmatrix}$$
 — ลัญญาณช่องที่ 1 $\mathbf{y}: \mathbb{R}_{\geq 0} \to \mathbb{R}^2$ ลัญญาณแบบ bus

```
MATLAB Code:

>> t = (0:0.1:10)';
>> v = 1;
>> y = [v*sin(t) v*cos(t)];
>> hold on;
>> plot(t,y(:,1))
>> plot(t,y(:,2))
>> legend('y_1','y_2')
```

```
MATLAB Code:

>> t = (0:0.1:10)';
>> v = 1;
>> y = [v*sin(t) v*cos(t)];
>> hold on;
>> plot(t,y(:,1))
>> plot(t,y(:,2))
>> legend('y_1','y_2')
```

 	>> t =	>> y=	
I I	0	0	1.0000
 	0.1	0.0998	0.9950
l I	0.2	0.1987	0.9801
į			•••
l	9.9	-0.4575	-0.8892
 	10.0	-0.5440	-0.8391
I			

ว่าด้วยเรื่องขนาดและมิติของสัญญาณ (Matrix)

$$\mathbf{R}(t) = \begin{bmatrix} \cos(t) & -\sin(t) \\ \sin(t) & \cos(t) \end{bmatrix}$$

$$\mathbf{R} \in \mathbb{R}_{\geq 0} \to \mathbb{R}^{2 \times 2}$$

vectorize



$$\mathbf{v}(t) = \mathbf{vec}(\mathbf{R}(t)) = \begin{bmatrix} \cos(t) \\ \sin(t) \\ -\sin(t) \\ \cos(t) \end{bmatrix}$$

$$\mathbf{v} \in \mathbb{R}_{\geq 0} \to \mathbb{R}^4$$


```
MATLAB Code:


>> N = 11;
>> t = linspace(0,10,N)';
>> R = cat(3,[cos(t) -sin(t)],
[sin(t) cos(t)]);
>> v = reshape(y,N,[]);
```

ว่าด้วยเรื่องของ ค่าของสัญญาณ

$$y:\mathcal{D}\to\mathcal{R}$$

สัญญาณที่มีค่าอยู่ในช่วงที่ต่อเนื่อง เรียกว่าสัญญาณอนาล็อก (Analog Signal)









ว่าด้วยเรื่องของ ค่าของสัญญาณ

$$y:\mathcal{D}\to\mathcal{R}$$

สัญญาณที่มีค่าอยู่ในเซ็ตที่นับได้และจำกัด เรียกว่า สัญญาณดิจิตอล (Digital Signal)





ว่าด้วยเรื่องของ ความไม่แน่นอน

สัญญาณที่สามารถถูกระบุได้ชัดเจนในรูปของ สมการทางคณิตศาสตร์และสามารถคำนวณหาได้ ในทุกช่วงเวลา เรียกว่า สัญญาณเชิงกำหนด

Deterministic Signal

$$y[n] = \sin(n)$$


สัญญาณที่มีพฤติกรรมที่<u>ไม่สามารถถูกระบุได้</u> ชัดเจน เรียกว่า สัญญาณสุ่ม

Random Signal

$$x[n] = \sin(n) + w[n]$$

 $w \sim \mathcal{N}(0, \sigma^2)$: Gaussian Distribution

Deterministic Signal & Random Signal



$$x[n] = \sin(n) + w[n]$$

$$w \sim \mathcal{N}(0, \sigma^2)$$

ความต่อเนื่องของเวลา

Continuous-time

Discrete-time

ค่าของสัญญาณ

Analog

Digital

ความไม่แน่นอน

Deterministic

Random

Where does the signal come from ?


Ans: A <u>"system"</u> provides it !!!

- Acquire from the physical system via measurement tool
- Simulate by using some assumption

Dynamical System


"A system in which a function describes the **evolution** of **something** over **time** "

Something that change over time: States



Systems: Examples


"A system in which a function describes the **evolution** of **something** over **time** "



This is not a dynamical system since there is **NO** evolution of states !!! This is just a <u>direct mathematic map</u> from one domain to the other.

Systems: Examples

"A system in which a function describes the **evolution** of **something** over **time** "



This is a dynamical system since evolution occurs for state variable x.

State Dependency

The output of the system varies according to the current state of the system

$$\frac{dx}{dt} = u(t)$$
$$y = x$$

Some calculation for exact x(t)

$$x(t = 0) = x_0$$

$$dx = u(t) dt$$

$$\int_{x_0}^{x(t)} 1 dx = \int_{\tau=0}^{t} u(t) d\tau$$


$$x(t) - x_0 = \int_{\tau=0}^t u(t) d\tau$$
$$x(t) = x_0 + \int_{\tau=0}^t u(t) d\tau$$

$$x(t) = x_0 + \int_{\tau=0}^t u(t) d\tau$$

As you can see, the value of \boldsymbol{x} depends on both input signal \boldsymbol{u} and initial states \boldsymbol{x}_0

A unique u at time t doesn't always result in the same x .

Inputs, Outputs, States



Note: A system without inputs is called "unforced system"

Type of System: Categorized by State type

 A <u>continuous-state system</u> is a dynamical system whose states are continuous. (Model using differential/difference equation)

Example: Pendulum

$$\theta \in \mathbb{R}$$
$$ml^2\ddot{\theta} + mlg\sin(\theta) = u$$

 A <u>discrete-state system</u> is a system with states that take on values in a countable set (discrete states). (Model using state machine)

Example : Traffic light $s \in \{red, green, yellow\}$

 A <u>hybrid-state system</u> is a system with both discrete and continuous states. (Hybrid State Machine)

Example : Bipedal Robot $\langle \vec{\theta}, s \rangle \in \langle \mathbb{R}^n, \{SS, DS\} \rangle$

Place Holder for Image: Pendulum

Place Holder for Image : Traffic Light

Place Holder for Image : Bipedal robot

Type of System: Categorized by Time

 A <u>continuous-time</u> system refers to a continuous-state system that change continuously in time (Model using differential equation)

Example: Pendulum

$$\theta \in \mathbb{R}$$
$$ml^2\ddot{\theta} + mlg\sin(\theta) = u$$

 A <u>discrete-time</u> system is a continuousstate system that changes at given points in time. (Model using difference/recurrence equation)

Example : Population Model $x[n+1] = \alpha x[n] \cdot x[n+1]$

Place Holder for Image : Graph of Pendulum

Place Holder for Image: Graph of Discrete Population

Type of System: Categorized by Linearity

- A <u>linear system</u> is a system that follows linear property.
 - Homogeneity

If
$$y = S(u)$$

Then $\alpha y = S(\alpha u)$

Additivity

If
$$S(u_1 + u_2) = S(u_1) + S(u_2)$$

Example: RC Filter

$$RC\frac{dv}{dt} + v = u$$

• A <u>nonlinear system</u> is a system that is not linear.

Example : Pendulum
$$ml^2\ddot{\theta} + mlg\sin(\theta) = u$$

Place Holder for Image : Linearity

Type of System: Categorized by Parameters

 A <u>lumped-parameter system</u> is a system that is modelled such that parameters are grouped as discrete entities. (Model using Ordinary differential equation)

Example : RC Filter

$$RC\frac{dv}{dt} + v = u$$

 A <u>distributed-parameter system</u> is a system that modelled such that parameters are distributed over some spatial domain (Model using Partial Differential Equation)

Example: Telegraph's equations

$$\frac{\partial V}{\partial x} = -L\frac{\partial I}{\partial t} - RI$$

$$\frac{\partial I}{\partial x} = -C \frac{\partial V}{\partial t} - GV$$

Place Holder for Image : RC Filter

Place Holder for Image: Transmission Line

Type of System: Categorized by Parameters

• A <u>deterministic system</u> is a system that is modelled such that its evolution is known with certainty.

Example : RC Filter

$$RC\frac{dv}{dt} + v = u$$

• A <u>probabilistic system</u> is a system that modelled such that its evolution cannot be predict perfectly.

Example: RC Filter with Disturbance

$$RC\frac{dv}{dt} + v = u + v$$

$$v \sim \mathcal{N}(\mu, \sigma^2)$$

Place Holder for Image : RC Filter

Place Holder for Image: Transmission Line

Why is it important to differentiate types of systems?

To understand the behavior of the system and model the system efficiently

• To set a proper scope for *analysis*

• To synthesize a proper algorithm to process such system

Understanding the system helps dealing with its signals.

Summary

- Notion of Signals
 - Continuous-time & Discrete-time
 - Analog & Digital
 - Certainty
- Notion of dynamical systems
 - Inputs, Outputs, States, Parameters
 - Time, Signal, Subsystem
- Type of System
 - State
 - Time
 - Linearity
 - Parameters
 - Certainty