

# F-RASS Operation Manual (Fujikura Risk Assessment System for Safety)

REV. 3 (20231110) EHS Management Center Fujikura Ltd.

#### Introduction

- We recommend Google Chrome as the browser when you use this system.
- If you mistake the password three times, your account will be locked. Please be careful about password setting. In case your account was locked please contact us (fjk.risksystem@jp.fujikura.com). Please handle the password properly and do not forget it.
- This system requires you to update your password every two months. Please set a password that is easy to update according to the update message.
- Please make sure to manage your password by yourself and do not disclose to others.

#### User login


Be sure to put a tick mark before logging in.

Please enter the interim password in the e-mail from administrator.


After login, please change the interim password to your original one.

(refer to pp. 28-29)

Please select language. (Selectable languages are only Japanese or English)



## Dashboards (The initial screen in login)




When you click each icon, the corresponding screen will be launched. The display menu may be different depending on the authority of ID.

#### **Data Input Description**

- 1 Add Record: Machinery
- 2 Add Record: Part
- ③ Add Record: Risk
- 4 Add Record: Assessment and Action Plan
- ⑤ Quick Search: By machinery name / site name etc, it will be used for searching and editing
- 6 Quick Search: By part name, it will be used for searching and editing
- Quick Search: By risk and risk item, it will be used for searching and editing
- ® Quick Search: By assessment and action plan, it will be used for searching and editing

## Dashboards (Switch screen display)


You can switch the display from the pull-down list in the upper left of the Dashboard tab. The following two items are mainly used.



F-RASS(E): Icon type (default)

Risk Management: List type (similar to the traditional F-RASS display)

## Dashboard (The screen when Risk Management is selected)



#### **Data Input Description**


- 1 Add Record : Assessment and Action Plan
- 2 Add Record : Machinery
- 3 Add Record : Part
- 4 Add Record : Risk
- ⑤ Quick Search: By assessment and action plan, it will be used for searching and editing
- 6 Quick Search : By machinery name / site name etc, it will be used for searching and editing
- Quick Search: By part name, it will be used for searching and editing
- Quick Search: By risk and risk item, it will
  be used for searching and editing

When you click each icon, the corresponding screen will be launched. The display menu may be different depending on the authority of ID.

# New Data Add


- When purchasing new machinery, be sure to enter new data.
- This section explains how to enter data for new machinery in the following order: Machinery, Part, Risk, and Risk Assessment and Action Plan.
- To add new Part or Risk to existing Machinery, refer to "Searching and Editing Data" (page 21).

#### New data addition: Machinery




Please click the  $\nabla$  button of


#### New data addition: Machinery




#### New data addition: Part




#### New data addition: Part



#### New data addition: Risk




#### New data addition: Risk




- The risk owner is the person responsible for managing the relevant risk.
- The search field in the drop-down list is useful when selecting a risk owner.
- Risk status is active as long as risk exists. Only when the risk disappears will you choose inactive in the risk status.


#### New data addition: Risk




#### New data addition: Risk assessment and Action Plan




# New data addition: Risk assessment and Action Plan - Description




## New data addition: Risk assessment and Action Plan – Initial Condition (Mandatory)




# New data addition: Risk assessment and Action Plan – Action Plan (3 Steps Method)



#### New data addition: Risk assessment and Action Plan – Current Condition (Mandatory)



# New data addition: Risk assessment and Action Plan - Target



# Searching and Editing Data

- Using Quick Search, you can easily search for "Machinery," "Part,"
  "Risk," and "Risk Assessment and Action Plan."
- •When "Adding new parts or risks to existing machinery," "Adding a three-step method," or "If the current assessment has changed due to implementation of countermeasures," you can refer to the data from the search results and enter additions or corrections.


#### Searching and Editing Data: Quick Search

Select the category of data you want to search from the dashboard or list.

#### Initial display (Icon type)



Risk Management (List type)



%When searching, you can search in the order of relevant machinery  $\rightarrow$  part in the machinery  $\rightarrow$  risk at that part  $\cdots$ , but if you know in advance what information you can search in each category, you can search starting from that category.

Machinery: Machinery ID, Machinery name, Machinery number, etc.


Part: Part ID, Part Name/Work Name, Machinery name, etc.

Risk: Risk Reference, Risk Contents, etc.

# Searching and Editing Data: Quick Search


When you select Quick Search, a screen below appears.

Enter keywords so that you can identify the data you want to search, then click "Search."




#### Searching and Editing Data: Search results

After you click Search, the search results appear at the bottom of the page. (If you can't see the results, scroll down the page.)




## Searching and Editing Data: Edit Existing Data



Click the data row you want to edit




When the data input screen appears, refer to "New Data Add" (pp. 7-20) to update, change, or add data.




#### Searching and Editing Data: Others

You can move to each category from the list displayed in ▼ at the top left of the Quick Search page.



You can download search results from

in th per right of the search results list.






You can download a csv file or an excel file.


# **Notes**

Notes on F-RASS Operation

# How to change the password



Move the cursor here and click Change Password.




#### How to change the password

The Change Password page appears.


Enter your current password and your new password (in two places, including for verification).

The new password must be at least 8 characters long, using uppercase alphabets, lowercase alphabets, numbers, and symbols \*.

\*#, \$,%, &, @,? ,! and other symbolic characters. If you enter a symbol that cannot be used, an error message appears.



If Change Password succeeds, you will see the following:



# **Revision History**

REV.1 (20180630) Newly created as "Operation manual" REV.2 (20190729) Add the changing method of password REV.3 (20231110) Completely overhauled with migration to IRM