Change Order Report For Project

rovi_tracking.PrjPcb And rovi_tracking.PrjPcb

Action	Object	Change Document	Status
Add Co	omponents		
Add	B1	To PCB1.PcbDoc	Footprint Not Found DLM0NSB120
Add	C1	To PCB1.PcbDoc	Footprint Not Found CAPC2012X1
Add Add	C2 C3	To PCB1.PcbDoc To PCB1.PcbDoc	Footprint Not Found CAPC2012X1 Footprint Not Found CAPC2012X1
Add	C4	To PCB1. cbboc	Footprint Not Found CAP EEEFN
Add	C5	To PCB1.PcbDoc	Footprint Not Found CAPC2012X1
Add	<u>C6</u>	To PCB1.PcbDoc	Footprint Not Found CAPC2012X1
Add Add	C7 C8	To PCB1.PcbDoc To PCB1.PcbDoc	Footprint Not Found CAPC2012X1 Footprint Not Found CAPC2012X1
Add	C9	To PCB1.PcbDoc	Footprint Not Found CAPC2012X1
Add	C10	To PCB1.PcbDoc	Footprint Not Found CAPC2012X1
Add Add	C11 C12	To PCB1.PcbDoc To PCB1.PcbDoc	Footprint Not Found CAPC2012X1 Footprint Not Found CAPMP7343>
Add	C13	To PCB1.PcbDoc	Footprint Not Found CAP Nii 73437
Add	C14	To PCB1.PcbDoc	Footprint Not Found CAPC2012X1
Add	C15	To PCB1.PcbDoc	Footprint Not Found CAPC2012X1
Add Add	C16 C17	To PCB1.PcbDoc To PCB1.PcbDoc	Footprint Not Found CAPC2012X1 Footprint Not Found CAPC2012X1
Add	C18	To PCB1.PcbDoc	Footprint Not Found CAPC2012X1
Add	C19	To PCB1.PcbDoc	Footprint Not Found CAPC2012X1
Add Add	C20 C21	To PCB1.PcbDoc	Footprint Not Found CAPC2012X1 Footprint Not Found CAPC2012X1
Add	C22	To PCB1.PcbDoc To PCB1.PcbDoc	Footprint Not Found CAPC2012X1
Add	D1	To PCB1.PcbDoc	Footprint Not Found SODFL3618X
Add	D2	To PCB1.PcbDoc	Footprint Not Found DIOM4336X2
Add Add	D3 D4	To PCB1.PcbDoc To PCB1.PcbDoc	Footprint Not Found DIOM4325X2 Footprint Not Found DIOM7959X2
Add	D5	To PCB1.PcbDoc	Footprint Not Found LEDC2012X7
Add	D6	To PCB1.PcbDoc	Footprint Not Found LEDC2012X7
Add	D7	To PCB1.PcbDoc	Footprint Not Found DIOM4325X2
Add Add	D8 D9	To PCB1.PcbDoc To PCB1.PcbDoc	Footprint Not Found DIOM4325X2 Footprint Not Found DIOM4325X2
Add	D10	To PCB1.PcbDoc	r dotprint Not 1 dana Brown 1020X2
Add	F1	To PCB1.PcbDoc	Footprint Not Found FUSC3115X6
Add Add	J1 J2	To PCB1.PcbDoc To PCB1.PcbDoc	Footprint Not Found CUI_NSIM-2- Footprint Not Found AMPHENOL
Add		To PCB1.PcbDoc	Footprint Not Found TE CONMHR
Add	J4	To PCB1.PcbDoc	Footprint Not Found TE_CONMHF
Add	<u>L1</u>	To PCB1.PcbDoc	Footprint Not Found IND_LQH66S
Add Add	<u>L2</u> P1	To PCB1.PcbDoc To PCB1.PcbDoc	Footprint Not Found INDC1608X9
Add	P2	To PCB1.PcbDoc	
Add	P3	To PCB1.PcbDoc	
Add Add	Q1 Q2	To PCB1.PcbDoc To PCB1.PcbDoc	Footprint Not Found SOT95P237X Footprint Not Found SOT95P237X
Add	Q2 Q3	To PCB1.PcbDoc	Footprint Not Found SOT95P237X Footprint Not Found SOT95P237X
Add	Q4	To PCB1.PcbDoc	Footprint Not Found SOT95P237X
Add	R1	To PCB1.PcbDoc	Footprint Not Found RESC2012X6
Add Add	R2 R3	To PCB1.PcbDoc To PCB1.PcbDoc	Footprint Not Found RESC2012X6 Footprint Not Found RESC2012X6
Add	R4	To PCB1.PcbDoc	Footprint Not Found RESC2012X6
Add	R5	To PCB1.PcbDoc	Footprint Not Found RESC2012X6
Add	R6 R7	To PCB1.PcbDoc	Footprint Not Found RESC2012X6
Add Add	R8	To PCB1.PcbDoc To PCB1.PcbDoc	Footprint Not Found RESC2012X6 Footprint Not Found RESC2012X6
Add	R9	To PCB1.PcbDoc	Footprint Not Found RESC2012X6
Add	R10	To PCB1.PcbDoc	Footprint Not Found RESC2012X6
Add Add	R11 R12	To PCB1.PcbDoc	Footprint Not Found RESC2012X6
Add	R13	To PCB1.PcbDoc To PCB1.PcbDoc	Footprint Not Found RESC2012X6 Footprint Not Found RESC2012X6
Add	R14	To PCB1.PcbDoc	Footprint Not Found RESC2012X6
Add	R15	To PCB1.PcbDoc	Footprint Not Found RESC2012X6
Add Add	R16 R17	To PCB1.PcbDoc To PCB1.PcbDoc	Footprint Not Found RESC2012X6 Footprint Not Found RESC2012X6
Add	R18	To PCB1.PcbDoc	Footprint Not Found RESC2012X6
Add	R19	To PCB1.PcbDoc	Footprint Not Found RESC2012X6
Add	R20	To PCB1.PcbDoc	Footprint Not Found RESC2012X6

Action	Object	Change Document	Status
Add Co	mponents		
Add	R21	To PCB1.PcbDoc	Footprint Not Found RESC2012X6
Add	R22	To PCB1.PcbDoc	Footprint Not Found RESC2012X6
Add	R23	To PCB1.PcbDoc	Footprint Not Found RESC2012X6
Add	U1	To PCB1.PcbDoc	
Add	U2	To PCB1.PcbDoc	
Add	U3	To PCB1.PcbDoc	Footprint Not Found SOT65P210X
Add	W1	To PCB1.PcbDoc	Footprint Not Found KEYSTONE_:
			•

Action	Object		Change Document	Status
Add Div	ns To Nets			
Add Pil	B1-1 to NetB1_1	In	PCB1.PcbDoc	Unknown Pin: Pin B1-1
Add	B1-2 to USB_DM		PCB1.PcbDoc	Unknown Pin: Pin B1-1
Add	B1-3 to USB_DP		PCB1.PcbDoc	Unknown Pin: Pin B1-3
Add	B1-4 to NetB1_4		PCB1.PcbDoc	Unknown Pin: Pin B1-4
Add	C1-1 to NetC1_1		PCB1.PcbDoc	Unknown Pin: Pin C1-1
Add	C1-2 to NetC1_2		PCB1.PcbDoc	Unknown Pin: Pin C1-2
Add	C2-1 to NetC2_1		PCB1.PcbDoc	Unknown Pin: Pin C2-1
Add	C2-2 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin C2-2
Add Add	C3-1 to NetC3_1 C3-2 to VBAT		PCB1.PcbDoc PCB1.PcbDoc	Unknown Pin: Pin C3-1 Unknown Pin: Pin C3-2
Add	C4-1 to NetC4_1		PCB1.PcbDoc	Unknown Pin: Pin C3-2 Unknown Pin: Pin C4-1
Add	C4-1 to NetC4_1 C4-2 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin C4-2
Add	C5-1 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin C5-1
Add	C5-2 to NetC4_1		PCB1.PcbDoc	Unknown Pin: Pin C5-2
Add	C6-1 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin C6-1
Add	C6-2 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin C6-2
Add	C7-1 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin C7-1
Add	C7-2 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin C7-2
Add Add	C8-1 to VBAT C8-2 to VBAT		PCB1.PcbDoc PCB1.PcbDoc	Unknown Pin: Pin C8-1 Unknown Pin: Pin C8-2
Add	C9-1 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin C9-1
Add	C9-2 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin C9-2
Add	C10-1 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin C10-1
Add	C10-2 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin C10-2
Add	C11-1 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin C11-1
Add	C11-2 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin C11-2
Add	C12-1 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin C12-1
Add Add	C12-2 to VBAT C13-1 to VBAT		PCB1.PcbDoc PCB1.PcbDoc	Unknown Pin: Pin C12-2 Unknown Pin: Pin C13-1
Add	C13-2 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin C13-1
Add	C14-1 to NetC14_1		PCB1.PcbDoc	Unknown Pin: Pin C14-1
Add	C14-2 to NetC14_2		PCB1.PcbDoc	Unknown Pin: Pin C14-2
Add	C15-1 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin C15-1
Add	C15-2 to USIM_VDD		PCB1.PcbDoc	Unknown Pin: Pin C15-2
Add	C16-1 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin C16-1
Add	C16-2 to NetC16_2		PCB1.PcbDoc	Unknown Pin: Pin C16-2
Add Add	C17-1 to VBAT C17-2 to NetC17_2		PCB1.PcbDoc PCB1.PcbDoc	Unknown Pin: Pin C17-1 Unknown Pin: Pin C17-2
Add	C17-2 to NetC17_2 C18-1 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin C18-1
Add	C18-2 to NetC18_2		PCB1.PcbDoc	Unknown Pin: Pin C18-2
Add	C19-1 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin C19-1
Add	C19-2 to VBAT	In	PCB1.PcbDoc	Unknown Pin: Pin C19-2
Add	C20-1 to NetC20_1		PCB1.PcbDoc	Unknown Pin: Pin C20-1
Add	C20-2 to NetC20_2		PCB1.PcbDoc	Unknown Pin: Pin C20-2
Add	C21-1 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin C21-1
Add Add	C21-2 to ANT_GNSS C22-1 to VBAT		PCB1.PcbDoc PCB1.PcbDoc	Unknown Pin: Pin C21-2 Unknown Pin: Pin C22-1
Add	C22-1 to VBA1 C22-2 to NetC20 2		PCB1.PcbDoc	Unknown Pin: Pin C22-1
Add	D1-1 to NetC4_1		PCB1.PcbDoc	Unknown Pin: Pin D1-1
Add	D1-2 to NetD1_2		PCB1.PcbDoc	Unknown Pin: Pin D1-2
Add	D2-A to VBAT	In	PCB1.PcbDoc	Unknown Pin: Pin D2-A
Add	D2-C to NetC4_1		PCB1.PcbDoc	Unknown Pin: Pin D2-C
Add	D3-A to VBAT		PCB1.PcbDoc	Unknown Pin: Pin D3-A
Add Add	D3-C to VBAT		PCB1.PcbDoc PCB1.PcbDoc	Unknown Pin: Pin D3-C
Add	D4-A to VBAT D4-C to NetC1_1		PCB1.PcbDoc	Unknown Pin: Pin D4-A Unknown Pin: Pin D4-C
Add	D5-A to VBAT		PCB1.PcbDoc	Unknown Pin: Pin D5-A
Add	D5-C to NetD5_C		PCB1.PcbDoc	Unknown Pin: Pin D5-C
Add	D6-A to VBAT		PCB1.PcbDoc	Unknown Pin: Pin D6-A
Add	D6-C to NetD6_C		PCB1.PcbDoc	Unknown Pin: Pin D6-C
Add	D7-A to VBAT		PCB1.PcbDoc	Unknown Pin: Pin D7-A
Add	D7-C to VDD_EXT		PCB1.PcbDoc	Unknown Pin: Pin D7-C
Add	D8-A to VBAT		PCB1.PcbDoc	Unknown Pin: Pin D8-A
Add Add	D8-C to USB_DM D9-A to VBAT		PCB1.PcbDoc PCB1.PcbDoc	Unknown Pin: Pin D8-C Unknown Pin: Pin D9-A
Add	D9-A to VBAT		PCB1.PcbDoc	Unknown Pin: Pin D9-A Unknown Pin: Pin D9-C
Add	D10-1 to VBAT		PCB1.PcbDoc	Unknown Pin: Pin D10-1
Add	D10-2 to NetC20_1		PCB1.PcbDoc	Unknown Pin: Pin D10-2
Add	F1-1 to Vin		PCB1.PcbDoc	Unknown Pin: Pin F1-1

Action	Object	Ch	ange Document	Status
A LLD:	- T No.			
	ns To Nets F1-2 to NetD1_2	In DC	D1 DahDaa	Helmoure Dies Die E4 9
Add Add	J1-C1 to USIM_VDD		B1.PcbDoc B1.PcbDoc	Unknown Pin: Pin F1-2 Unknown Pin: Pin J1-C1
Add	J1-C2 to NetC16_2		B1.PcbDoc	Unknown Pin: Pin J1-C2
Add	J1-C3 to NetC17_2		B1.PcbDoc	Unknown Pin: Pin J1-C3
Add	J1-C5 to VBAT		B1.PcbDoc	Unknown Pin: Pin J1-C5
Add	J1-C7 to NetC18_2		B1.PcbDoc	Unknown Pin: Pin J1-C7
Add	J1-S/W to USIM_DET		B1.PcbDoc	Unknown Pin: Pin J1-S/W
Add	J1-SH1 to VBAT		B1.PcbDoc	Unknown Pin: Pin J1-SH1
Add	J1-SH2 to VBAT		B1.PcbDoc	Unknown Pin: Pin J1-SH2
Add	J1-SH3 to VBAT		B1.PcbDoc	Unknown Pin: Pin J1-SH3
Add	J2-1 to USB_VBUS		B1.PcbDoc	Unknown Pin: Pin J2-1
Add	J2-2 to NetB1_4		B1.PcbDoc	Unknown Pin: Pin J2-2
Add Add	J2-3 to NetB1_1 J2-5 to VBAT		B1.PcbDoc B1.PcbDoc	Unknown Pin: Pin J2-3 Unknown Pin: Pin J2-5
Add	J2-St0 VBAT		B1.PcbDoc	Unknown Pin: Pin J2-SH1
Add	J2-SH2 to VBAT		B1.PcbDoc	Unknown Pin: Pin J2-SH2
Add	J2-SH3 to VBAT		B1.PcbDoc	Unknown Pin: Pin J2-SH3
Add	J2-SH4 to VBAT		B1.PcbDoc	Unknown Pin: Pin J2-SH4
Add	J2-SH5 to VBAT		B1.PcbDoc	Unknown Pin: Pin J2-SH5
Add	J2-SH6 to VBAT		B1.PcbDoc	Unknown Pin: Pin J2-SH6
Add	J3-1 to NetJ3_1	In PC	B1.PcbDoc	Unknown Pin: Pin J3-1
Add	J3-2 to NetJ3_2		B1.PcbDoc	Unknown Pin: Pin J3-2
Add	J3-3 to NetJ3_2		B1.PcbDoc	Unknown Pin: Pin J3-3
Add	J3-4 to NetJ3_2		B1.PcbDoc	Unknown Pin: Pin J3-4
Add	J4-1 to NetC20_1		B1.PcbDoc	Unknown Pin: Pin J4-1
Add	J4-2 to NetJ4_2		B1.PcbDoc	Unknown Pin: Pin J4-2
Add Add	J4-3 to NetJ4_2 J4-4 to NetJ4_2		B1.PcbDoc B1.PcbDoc	Unknown Pin: Pin J4-3 Unknown Pin: Pin J4-4
Add	L1-1 to NetC1_1		B1.PcbDoc	Unknown Pin: Pin J4-4 Unknown Pin: Pin L1-1
Add	L1-2 to VBAT		B1.PcbDoc	Unknown Pin: Pin L1-2
Add	L2-1 to NetC20_1		B1.PcbDoc	Unknown Pin: Pin L2-1
Add	L2-2 to NetL2 2		B1.PcbDoc	Unknown Pin: Pin L2-2
Add	P1-1 to VBAT		B1.PcbDoc	Unknown Pin: Pin P1-1
Add	P1-4 to Vin		B1.PcbDoc	Unknown Pin: Pin P1-4
Add	P2-1 to RXD		B1.PcbDoc	Unknown Pin: Pin P2-1
Add	P2-2 to TXD		B1.PcbDoc	Unknown Pin: Pin P2-2
Add	P2-3 to VBAT		B1.PcbDoc	Unknown Pin: Pin P2-3
Add	P3-1 to VBAT		B1.PcbDoc	Unknown Pin: Pin P3-1
Add Add	P3-2 to DBG_TXD		B1.PcbDoc	Unknown Pin: Pin P3-2
Add	P3-3 to DBG_RXD P3-4 to USB_DP		B1.PcbDoc B1.PcbDoc	Unknown Pin: Pin P3-3 Unknown Pin: Pin P3-4
Add	P3-5 to USB_DM		B1.PcbDoc	Unknown Pin: Pin P3-5
Add	P3-6 to USB_VBUS		B1.PcbDoc	Unknown Pin: Pin P3-6
Add	Q1-1 to NetC2_1		B1.PcbDoc	Unknown Pin: Pin Q1-1
Add	Q1-2 to TXD		B1.PcbDoc	Unknown Pin: Pin Q1-2
Add	Q1-3 to MAIN_RXD		B1.PcbDoc	Unknown Pin: Pin Q1-3
Add	Q2-1 to NetC3_1	In PC	B1.PcbDoc	Unknown Pin: Pin Q2-1
Add	Q2-2 to MAIN_TXD		B1.PcbDoc	Unknown Pin: Pin Q2-2
Add	Q2-3 to RXD		B1.PcbDoc	Unknown Pin: Pin Q2-3
Add	Q3-1 to NET_STATUS		B1.PcbDoc	Unknown Pin: Pin Q3-1
Add	Q3-2 to VBAT		B1.PcbDoc	Unknown Pin: Pin Q3-2
Add	Q3-3 to NetQ3_3		B1.PcbDoc	Unknown Pin: Pin Q3-3
Add Add	Q4-1 to STATUS Q4-2 to VBAT		B1.PcbDoc B1.PcbDoc	Unknown Pin: Pin Q4-1 Unknown Pin: Pin Q4-2
Add	Q4-2 to VBA1 Q4-3 to NetQ4_3		B1.PcbDoc	Unknown Pin: Pin Q4-2 Unknown Pin: Pin Q4-3
Add	R1-1 to NetC4_1		B1.PcbDoc	Unknown Pin: Pin R1-1
Add	R1-2 to NetR1_2		B1.PcbDoc	Unknown Pin: Pin R1-2
Add	R2-1 to NetR1_2		B1.PcbDoc	Unknown Pin: Pin R2-1
Add	R2-2 to VBAT		B1.PcbDoc	Unknown Pin: Pin R2-2
Add	R3-1 to NetC2_1		B1.PcbDoc	Unknown Pin: Pin R3-1
Add	R3-2 to VBAT		B1.PcbDoc	Unknown Pin: Pin R3-2
Add	R4-1 to NetC3_1		B1.PcbDoc	Unknown Pin: Pin R4-1
Add	R4-2 to VBAT		B1.PcbDoc	Unknown Pin: Pin R4-2
Add	R5-1 to MAIN_RXD		B1.PcbDoc	Unknown Pin: Pin R5-1
Add	R5-2 to VBAT		B1.PcbDoc	Unknown Pin: Pin R5-2
Add	R6-1 to RXD		B1.PcbDoc	Unknown Pin: Pin R6-1
Add	R6-2 to VBAT		B1.PcbDoc	Unknown Pin: Pin R6-2
Add Add	R7-1 to NetR7_1 R7-2 to VBAT		B1.PcbDoc B1.PcbDoc	Unknown Pin: Pin R7-1 Unknown Pin: Pin R7-2
Auu	INT-Z IU VDMI	III PC	DI.I CUDUC	Ulikiluwii Fili. Pili K1-2

Add Pins 10 Nats	Action	Object	Change Document	Status
Add R8-1 to VRAT	Add Div	an To Note		
Add R8-10 WBRT			In DCR1 PobDoo	Unknown Din: Din D8 1
Acid R9-1 to NBAT				
AGS R9-10 NatCH 1 In PGB Pebbloe Uniscount Pin Pin R9-2 Add R10-10 Nat Nat In PGB Pebbloe Uniscount Pin Pin R10-1 Add R11-10 UNISM VDD In PGB Pebbloe Uniscount Pin Pin R10-1 Add R11-10 UNISM VDD In PGB Pebbloe Uniscount Pin Pin R10-1 Add R11-10 UNISM VDD In PGB Pebbloe Uniscount Pin Pin R11-1 Add R11-10 NatCH 2-1 In PGB Pebbloe Uniscount Pin Pin R11-1 Add R12-10 UNISM VDD EXT In PGB Pebbloe Uniscount Pin Pin R11-1 Add R12-10 UNISM VDD EXT In PGB Pebbloe Uniscount Pin Pin R11-1 Add R12-10 UNISM VDD EXT In PGB Pebbloe Uniscount Pin Pin R12-1 Add R12-10 UNISM VDD EXT In PGB Pebbloe Uniscount Pin Pin R12-1 Add R13-10 UNISM VDD EXT In PGB Pebbloe Uniscount Pin Pin R12-1 Add R13-10 UNISM VDD EXT In PGB Pebbloe Uniscount Pin Pin R12-1 Add R13-10 UNISM VDD EXT In PGB Pebbloe Uniscount Pin Pin R13-1 Add R13-10 UNISM VDD EXT In PGB Pebbloe Uniscount Pin Pin R13-1 Add R13-10 UNISM VDD EXT In PGB Pebbloe Uniscount Pin Pin R13-1 Add R13-10 UNISM VDD EXT In PGB Pebbloe Uniscount Pin Pin R13-1 Add R13-10 UNISM VDD EXT In PGB Pebbloe Uniscount Pin Pin R13-1 Add R13-10 UNISM VDD EXT In PGB Pebbloe Uniscount Pin Pin R13-1 Add R13-10 Nation State VDD EXT In PGB Pebbloe Uniscount Pin Pin R13-1 Add R13-10 Nation State VDD EXT In PGB Pebbloe Uniscount Pin Pin R13-1 Add R13-10 Nation State VDD EXT In PGB Pebbloe Uniscount Pin Pin R13-1 Add R13-10 Nation State VDD EXT In PGB Pebbloe Uniscount Pin Pin R13-1 Add R13-10 Nation State VDD EXT In PGB Pebbloe Uniscount Pin Pin R13-1 In PGB Pebbloe Uniscoun				
AGS R10-1 to VSAIT In PCBI PackOc Uniscount Pin Pin R10-1				
AGS				
Add R11-2 to NoC18-2 in PCBI Pebbos Unknown Pin Pin R11-2 Add R11-2 to USIM DET in PCBI Pebbos Unknown Pin Pin R12-1 Add R11-1 to USIM RST in PCBI Pebbos Unknown Pin Pin R12-2 Add R11-1 to USIM RST in PCBI Pebbos Unknown Pin Pin R13-4 Add R11-1 to USIM RST in PCBI Pebbos Unknown Pin Pin R13-4 Add R11-1 to USIM CRI in PCBI Pebbos Unknown Pin Pin R13-4 Add R11-1 to USIM CRI in PCBI Pebbos Unknown Pin Pin R13-4 Add R11-1 to USIM CRI in PCBI Pebbos Unknown Pin Pin R14-1 Add R11-1 to USIM OATA in PCBI Pebbos Unknown Pin Pin R14-1 Add R11-1 to USIM OATA in PCBI Pebbos Unknown Pin Pin R14-1 Add R11-1 to USIM OATA in PCBI Pebbos Unknown Pin Pin R14-1 Add R11-1 to USIM OATA in PCBI Pebbos Unknown Pin Pin R14-1 Add R11-1 to Net-2 2 in PCBI Pebbos Unknown Pin Pin R14-1 Add R11-1 to Net-2 3 in PCBI Pebbos Unknown Pin Pin R15-1 Add R11-1 to Net-2 3 in PCBI Pebbos Unknown Pin Pin R15-1 Add R11-1 to Net-2 3 in PCBI Pebbos Unknown Pin Pin R15-1 Add R11-1 to Net-2 3 in PCBI Pebbos Unknown Pin Pin R16-1 Add R11-1 to Net-2 3 in PCBI Pebbos Unknown Pin Pin R16-1 Add R11-1 to Net-2 3 in PCBI Pebbos Unknown Pin Pin R16-1 Add R11-1 to Net-2 3 in PCBI Pebbos Unknown Pin Pin R16-1 Add R11-1 to Net-2 3 in PCBI Pebbos Unknown Pin Pin R16-1 Add R11-1 to Net-2 3 in PCBI Pebbos Unknown Pin Pin R16-1 Add R11-2 to Net-2 5 in PCBI Pebbos Unknown Pin Pin R16-1 Add R11-2 to Net-2 5 in PCBI Pebbos Unknown Pin Pin R18-1 Add R11-2 to Net-2 5 in PCBI Pebbos Unknown Pin Pin R18-1 Add R11-2 to Net-2 5 in PCBI Pebbos Unknown Pin Pin R18-1 Add R11-2 to Net-2 5 in PCBI Pebbos Unknown Pin Pin R18-1 Add R11-2 to Net-2 5 in PCBI Pebbos Unknown Pin Pin R18-1 Add R11-2 to Net-2 5 in PCBI Pebbos Unknown Pin Pin R18-1 Add R11-2 to Net-2 5 in PCBI Pebbos Unknown Pin Pin R18-1 Add R11-2 to Net-2 5 in PCBI Pebbos Unknown Pin Pin R12-1 Add R11-2 to Net-2 5 in PCBI Pebbos Unknown Pin Pin R12-1 Add R11-2 to Net-2 5 in PCBI Pebbos Unknown Pin Pin R12-1 Add R11-2 to Net-2 5 in PCBI Pebbos Unknown Pin Pin R12-1 Add R11-3 to Net-2 5 in PCBI Pebbos Unknown Pin Pin R12-1 A	Add		In PCB1.PcbDoc	Unknown Pin: Pin R10-2
Add R12-16 V/D_EXT In PCBI Pebbo Unknown Pin Pn R12-1 Add R12-16 USIM RST In PCBI Pebbo Unknown Pin Pn R13-1 Add R13-16 USIM RST In PCBI Pebbo Unknown Pin Pn R13-1 Add R13-16 USIM RST In PCBI Pebbo Unknown Pin Pn R13-1 Add R14-16 USIM CNL In PCBI Pebbo Unknown Pin Pn R13-1 Add R14-16 USIM CNL In PCBI Pebbo Unknown Pin Pn R13-1 Add R14-16 USIM CNL In PCBI Pebbo Unknown Pin Pn R14-1 Add R14-16 USIM CNL In PCBI Pebbo Unknown Pin Pn R14-1 Add R14-16 USIM CNATA In PCBI Pebbo Unknown Pin Pn R14-1 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R15-1 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R15-1 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R15-1 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R15-1 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R15-1 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R15-1 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R15-1 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R15-1 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R15-1 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R17-2 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R17-2 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R17-2 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R17-2 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R17-2 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R18-1 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R18-1 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R18-1 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R18-1 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R18-1 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R18-1 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R18-1 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R18-2 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R18-2 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R12-1 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn R13-1 Add R15-16 USIM DATA In PCBI Pebbo Unknown Pin Pn U1-1 Add U1-16 USIM DATA In PCBI Pebbo Unknown Pin Pn U1-1 Add U1-16 USIM DATA In PCBI Pebbo Unknown				
Add R13-2 to USIM. DET In PCBI PebDoc Unknown Pin. Pn R13-2 Add R13-1 to USIM. CRIST In PCBI PebDoc Unknown Pin. Pn R13-3 Add R14-1 to USIM. CRIS. In PCBI PebDoc Unknown Pin. Pn R13-4 Add R14-1 to USIM. CRIS. In PCBI PebDoc Unknown Pin. Pn R13-4 Add R14-1 to USIM. CRIS. In PCBI PebDoc Unknown Pin. Pn R14-1 Add R14-1 to USIM. DATA In PCBI PebDoc Unknown Pin. Pn R14-1 Add R14-1 to USIM. DATA In PCBI PebDoc Unknown Pin. Pn R14-1 Add R14-1 to USIM. DATA In PCBI PebDoc Unknown Pin. Pn R14-2 Add R14-1 to USIM. DATA In PCBI PebDoc Unknown Pin. Pn R15-2 Add R16-1 to Neu03.3 In PCBI PebDoc Unknown Pin. Pn R15-2 Add R16-1 to Neu03.3 In PCBI PebDoc Unknown Pin. Pn R15-4 Add R16-1 to Neu03.3 In PCBI PebDoc Unknown Pin. Pn R16-1 Add R16-1 to Neu04.3 In PCBI PebDoc Unknown Pin. Pn R16-1 Add R17-1 to Neu04.3 In PCBI PebDoc Unknown Pin. Pn R17-2 Add R17-1 to Neu05.0 In PCBI PebDoc Unknown Pin. Pn R17-2 Add R16-1 to NeuR18-1 In PCBI PebDoc Unknown Pin. Pn R17-2 Add R18-1 to NeuR18-1 In PCBI PebDoc Unknown Pin. Pn R18-1 Add R18-1 to NeuR18-1 In PCBI PebDoc Unknown Pin. Pn R18-1 Add R18-1 to NeuR18-1 In PCBI PebDoc Unknown Pin. Pn R18-1 Add R18-1 to VDD. EXT In PCBI PebDoc Unknown Pin. Pn R18-1 Add R19-2 to VDD. EXT In PCBI PebDoc Unknown Pin. Pn R18-1 Add R20-1 to VDD. EXT In PCBI PebDoc Unknown Pin. Pn R18-1 Add R20-1 to VDD. EXT In PCBI PebDoc Unknown Pin. Pn R18-1 Add R20-1 to NeuR19-1 In PCBI PebDoc Unknown Pin. Pn R18-2 Add R20-1 to NeuR19-1 In PCBI PebDoc Unknown Pin. Pn R20-1 Add R20-1 to NeuR19-1 In PCBI PebDoc Unknown Pin. Pn R20-1 Add R20-1 to NeuR19-1 In PCBI PebDoc Unknown Pin. Pn R20-1 Add R20-1 to NeuR19-1 In PCBI PebDoc Unknown Pin. Pn R20-1 Add R20-1 to NeuR19-1 In PCBI PebDoc Unknown Pin. Pn R20-1 Add R20-1 to NeuR19-1 In PCBI PebDoc Unknown Pin. Pn R20-1 Add R20-1 to NeuR19-1 In PCBI PebDoc Unknown Pin. Pn R20-1 Add R20-1 to NeuR19-1 In PCBI PebDoc Unknown Pin. Pn R20-1 Add R20-1 to NeuR19-1 In PCBI PebDoc Unknown Pin. Pn R20-1 Add R20-1 to NeuR19-1 In PCBI PebDoc Unknown Pin. Pn R20-1 In PCBI PebDoc Unknown Pi				
Add R15-10 USMIR RST In PCB1 PebBoc Unknown Pinr Pin R13-1 Add R15-10 USMIR CKL In PCB1 PebBoc Unknown Pinr Pin R13-1 Add R14-10 USMIR CKL In PCB1 PebBoc Unknown Pinr Pin R14-1 Add R14-10 USMIR CKL In PCB1 PebBoc Unknown Pinr Pin R14-1 Add R15-10 USMIR DATA In PCB1 PebBoc Unknown Pinr Pin R14-2 Add R15-10 USMIR DATA In PCB1 PebBoc Unknown Pinr Pin R15-1 Add R15-10 USMIR DATA In PCB1 PebBoc Unknown Pinr Pin R15-1 Add R15-10 USMIR DATA In PCB1 PebBoc Unknown Pinr Pin R15-2 Add R16-10 Ne03 3 In PCB1 PebBoc Unknown Pinr Pin R15-2 Add R16-10 Ne03 3 In PCB1 PebBoc Unknown Pinr Pin R16-1 Add R16-10 Ne04 3 In PCB1 PebBoc Unknown Pinr Pin R16-2 Add R17-10 Ne04 3 In PCB1 PebBoc Unknown Pinr Pin R16-2 Add R17-10 Ne04 3 In PCB1 PebBoc Unknown Pinr Pin R17-2 Add R15-10 Ne04 5 In PCB1 PebBoc Unknown Pinr Pin R17-2 Add R15-10 Ne04 5 In PCB1 PebBoc Unknown Pinr Pin R17-2 Add R15-10 Ne04 5 In PCB1 PebBoc Unknown Pinr Pin R18-1 Add R15-10 Ne04 5 In PCB1 PebBoc Unknown Pinr Pin R18-1 Add R15-10 VBAT In PCB1 PebBoc Unknown Pinr Pin R18-1 Add R15-10 VBAT In PCB1 PebBoc Unknown Pinr Pin R18-1 Add R15-10 VBAT In PCB1 PebBoc Unknown Pinr Pin R18-1 Add R15-10 VBAT In PCB1 PebBoc Unknown Pinr Pin R18-1 Add R20-10 VBAT In PCB1 PebBoc Unknown Pinr Pin R18-1 Add R20-10 VBAT In PCB1 PebBoc Unknown Pinr Pin R18-1 Add R20-10 VBAT In PCB1 PebBoc Unknown Pinr Pin R18-1 Add R20-10 VBAT In PCB1 PebBoc Unknown Pinr Pin R18-1 Add R20-10 VBAT In PCB1 PebBoc Unknown Pinr Pin R20-1 Add R20-10 VBAT In PCB1 PebBoc Unknown Pinr Pin R20-1 Add R20-10 VBAT In PCB1 PebBoc Unknown Pinr Pin R20-1 Add R20-10 VBAT In PCB1 PebBoc Unknown Pinr Pin R20-1 Add R20-10 VBAT In PCB1 PebBoc Unknown Pinr Pin R20-1 Add R20-10 VBAT In PCB1 PebBoc Unknown Pinr Pin R20-1 Add R20-10 VBAT In PCB1 PebBoc Unknown Pinr Pin R20-1				
Add R14-12 to Metric 2				
Add R14-10 USIM CKL In POSI Pebbo Unknown Pin: Pin R14-1 Add R14-20 UNknown Pin: Pin R14-2 In POSI Pebbo Unknown Pin: Pin R14-2 Add R15-10 USIM DATA In POSI Pebbo Unknown Pin: Pin R15-1 Add R15-10 USIM DATA In POSI Pebbo Unknown Pin: Pin R15-1 Add R15-10 Net/3 3 In POSI Pebbo Unknown Pin: Pin R15-1 Add R16-10 Net/3 3 In POSI Pebbo Unknown Pin: Pin R16-1 Add R16-2 to Net/5 C In POSI Pebbo Unknown Pin: Pin R16-1 Add R16-2 to Net/5 C In POSI Pebbo Unknown Pin: Pin R16-1 Add R17-10 Net/4 3 In POSI Pebbo Unknown Pin: Pin R16-1 Add R17-10 Net/4 3 In POSI Pebbo Unknown Pin: Pin R17-1 Add R17-2 to Net/5 C In POSI Pebbo Unknown Pin: Pin R17-1 Add R17-2 to Net/5 C In POSI Pebbo Unknown Pin: Pin R17-1 Add R17-2 to Net/5 C In POSI Pebbo Unknown Pin: Pin R17-1 Add R18-1 to Net/81-1 In POSI Pebbo Unknown Pin: Pin R18-1 In POSI Pebbo Unknown Pin: Pin R18-1 Add R18-1 to Net/81-2 to Net/5 C In POSI Pebbo Unknown Pin: Pin R18-1 Add R19-1 to PWRKEY In POSI Pebbo Unknown Pin: Pin R18-1 Add R19-1 to VDD EXT In POSI Pebbo Unknown Pin: Pin R19-1 Add R20-1 to VDD EXT In POSI Pebbo Unknown Pin: Pin R19-1 Add R20-1 to VDD EXT In POSI Pebbo Unknown Pin: Pin R20-1 Add R20-1 to VDD EXT In POSI Pebbo Unknown Pin: Pin R20-1 Add R20-1 to VDD EXT In POSI Pebbo Unknown Pin: Pin R20-1 Add R20-1 to Net/3 In POSI Pebbo Unknown Pin: Pin R20-1 Add R20-1 to Net/3 In POSI Pebbo Unknown Pin: Pin R20-1 Add R20-1 to Net/3 In POSI Pebbo Unknown Pin: Pin R20-1 Add R20-1 to Net/3 In POSI Pebbo Unknown Pin: Pin R20-1 Add R20-1 to Net/3 In POSI Pebbo Unknown Pin: Pin R21-1 Add R20-1 to Net/3 In POSI Pebbo Unknown Pin: Pin R21-1 Add R20-1 to Net/3 In POSI Pebbo Unknown Pin: Pin R21-1 Add R20-1 to Net/3 In POSI Pebbo Unknown Pin: Pin R21-1 Add R20-1 to Net/3 In POSI Pebbo Unknown Pin: Pin R21-1 Add R20-1 to Net/3 In POSI Pebbo Unknown Pin: Pin R23-1 Add R20-1 to Net/3 In POSI Pebbo Unknown Pin: Pin R23-1 Add R20-1 to Net/3 In POSI Pebbo Unknown Pin: Pin R23-1 Add R20-1 to Net/3 In POSI Pebbo Unknown Pin: Pin R23-1 Add U1-1 to Net/1 In POSI Pebbo Unknown Pin: Pi				
Add R1-2 to NetC17_2 In PCB1 PebDoc Unknown Pin: Pin R14-2 Add R15-2 to NetC18_2 In PCB1 PebDoc Unknown Pin: Pin R15-1 Add R15-2 to NetC18_2 In PCB1 PebDoc Unknown Pin: Pin R15-2 Add R16-2 to NetD5_C In PCB1 PebDoc Unknown Pin: Pin R15-2 Add R16-2 to NetD5_C In PCB1 PebDoc Unknown Pin: Pin R16-2 Add R17-2 to NetD6_C In PCB1 PebDoc Unknown Pin: Pin R16-2 Add R17-2 to NetD6_C In PCB1 PebDoc Unknown Pin: Pin R17-2 Add R18-2 to NetD6_C In PCB1 PebDoc Unknown Pin: Pin R17-2 Add R18-1 to NetD6_C In PCB1 PebDoc Unknown Pin: Pin R17-2 Add R18-2 to VBAT In PCB1 PebDoc Unknown Pin: Pin R17-2 Add R18-2 to VBAT In PCB1 PebDoc Unknown Pin: Pin R18-2 Add R18-2 to VBAT In PCB1 PebDoc Unknown Pin: Pin R18-2 Add R19-2 to VBAT In PCB1 PebDoc Unknown Pin: Pin R18-2 Add R19-2 to VBAT In PCB1 PebDoc Unknown Pin: Pin R18-2 Add R20-2 to MAN DTR In PCB1 PebDoc Unknown Pin: Pin R19-2 Add R20-2 to MAN DTR In PCB1 PebDoc Unknown Pin: Pin R19-2 Add R20-2 to MAN DTR In PCB1 PebDoc Unknown Pin: Pin R19-2 Add R21-2 to VBAT In PCB1 PebDoc Unknown Pin: Pin R19-2 Add R21-2 to VBAT In PCB1 PebDoc Unknown Pin: Pin R20-2 Add R21-2 to VBAT In PCB1 PebDoc Unknown Pin: Pin R20-2 Add R22-2 to VBAT In PCB1 PebDoc Unknown Pin: Pin R20-2 Add R22-2 to VBAT In PCB1 PebDoc Unknown Pin: Pin R20-2 Add R22-2 to VBAT In PCB1 PebDoc Unknown Pin: Pin R20-2 Add R22-2 to VBAT In PCB1 PebDoc Unknown Pin: Pin R20-2 Add R22-2 to VBAT In PCB1 PebDoc Unknown Pin: Pin R20-2 Add R22-2 to VBAT In PCB1 PebDoc Unknown Pin: Pin R20-2 Add R22-2 to VBAT In PCB1 PebDoc Unknown Pin: Pin R20-2 Add R22-2 to VBAT In PCB1 PebDoc Unknown Pin: Pin R20-2 Add R22-2 to VBAT In PCB1 PebDoc Unknown Pin: Pin R20-2 Add R22-2 to VBAT In PCB1 PebDoc Unknown Pin: Pin R20-2 Add R22-2 to VBAT In PCB1 PebDoc Unknown Pin: Pin R20-2 Add R22-2 to VBAT				
Add R15-1 to USIM DATA MR 17-10 to Net03.3 MR 16-1 to Net03.3 MR 16-10 Net03.3 MR 16-10 Net03.3 MR 17-11 to Net04.3 MR 17-10 Net04.3 MR 17-11 to Net04.3 MR 17-10 Net04.3 MR 18-10 Net118.1 MR 18-10 Net1				
Add R15-2 to NetCi 2				
Add R16-1 to Net03 3				
Add R17-1 to Net04 3			In PCB1.PcbDoc	Unknown Pin: Pin R16-1
Add R13 to NeR18 1 In PGB1 PebDoc Unknown Pm. Pin R17-2 Add R13 to NeR18 1 In PGB1 PebDoc Unknown Pm. Pin R18-1 Add R13 to NeR18 1 In PGB1 PebDoc Unknown Pm. Pin R18-2 Add R13 to NeR18 1 In PGB1 PebDoc Unknown Pm. Pin R18-2 Add R13 to NeR18 1 In PGB1 PebDoc Unknown Pm. Pin R18-2 Add R19 to NeR18 1 In PGB1 PebDoc Unknown Pm. Pin R18-2 Add R20 to NDD EXT In PGB1 PebDoc Unknown Pm. Pin R18-2 Add R20 to NDD EXT In PGB1 PebDoc Unknown Pm. Pin R20-1 Add R20 to NDD EXT In PGB1 PebDoc Unknown Pm. Pin R20-1 Add R20 to NDD EXT In PGB1 PebDoc Unknown Pm. Pin R20-1 Add R20 to NDD EXT In PGB1 PebDoc Unknown Pm. Pin R20-2 Add R21 to NeR12 In PGB1 PebDoc Unknown Pm. Pin R20-2 Add R21 to NBAS In PGB1 PebDoc Unknown Pm. Pin R21-2 Add R22 to NBAS In PGB1 PebDoc Unknown Pm. Pin R21-2 Add R22 to NBAS In PGB1 PebDoc Unknown Pm. Pin R22-2 Add R22 to NBAS In PGB1 PebDoc Unknown Pm. Pin R22-2 Add R23 to NBCC0 2 In PGB1 PebDoc Unknown Pm. Pin R23-1 Add R23 to NBCC0 2 In PGB1 PebDoc Unknown Pm. Pin R23-1 Add R23 to NBCC0 2 In PGB1 PebDoc Unknown Pm. Pin R23-2 Add R23 to NBCC0 2 In PGB1 PebDoc Unknown Pm. Pin R23-2 Add U1-1 to NBCC1 1 In PGB1 PebDoc Unknown Pm. Pin R23-2 Add U1-1 to NBCC1 1 In PGB1 PebDoc Unknown Pm. Pin U1-1 Add U1-5 to NBAT In PGB1 PebDoc Unknown Pm. Pin U1-1 Add U1-2 to NBC1 2 In PGB1 PebDoc Unknown Pm. Pin U1-1 Add U1-3 to NBCC1 4 In PGB1 PebDoc Unknown Pm. Pin U1-1 Add U1-5 to NBAT In PGB1 PebDoc Unknown Pm. Pin U1-1 Add U1-5 to NBAT In PGB1 PebDoc Unknown Pm. Pin U1-1 Add U1-5 to NBAT In PGB1 PebDoc Unknown Pm. Pin U1-1 Add U1-5 to NBAT In PGB1 PebDoc Unknown Pm. Pin U1-1 Add U1-5 to NBAT In PGB1 PebDoc Unknown Pm. Pin U1-1 Add U1-5 to NBAT In PGB1 PebDoc Unknown Pm. Pin U1-1 Add U1-5 to NBAT In PGB1 PebDoc Unknown Pm. Pin U1-1 Add U1-5 to NBAT In PGB1 PebDo				
Add R18-1 to NeR18-1 In PG81 PebDoc Unknown Prn: Pin R18-1 Add R19-1 to PVATT In PG81 PebDoc Unknown Prn: Pin R19-2 Add R19-1 to PVATT In PG81 PebDoc Unknown Prn: Pin R19-1 Add R19-1 to PVATT In PG81 PebDoc Unknown Prn: Pin R19-1 Add R19-1 to VBAT In PG81 PebDoc Unknown Prn: Pin R19-2 Add R20-1 to VBAT In PG81 PebDoc Unknown Prn: Pin R20-1 Add R20-2 to MAN DTR In PG81 PebDoc Unknown Prn: Pin R20-1 Add R20-2 to MAN DTR In PG81 PebDoc Unknown Prn: Pin R20-2 Add R20-2 to MAN DTR In PG81 PebDoc Unknown Prn: Pin R20-2 Add R20-2 to MAN DTR In PG81 PebDoc Unknown Prn: Pin R20-2 Add R20-2 to MAN T GSM In PG81 PebDoc Unknown Prn: Pin R20-2 Add R20-2 to NAT GSM In PG81 PebDoc Unknown Prn: Pin R20-1 Add R20-2 to NAT GSM In PG81 PebDoc Unknown Prn: Pin R20-2 Add R20-2 to NAT GSM In PG81 PebDoc Unknown Prn: Pin R20-2 Add R20-2 to NAT GSM In PG81 PebDoc Unknown Prn: Pin R20-2 Add U1-1 to NetC1 In PG81 PebDoc Unknown Prn: Pin R20-2 Add U1-2 to NetR1 2 In PG81 PebDoc Unknown Prn: Pin R20-2 Add U1-2 to NetR1 2 In PG81 PebDoc Unknown Prn: Pin In R20-2 Add U1-2 to NetR1 2 In PG81 PebDoc Unknown Prn: Pin In U1-1 Add U1-2 to NetR1 2 In PG81 PebDoc Unknown Prn: Pin In U1-1 Add U1-3 to NetC1 2 In PG81 PebDoc Unknown Prn: Pin In U1-1 Add U1-3 to NetC1 2 In PG81 PebDoc Unknown Prn: Pin In U1-3 Add U1-4 to NetR2 1 In PG81 PebDoc Unknown Prn: Pin In U1-5 Add U1-5 to NetC1 2 In PG81 PebDoc Unknown Prn: Pin U1-5 Add U1-5 to NetC4 1 In PG81 PebDoc Unknown Prn: Pin U1-6 Add U1-5 to NetC4 1 In PG81 PebDoc Unknown Prn: Pin U1-6 Add U1-5 to NetC4 1 In PG81 PebDoc Unknown Prn: Pin U1-6 Add U1-5 to NetC4 1 In PG81 PebDoc Unknown Prn: Pin U1-6 Add U1-5 to NetC4 1 In PG81 PebDoc Unknown Prn: Pin U1-6 Add U1-5 to NetC4 1 In PG81 PebDoc Unknown Prn: Pin U1-6 Add U1-5 to NetC4 1 In PG81 PebDoc Unknown Prn: P				
Add R19-1 to PMRKEY In PCB1 PedDoc Unknown Prin Pin R19-2				
Add R19-1 to PWRKEY In PGBI PebDoc Unknown Prin Pin R19-1 Add R19-2 to VBAT In PGBI PebDoc Unknown Prin Pin R20-1 Add R20-1 to VDD EXT In PCBI PebDoc Unknown Prin Pin R20-1 Add R20-1 to WND In PCBI PebDoc Unknown Prin Pin R20-1 Add R21-1 to WBAT In PCBI PebDoc Unknown Prin Pin R21-1 Add R22-1 to WBAT In PCBI PebDoc Unknown Prin Pin R21-1 Add R22-1 to NBAT In PCBI PebDoc Unknown Prin Pin R22-1 Add R22-1 to NBAT GSM In PCBI PebDoc Unknown Prin Pin R22-1 Add R22-1 to NBAT GSMS In PCBI PebDoc Unknown Prin Pin R23-1 Add R23-1 to NBAT GMSS In PCBI PebDoc Unknown Prin Pin R23-2 Add U.1 to NetCl 1 In PCBI PebDoc Unknown Prin Pin U1-1 Add U.1 to NetCl 2 In PCBI PebDoc Unknown Prin Pin U1-1 Add U.1 to NetCl 2 In PCBI PebDoc Unknown Prin Pin U1-1 Add U.1 to NetCl 3 In PCBI PebDoc Unknown Prin Pin U1-3 <tr< td=""><td></td><td></td><td></td><td></td></tr<>				
Add R20-1 to VDD EXT In PCBI PebDoc Unknown Pin: Pin R20-1				
Add R20-1 to VDD EXT In PC81 PcbDoc Unknown Pin: Pin R20-1 Add R20-2 to MAIN DTIR In PC81 PcbDoc Unknown Pin: Pin R20-2 Add R21-1 to Nelt_2 In PC81 PcbDoc Unknown Pin: Pin R20-1 Add R21-1 to Nelt_3 In PC81 PcbDoc Unknown Pin: Pin R21-1 Add R21-1 to Nelt_3 In PC81 PcbDoc Unknown Pin: Pin R21-1 Add R22-1 to Nelt_3 In PC81 PcbDoc Unknown Pin: Pin R21-1 Add R22-1 to Nelt_3 In PC81 PcbDoc Unknown Pin: Pin R22-1 Add R22-1 to Nelt_3 In PC81 PcbDoc Unknown Pin: Pin R22-1 Add R23-1 to Nelt_2 In PC81 PcbDoc Unknown Pin: Pin R22-1 Add R23-2 to ANT GNS In PC81 PcbDoc Unknown Pin: Pin R23-1 Add U1-1 to Nelt_1 In PC81 PcbDoc Unknown Pin: Pin U1-1 Add U1-2 to NelR1 2 In PC81 PcbDoc Unknown Pin: Pin U1-1 Add U1-2 to NelR1 2 In PC81 PcbDoc Unknown Pin: Pin U1-1 Add U1-3 to NelC14 2 In PC81 PcbDoc Unknown Pin: Pin U1-3 Add U1-4 to NelR1 1 In PC81 PcbDoc Unknown Pin: Pin U1-3 Add U1-4 to NelR1 1 In PC81 PcbDoc Unknown Pin: Pin U1-3 Add U1-4 to NelR2 In PC81 PcbDoc Unknown Pin: Pin U1-3 Add U1-6 to NelR2 In PC81 PcbDoc Unknown Pin: Pin U1-3 Add U1-6 to NelR2 In PC81 PcbDoc Unknown Pin: Pin U1-6 Add U1-6 to NelR2 In PC81 PcbDoc Unknown Pin: Pin U1-6 Add U1-6 to NelR2 In PC81 PcbDoc Unknown Pin: Pin U1-7 Add U1-8 to NelC1 In PC81 PcbDoc Unknown Pin: Pin U1-7 Add U1-8 to NelC1 In PC81 PcbDoc Unknown Pin: Pin U1-7 Add U1-9 to NelC2 In PC81 PcbDoc Unknown Pin: Pin U1-7 Add U1-9 to NelC2 In PC81 PcbDoc Unknown Pin: Pin U1-7 Add U1-9 to NelC2 In PC81 PcbDoc Unknown Pin: Pin U1-7 Add U1-9 to NelC2 In PC81 PcbDoc Unknown Pin: Pin U1-7 Add U1-9 to NelC2 In PC81 PcbDoc Unknown Pin: Pin U1-7 Add U1-9 to NelC2 Unknown Pin: Pin U1-1 Add U1-9 to NelC2 Unknown Pin: Pin				
Add R20-2 to MAIN DTR				
Add	_			
Add				
Add	Add	R21-2 to VBAT		Unknown Pin: Pin R21-2
Add				
Add U1-8 to NetC1 2	Add	U1-6 to NetR8_2	In PCB1.PcbDoc	Unknown Pin: Pin U1-6
Add U-9 to VBAT				
Add U2-1 to ANT GNSS				
Add U2-7 to PWRKEY In PCB1.PcbDoc Unknown Pin: Pin U2-7 Add U2-11 to USIM_DATA In PCB1.PcbDoc Unknown Pin: Pin U2-11 Add U2-12 to USIM_RST In PCB1.PcbDoc Unknown Pin: Pin U2-12 Add U2-13 to USIM_CKL In PCB1.PcbDoc Unknown Pin: Pin U2-13 Add U2-14 to USIM_VDD In PCB1.PcbDoc Unknown Pin: Pin U2-14 Add U2-16 to NET_STATUS In PCB1.PcbDoc Unknown Pin: Pin U2-14 Add U2-16 to NET_STATUS In PCB1.PcbDoc Unknown Pin: Pin U2-17 Add U2-17 to MAIN_RXD In PCB1.PcbDoc Unknown Pin: Pin U2-17 Add U2-18 to MAIN_TXD In PCB1.PcbDoc Unknown Pin: Pin U2-18 Add U2-18 to MAIN_DTR In PCB1.PcbDoc Unknown Pin: Pin U2-18 Add U2-24 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U2-24 Add U2-25 to STATUS In PCB1.PcbDoc Unknown Pin: Pin U2-25 Add U2-35 to ANT_GSM In PCB1.PcbDoc Unknown Pin: Pin U2-35 Add U2-35 to DBG_RXD In PCB1.PcbDoc Unknown Pin: Pin U2-39	_			
Add U2-11 to USIM_DATA In PCB1.PcbDoc Unknown Pin: Pin U2-11 Add U2-12 to USIM_RST In PCB1.PcbDoc Unknown Pin: Pin U2-12 Add U2-13 to USIM_CKL In PCB1.PcbDoc Unknown Pin: Pin U2-13 Add U2-14 to USIM_VDD In PCB1.PcbDoc Unknown Pin: Pin U2-14 Add U2-16 to NET_STATUS In PCB1.PcbDoc Unknown Pin: Pin U2-16 Add U2-16 to NET_STATUS In PCB1.PcbDoc Unknown Pin: Pin U2-16 Add U2-17 to MAIN_RXD In PCB1.PcbDoc Unknown Pin: Pin U2-17 Add U2-18 to MAIN_TXD In PCB1.PcbDoc Unknown Pin: Pin U2-18 Add U2-19 to MAIN_DTR In PCB1.PcbDoc Unknown Pin: Pin U2-18 Add U2-24 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U2-24 Add U2-25 to STATUS In PCB1.PcbDoc Unknown Pin: Pin U2-25 Add U2-35 to ANT_GSM In PCB1.PcbDoc Unknown Pin: Pin U2-35 Add U2-36 to ANT_GSM In PCB1.PcbDoc Unknown Pin: Pin U2-38 Add U2-39 to DBG_TXD In PCB1.PcbDoc Unknown Pin: Pin U2-39 <td></td> <td></td> <td></td> <td></td>				
Add U2-12 to USIM_RST In PCB1.PcbDoc Unknown Pin: Pin U2-12 Add U2-13 to USIM_CKL In PCB1.PcbDoc Unknown Pin: Pin U2-13 Add U2-14 to USIM_VDD In PCB1.PcbDoc Unknown Pin: Pin U2-14 Add U2-16 to NET_STATUS In PCB1.PcbDoc Unknown Pin: Pin U2-16 Add U2-17 to MAIN_RXD In PCB1.PcbDoc Unknown Pin: Pin U2-17 Add U2-18 to MAIN_TXD In PCB1.PcbDoc Unknown Pin: Pin U2-18 Add U2-19 to MAIN_DTR In PCB1.PcbDoc Unknown Pin: Pin U2-19 Add U2-24 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U2-24 Add U2-25 to STATUS In PCB1.PcbDoc Unknown Pin: Pin U2-25 Add U2-25 to STATUS In PCB1.PcbDoc Unknown Pin: Pin U2-25 Add U2-38 to DBG_RXD In PCB1.PcbDoc Unknown Pin: Pin U2-33 Add U2-38 to DBG_RXD In PCB1.PcbDoc Unknown Pin: Pin U2-38 Add U2-42 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-42 Add U2-43 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-42				
Add U2-13 to USIM_CKL In PCB1.PcbDoc Unknown Pin: Pin U2-13 Add U2-14 to USIM_VDD In PCB1.PcbDoc Unknown Pin: Pin U2-14 Add U2-16 to NET_STATUS In PCB1.PcbDoc Unknown Pin: Pin U2-16 Add U2-17 to MAIN_RXD In PCB1.PcbDoc Unknown Pin: Pin U2-17 Add U2-18 to MAIN_TXD In PCB1.PcbDoc Unknown Pin: Pin U2-18 Add U2-19 to MAIN_DTR In PCB1.PcbDoc Unknown Pin: Pin U2-19 Add U2-24 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U2-25 Add U2-25 to STATUS In PCB1.PcbDoc Unknown Pin: Pin U2-25 Add U2-35 to ANT_GSM In PCB1.PcbDoc Unknown Pin: Pin U2-25 Add U2-38 to DBG_RXD In PCB1.PcbDoc Unknown Pin: Pin U2-35 Add U2-39 to DBG_TXD In PCB1.PcbDoc Unknown Pin: Pin U2-38 Add U2-39 to DBG_TXD In PCB1.PcbDoc Unknown Pin: Pin U2-38 Add U2-39 to USAT In PCB1.PcbDoc Unknown Pin: Pin U2-38 Add U2-43 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-42				
Add U2-14 to USIM_VDD In PCB1.PcbDoc Unknown Pin: Pin U2-14 Add U2-16 to NET_STATUS In PCB1.PcbDoc Unknown Pin: Pin U2-16 Add U2-17 to MAIN_RXD In PCB1.PcbDoc Unknown Pin: Pin U2-17 Add U2-18 to MAIN_TXD In PCB1.PcbDoc Unknown Pin: Pin U2-18 Add U2-19 to MAIN_DTR In PCB1.PcbDoc Unknown Pin: Pin U2-19 Add U2-24 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U2-24 Add U2-25 to STATUS In PCB1.PcbDoc Unknown Pin: Pin U2-25 Add U2-35 to ANT_GSM In PCB1.PcbDoc Unknown Pin: Pin U2-35 Add U2-38 to DBG_RXD In PCB1.PcbDoc Unknown Pin: Pin U2-38 Add U2-39 to DBG_TXD In PCB1.PcbDoc Unknown Pin: Pin U2-39 Add U2-42 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-42 Add U2-43 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-43 Add U2-40 to USB_DM In PCB1.PcbDoc Unknown Pin: Pin U2-43 Add U2-50 to USB_DM In PCB1.PcbDoc Unknown Pin: Pin U2-61				
Add U2-16 to NET_STATUS In PCB1.PcbDoc Unknown Pin: Pin U2-16 Add U2-17 to MAIN_RXD In PCB1.PcbDoc Unknown Pin: Pin U2-17 Add U2-18 to MAIN_TXD In PCB1.PcbDoc Unknown Pin: Pin U2-18 Add U2-19 to MAIN_DTR In PCB1.PcbDoc Unknown Pin: Pin U2-19 Add U2-24 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U2-24 Add U2-25 to STATUS In PCB1.PcbDoc Unknown Pin: Pin U2-25 Add U2-35 to ANT_GSM In PCB1.PcbDoc Unknown Pin: Pin U2-35 Add U2-38 to DBG_RXD In PCB1.PcbDoc Unknown Pin: Pin U2-38 Add U2-39 to DBG_TXD In PCB1.PcbDoc Unknown Pin: Pin U2-39 Add U2-42 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-43 Add U2-43 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-43 Add U2-59 to USB_DM In PCB1.PcbDoc Unknown Pin: Pin U2-43 Add U2-60 to USB_DM In PCB1.PcbDoc Unknown Pin: Pin U2-60 Add U2-61 to USB_VBUS In PCB1.PcbDoc Unknown Pin: Pin U2-61				
Add U2-18 to MAIN_TXD In PCB1.PcbDoc Unknown Pin: Pin U2-18 Add U2-19 to MAIN_DTR In PCB1.PcbDoc Unknown Pin: Pin U2-19 Add U2-24 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U2-24 Add U2-25 to STATUS In PCB1.PcbDoc Unknown Pin: Pin U2-25 Add U2-35 to ANT_GSM In PCB1.PcbDoc Unknown Pin: Pin U2-35 Add U2-38 to DBG_RXD In PCB1.PcbDoc Unknown Pin: Pin U2-38 Add U2-39 to DBG_TXD In PCB1.PcbDoc Unknown Pin: Pin U2-39 Add U2-42 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-42 Add U2-43 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-43 Add U2-59 to USB_DP In PCB1.PcbDoc Unknown Pin: Pin U2-43 Add U2-60 to USB_DM In PCB1.PcbDoc Unknown Pin: Pin U2-60 Add U2-60 to USB_VBUS In PCB1.PcbDoc Unknown Pin: Pin U2-61 Add U2-79 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U2-79 Add U2-82 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U3-8 <t< td=""><td></td><td></td><td></td><td></td></t<>				
Add U2-19 to MAIN_DTR In PCB1.PcbDoc Unknown Pin: Pin U2-19 Add U2-24 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U2-24 Add U2-25 to STATUS In PCB1.PcbDoc Unknown Pin: Pin U2-25 Add U2-35 to ANT_GSM In PCB1.PcbDoc Unknown Pin: Pin U2-35 Add U2-38 to DBG_RXD In PCB1.PcbDoc Unknown Pin: Pin U2-38 Add U2-39 to DBG_TXD In PCB1.PcbDoc Unknown Pin: Pin U2-39 Add U2-42 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-42 Add U2-42 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-43 Add U2-59 to USB_DP In PCB1.PcbDoc Unknown Pin: Pin U2-43 Add U2-60 to USB_DM In PCB1.PcbDoc Unknown Pin: Pin U2-59 Add U2-61 to USB_VBUS In PCB1.PcbDoc Unknown Pin: Pin U2-60 Add U2-79 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U2-61 Add U2-79 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U2-82 Add U3-1 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U3-1 <t< td=""><td></td><td></td><td></td><td></td></t<>				
Add U2-24 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U2-24 Add U2-25 to STATUS In PCB1.PcbDoc Unknown Pin: Pin U2-25 Add U2-35 to ANT_GSM In PCB1.PcbDoc Unknown Pin: Pin U2-35 Add U2-38 to DBG_RXD In PCB1.PcbDoc Unknown Pin: Pin U2-38 Add U2-39 to DBG_TXD In PCB1.PcbDoc Unknown Pin: Pin U2-39 Add U2-42 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-42 Add U2-43 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-43 Add U2-59 to USB_DP In PCB1.PcbDoc Unknown Pin: Pin U2-59 Add U2-60 to USB_DM In PCB1.PcbDoc Unknown Pin: Pin U2-60 Add U2-61 to USB_VBUS In PCB1.PcbDoc Unknown Pin: Pin U2-61 Add U2-79 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U2-79 Add U2-82 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U3-62 Add U3-2 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U3-1 Add U3-2 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U3-3		_		
Add U2-25 to STATUS In PCB1.PcbDoc Unknown Pin: Pin U2-25 Add U2-35 to ANT_GSM In PCB1.PcbDoc Unknown Pin: Pin U2-35 Add U2-38 to DBG_RXD In PCB1.PcbDoc Unknown Pin: Pin U2-38 Add U2-39 to DBG_TXD In PCB1.PcbDoc Unknown Pin: Pin U2-39 Add U2-42 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-42 Add U2-43 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-43 Add U2-59 to USB_DP In PCB1.PcbDoc Unknown Pin: Pin U2-59 Add U2-60 to USB_DM In PCB1.PcbDoc Unknown Pin: Pin U2-60 Add U2-61 to USB_VBUS In PCB1.PcbDoc Unknown Pin: Pin U2-61 Add U2-79 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U2-79 Add U2-82 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U2-82 Add U3-1 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U3-1 Add U3-2 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U3-2 Add U3-3 to USIM_VDD In PCB1.PcbDoc Unknown Pin: Pin U3-3				
Add U2-35 to ANT_GSM In PCB1.PcbDoc Unknown Pin: Pin U2-35 Add U2-38 to DBG_RXD In PCB1.PcbDoc Unknown Pin: Pin U2-38 Add U2-39 to DBG_TXD In PCB1.PcbDoc Unknown Pin: Pin U2-39 Add U2-42 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-42 Add U2-43 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-43 Add U2-59 to USB_DP In PCB1.PcbDoc Unknown Pin: Pin U2-59 Add U2-60 to USB_DM In PCB1.PcbDoc Unknown Pin: Pin U2-60 Add U2-61 to USB_VBUS In PCB1.PcbDoc Unknown Pin: Pin U2-61 Add U2-79 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U2-79 Add U2-82 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U3-1 Add U3-1 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U3-2 Add U3-2 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U3-2 Add U3-3 to USIM_VDD In PCB1.PcbDoc Unknown Pin: Pin U3-3 Add U3-4 to NetC18_2 In PCB1.PcbDoc Unknown Pin: Pin U3-5				
Add U2-38 to DBG_RXD In PCB1.PcbDoc Unknown Pin: Pin U2-38 Add U2-39 to DBG_TXD In PCB1.PcbDoc Unknown Pin: Pin U2-39 Add U2-42 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-42 Add U2-43 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-43 Add U2-59 to USB_DP In PCB1.PcbDoc Unknown Pin: Pin U2-59 Add U2-60 to USB_DM In PCB1.PcbDoc Unknown Pin: Pin U2-60 Add U2-61 to USB_VBUS In PCB1.PcbDoc Unknown Pin: Pin U2-61 Add U2-79 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U2-79 Add U2-82 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U2-82 Add U3-1 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U3-1 Add U3-2 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U3-2 Add U3-3 to USIM_VDD In PCB1.PcbDoc Unknown Pin: Pin U3-3 Add U3-4 to NetC18_2 In PCB1.PcbDoc Unknown Pin: Pin U3-4 Add U3-5 to NetC17_2 In PCB1.PcbDoc Unknown Pin: Pin U3-5				
Add U2-39 to DBG_TXD In PCB1.PcbDoc Unknown Pin: Pin U2-39 Add U2-42 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-42 Add U2-43 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-43 Add U2-59 to USB_DP In PCB1.PcbDoc Unknown Pin: Pin U2-59 Add U2-60 to USB_DM In PCB1.PcbDoc Unknown Pin: Pin U2-60 Add U2-61 to USB_VBUS In PCB1.PcbDoc Unknown Pin: Pin U2-61 Add U2-79 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U2-79 Add U2-82 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U2-82 Add U3-1 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U3-1 Add U3-2 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U3-2 Add U3-3 to USIM_VDD In PCB1.PcbDoc Unknown Pin: Pin U3-3 Add U3-4 to NetC18_2 In PCB1.PcbDoc Unknown Pin: Pin U3-4 Add U3-5 to NetC17_2 In PCB1.PcbDoc Unknown Pin: Pin U3-5				
Add U2-42 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-42 Add U2-43 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-43 Add U2-59 to USB_DP In PCB1.PcbDoc Unknown Pin: Pin U2-59 Add U2-60 to USB_DM In PCB1.PcbDoc Unknown Pin: Pin U2-60 Add U2-61 to USB_VBUS In PCB1.PcbDoc Unknown Pin: Pin U2-61 Add U2-79 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U2-79 Add U2-82 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U2-82 Add U3-1 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U3-1 Add U3-2 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U3-2 Add U3-3 to USIM_VDD In PCB1.PcbDoc Unknown Pin: Pin U3-3 Add U3-4 to NetC18_2 In PCB1.PcbDoc Unknown Pin: Pin U3-4 Add U3-5 to NetC17_2 In PCB1.PcbDoc Unknown Pin: Pin U3-5	_			
Add U2-43 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U2-43 Add U2-59 to USB_DP In PCB1.PcbDoc Unknown Pin: Pin U2-59 Add U2-60 to USB_DM In PCB1.PcbDoc Unknown Pin: Pin U2-60 Add U2-61 to USB_VBUS In PCB1.PcbDoc Unknown Pin: Pin U2-61 Add U2-79 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U2-79 Add U2-82 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U2-82 Add U3-1 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U3-1 Add U3-2 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U3-2 Add U3-3 to USIM_VDD In PCB1.PcbDoc Unknown Pin: Pin U3-3 Add U3-4 to NetC18_2 In PCB1.PcbDoc Unknown Pin: Pin U3-4 Add U3-5 to NetC17_2 In PCB1.PcbDoc Unknown Pin: Pin U3-5		_		
Add U2-60 to USB_DM In PCB1.PcbDoc Unknown Pin: Pin U2-60 Add U2-61 to USB_VBUS In PCB1.PcbDoc Unknown Pin: Pin U2-61 Add U2-79 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U2-79 Add U2-82 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U2-82 Add U3-1 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U3-1 Add U3-2 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U3-2 Add U3-3 to USIM_VDD In PCB1.PcbDoc Unknown Pin: Pin U3-3 Add U3-4 to NetC18_2 In PCB1.PcbDoc Unknown Pin: Pin U3-4 Add U3-5 to NetC17_2 In PCB1.PcbDoc Unknown Pin: Pin U3-5		U2-43 to VBAT		
Add U2-61 to USB_VBUS In PCB1.PcbDoc Unknown Pin: Pin U2-61 Add U2-79 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U2-79 Add U2-82 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U2-82 Add U3-1 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U3-1 Add U3-2 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U3-2 Add U3-3 to USIM_VDD In PCB1.PcbDoc Unknown Pin: Pin U3-3 Add U3-4 to NetC18_2 In PCB1.PcbDoc Unknown Pin: Pin U3-4 Add U3-5 to NetC17_2 In PCB1.PcbDoc Unknown Pin: Pin U3-5	_			
Add U2-79 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U2-79 Add U2-82 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U2-82 Add U3-1 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U3-1 Add U3-2 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U3-2 Add U3-3 to USIM_VDD In PCB1.PcbDoc Unknown Pin: Pin U3-3 Add U3-4 to NetC18_2 In PCB1.PcbDoc Unknown Pin: Pin U3-4 Add U3-5 to NetC17_2 In PCB1.PcbDoc Unknown Pin: Pin U3-5				
Add U2-82 to VDD_EXT In PCB1.PcbDoc Unknown Pin: Pin U2-82 Add U3-1 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U3-1 Add U3-2 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U3-2 Add U3-3 to USIM_VDD In PCB1.PcbDoc Unknown Pin: Pin U3-3 Add U3-4 to NetC18_2 In PCB1.PcbDoc Unknown Pin: Pin U3-4 Add U3-5 to NetC17_2 In PCB1.PcbDoc Unknown Pin: Pin U3-5				
Add U3-1 to USIM_DET In PCB1.PcbDoc Unknown Pin: Pin U3-1 Add U3-2 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U3-2 Add U3-3 to USIM_VDD In PCB1.PcbDoc Unknown Pin: Pin U3-3 Add U3-4 to NetC18_2 In PCB1.PcbDoc Unknown Pin: Pin U3-4 Add U3-5 to NetC17_2 In PCB1.PcbDoc Unknown Pin: Pin U3-5				
Add U3-2 to VBAT In PCB1.PcbDoc Unknown Pin: Pin U3-2 Add U3-3 to USIM_VDD In PCB1.PcbDoc Unknown Pin: Pin U3-3 Add U3-4 to NetC18_2 In PCB1.PcbDoc Unknown Pin: Pin U3-4 Add U3-5 to NetC17_2 In PCB1.PcbDoc Unknown Pin: Pin U3-5				
Add U3-3 to USIM_VDD In PCB1.PcbDoc Unknown Pin: Pin U3-3 Add U3-4 to NetC18_2 In PCB1.PcbDoc Unknown Pin: Pin U3-4 Add U3-5 to NetC17_2 In PCB1.PcbDoc Unknown Pin: Pin U3-5				
Add U3-4 to NetC18_2 In PCB1.PcbDoc Unknown Pin: Pin U3-4 Add U3-5 to NetC17_2 In PCB1.PcbDoc Unknown Pin: Pin U3-5				
Add U3-5 to NetC17_2 In PCB1.PcbDoc Unknown Pin: Pin U3-5				

Action	i Object	Change Document	Status
Add P	ins To Nets		
Add	W1-1 to NetR18_1	In PCB1.PcbDoc	Unknown Pin: Pin W1-1
Add	W1-2 to VDD_EXT	In PCB1.PcbDoc	Unknown Pin: Pin W1-2

Action	Object	Change Document	Status
Add Co	omponent Class Members		
Add	B1 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	C1 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	C2 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add Add	C3 to EG800K C4 to EG800K	In PCB1.PcbDoc In PCB1.PcbDoc	Failed to add class member : Com Failed to add class member : Com
Add	C5 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	C6 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	C7 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	C8 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	C9 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	C10 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add Add	C11 to EG800K C12 to EG800K	In PCB1.PcbDoc In PCB1.PcbDoc	Failed to add class member : Com Failed to add class member : Com
Add	C13 to EG800K	In PCB1.FcbDoc	Failed to add class member : Com
Add	C14 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	C15 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	C16 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	C17 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	C18 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	C19 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add Add	C20 to EG800K C21 to EG800K	In PCB1.PcbDoc In PCB1.PcbDoc	Failed to add class member : Com Failed to add class member : Com
Add	C22 to EG800K	In PCB1. CbDoc	Failed to add class member : Com
Add	D1 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	D2 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	D3 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	D4 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	D5 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	D6 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add Add	D7 to EG800K D8 to EG800K	In PCB1.PcbDoc In PCB1.PcbDoc	Failed to add class member : Com Failed to add class member : Com
Add	D9 to EG800K	In PCB1. CbDoc	Failed to add class member : Com
Add	D10 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	F1 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	J1 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	J2 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	J3 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add Add	J4 to EG800K L1 to EG800K	In PCB1.PcbDoc In PCB1.PcbDoc	Failed to add class member : Com Failed to add class member : Com
Add	L2 to EG800K	In PCB1. CbDoc	Failed to add class member : Com
Add	P1 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	P2 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	P3 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	Q1 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	Q2 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add Add	Q3 to EG800K Q4 to EG800K	In PCB1.PcbDoc In PCB1.PcbDoc	Failed to add class member : Com Failed to add class member : Com
Add	R1 to EG800K	In PCB1. CbDoc	Failed to add class member : Com
Add	R2 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	R3 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	R4 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	R5 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	R6 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add Add	R7 to EG800K R8 to EG800K	In PCB1.PcbDoc In PCB1.PcbDoc	Failed to add class member : Com Failed to add class member : Com
Add	R9 to EG800K	In PCB1.PcbDoc	Failed to add class member: Com Failed to add class member: Com
Add	R10 to EG800K	In PCB1. CbDoc	Failed to add class member : Com
Add	R11 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	R12 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	R13 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	R14 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	R15 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	R16 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add Add	R17 to EG800K R18 to EG800K	In PCB1.PcbDoc In PCB1.PcbDoc	Failed to add class member : Com Failed to add class member : Com
Add	R19 to EG800K	In PCB1.PcbDoc	Failed to add class member: Com Failed to add class member: Com
	R20 to EG800K	In PCB1. CbDoc	Failed to add class member : Com
Add	NZU IU EGOUUN		
Add Add	R21 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com

Action	Object	Change Document	Status
Add Co	omponent Class Members		
Add	R23 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	U1 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	U2 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	U3 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com
Add	W1 to EG800K	In PCB1.PcbDoc	Failed to add class member : Com

Add Rooms			
Add	Room EG800K	To PCB1.PcbDoc	
	(Scope=InComponentClass('EG800K')) TopLayer		