








CANBUS TRANCEIVER



STB pin must be pulled to GND for normal operation.
VIO pin must be pulled to 3.3V

Sheet: /can transceiver/	
File: can_transceiver.kicad_sch	
Title: CANLink	
Size: A4	Date: 2025-02-07
KiCad E.D.A. 10.0.5	
Rev: R1	
Id: 3/3	