

第3章 Channel description and technical parameters

1. channel table

The detailed data of the channel are shown in Table 5 and can be viewed in the manual interface:

14 channels	Channel function	numeric value	Effect
1	X-axis	0-255	level control
2	X-axis fine adjustment	0-255	Horizontal Control Trim
3	Y axis	0-255	vertical control
4	Y axis fine adjustment	0-255	Vertical control fine-tuning
5	XY speed	0-255	from fast to slow
6	Dimming	0-255	Dimming (from dark to bright)
7	strobe	0-3	invalid
		4-99	Synchronous strobe
		100-149	pulse strobe
		150-199	Strobe
		200-249	random strobe
		250-255	Consecrate
		0-6	White
		7-11	color 1
8	color wheel	12-16	color 2
		17-21	color 3
		22-26	color 4
		27-31	color 5
		32-36	color 6
		37-41	color 7
		42-46	color 8
		47-51	color 9
		52-56	color 10
		57-61	color 11
		62-66	color 12
		67-71	color 13
		72-75	White light + color 1
		76-79	Color 1+Color 2
		80-83	Color 2 + Color 3

9	Solid figure	84-87	Color 3+Color 4
		88-91	Color 4+Color 5
		92-95	Color 5+Color 6
		96-99	Color 6+Color 7
		100-103	Color 7+Color 8
		104-107	Color 8+Color 9
		108-111	Color 9+Color 10
		112-115	Color 10+Color 11
		116-119	Color 11+Color 12
		120-123	Color 12+Color 13
		124-127	Color 13+ white light
		128-189	Water flows counterclockwise from fast to slow
		190-193	Stop flowing water
		194-255	Water flows clockwise from slow to fast
		0-2	white light hole
		3-6	Pattern 1
		7-10	Pattern 2
		11-14	pattern 3
		15-16	Pattern 4
		19-22	Pattern 5
		23-26	Pattern 6
		27-30	Pattern 7
		31-34	Pattern 8
		35-38	Pattern 9
		39-42	Pattern 10
		43-46	Pattern 11
		47-50	Pattern 12
		51-54	Pattern 13
		55-58	Pattern 14
		59-62	Pattern 15
		63-66	Pattern 16
		67-70	Pattern 17
		71-77	Pattern 1 jitters from slow to fast
		78-84	Pattern 2 jitters from slow to fast
		85-91	Pattern 3 jitters from slow to fast
		92-98	Pattern 4 jitters from slow to fast
		99-105	Pattern 5 shakes from slow to fast
		106-112	Pattern 6 shakes from slow to fast
		113-119	Pattern 7 shakes from slow to fast
		120-126	Pattern 8 shakes from slow to fast
		127-133	Pattern 9 shakes from slow to fast

		134-140	Pattern 10 shakes from slow to fast
		141-147	Pattern 11 shakes from slow to fast
		148-154	Pattern 12 shakes from slow to fast
		155-161	Pattern 13 shakes from slow to fast
		162-168	Pattern 14 shakes from slow to fast
		169-175	Pattern 15 shakes from slow to fast
		176-182	Pattern 16 shakes from slow to fast
		183-189	Pattern 17 shakes from slow to fast
		190-221	Flow counterclockwise from fast to slow
		222-223	Stop flowing water
	Colorful	224-255	Clockwise flow from slow to fast
		0-127	Colorful cut out
		128-255	colorful cut
10	prism	0-127	Prism cut out
11		128-255	Prism cut in
12	prism rotation	0-127	0-400 degrees
		128-190	Reverse flow from fast to slow
		191-192	stop
		193-255	Flowing water from slow to fast
13	focusing	0-255	0-100% from far to near
14	reset	0-199	invalid
		200-205	reset all
		206-255	invalid

Table 5

2. Technical parameters:

Voltage: AC100-240V, 50-60Hz

Light source: brand new 200W white LED module

Pattern: 17 patterns + white light with two-way flow, variable speed jitter effect

Color wheel: 13 colors + white light, two-way variable speed rainbow flow effect

Effect plate: colorful mirror effect

Prism: 8+16 prism can be rotated in two directions with variable speed

XY: magnetic coding precise positioning

Horizontal: 540 degrees + fine adjustment

Vertical: 270 degrees + fine adjustment

Beam Angle: 1.6 degrees

Channel: 14CH

Dimming: 0-100% linear dimming

Strobe: 1-25Hz, random pulse and various strobes

Waterproof grade: IP65

Lifespan: 50,000 hours, low power consumption, energy saving and environmental protection.

Screen: Chinese and English touch screen LCD display showing the current function of the lamp

第4章 Common faults and use attention

1. Common fault handling

Lamps contain microcomputer circuit board, high voltage power supply and other professional components, for your safety and product life, non-professionals do not remove lamps and related accessories without authorization.

1. Bulb is not light on (except for LED light source)

Possible reasons: The bulb is not fully cooled, or the bulb reaches its life, treated as follows:

- Due to abnormal operation, the bulb is not completely cooled, the light body should be cooled for more than 10 minutes, so that its internal completely restored to the normal state, and then start the power supply again;
- Check whether the light bulb has reached the service life, and replace it with a new light bulb;
- Check whether the bulb and the lamp lighting device circuit leakage, fall off or poor contact;
- Replace the new lamp lighter.

2. The beam looked dim

Possible reasons: bulb is used long or light path is not clean, as follows:

- Check whether the light bulb has reached the service life, and replace it with a new light bulb;
- Check whether the optical components or bulbs are clean, and whether there is dust accumulation on the bulbs and other optical components, and the bulbs and the components should be cleaned and maintained regularly.

3. The pattern projection is vague

- Check if the electronic focus channel values are appropriate for the current projection distance.

4. The light fixtures work intermittently

Possible reasons: The internal line enters the protection state and handles as follows:

- Check whether the fan is running normally or whether it is dirty, causing the temperature inside the lamp to rise;
- Check whether the internal temperature control switch is in a closed state;
- Check the bulb and replace the new bulb.

5. The control of the console is not accepted after the lamp is normally reset

Possible cause: signal line failure or lamp parameter set abnormal, handled as follows:

- Check the starting address code and the connection of DMX signal line (whether the signal cable is intact and whether the Alcock head connection is loose);
- Add a signal amplifier, add 120 ohm terminal resistance;

6. The lamps cannot be started

Possible reasons: Poor power line, handled as follows:

- Check whether the insurance on the power input socket is fused and replace the insurance;
- Poor line contact of lamp travel due to vibration in long-distance transportation
- Check the input power supply, computer board and other connecting devices.

2. Precautions for use

- Check whether the local power supply meets the rated voltage requirements of the product, leakage protector, overcurrent protector and meet the load requirements;
- Do not use damaged power cord with insulation and do not attach power cord to other wires;