



DJI Osmo Pocket 4P Release Notes

Date:	2026.09.03
Firmware Version:	v01.01.71.31
DJI Mimo App iOS:	v2.11.8
DJI Mimo App Android:	v2.11.8
Osmo FrameTap:	v01.02.08.02

What's New

- Added Camera Cloud Service, supporting uploading camera files to cloud storage. The supported cloud services vary depending on country/region and mobile device type. Currently supported services include Google Drive, OneDrive, and the user's own NAS. Supported services may be adjusted in future updates.
- Added joystick support for 45° diagonal gimbal movement.
- Updated the D-Log to Rec.709 and D-Log to Rec.709 vivid LUT files to v2.0, improving the accuracy and consistency of color reproduction.
- Added a D-Log 10-bit color mode for slow motion. It is recommended to use with the updated v2.0 LUT files.
- Optimized the interaction experience and image quality in certain scenarios.
- Fixed some known issues.

Notes:

1. If the update fails, follow the steps for troubleshooting.
 - a. Restart Osmo Pocket 4P and DJI Mimo.
 - b. Enable Wi-Fi and Bluetooth on the mobile device.
 - c. Connect Osmo Pocket 4P to DJI Mimo and try the update again.Contact DJI Support if the update fails again.
2. Accessory updates:
 - a. Once connected to the camera, the battery handle and fill light will be updated together with the camera firmware. A prompt will appear on the camera screen when the update is complete. Do not remove the accessories until the update completes.
 - b. Connect Osmo FrameTap remote controller to DJI Mimo to update its firmware. The remote controller does not support simultaneous connections to a mobile device and Osmo Pocket 4P. Disconnect Osmo Pocket 4P before updating.
3. When using with DJI Mic series, make sure the transmitter is updated to the latest compatible version:
 - DJI Mic Mini 2 Transmitter: v02.03.17.00 or above
 - DJI Mic 3 Transmitter: v02.00.11.01 or above
 - DJI Mic Mini Transmitter: v01.01.00.56 or above
 - DJI Mic 2 Transmitter: v04.05.01.11 or above



DJI Osmo Pocket 4P Release Notes

Date:	2026.07.30
Firmware Version:	v01.01.65.13
DJI Mimo App iOS:	v2.10.12
DJI Mimo App Android:	v2.10.12
Osmo FrameTap:	v01.02.08.02

What's New

- Added support for HDR Enhancement in Photo mode. Play back footage on a device that supports high dynamic range display for the best viewing experience.
- Fixed some known issues.

Notes:

1. If the update fails, follow the steps for troubleshooting.
 - a. Restart Osmo Pocket 4P and DJI Mimo.
 - b. Enable Wi-Fi and Bluetooth on the mobile device.
 - c. Connect Osmo Pocket 4P to DJI Mimo and try the update again.
Contact DJI Support if the update fails again.
2. Accessory updates:
 - a. Once connected to the camera, the battery handle and fill light will be updated together with the camera firmware. A prompt will appear on the camera screen when the update is complete. Do not remove the accessories until the update completes.
 - b. Connect Osmo FrameTap remote controller to DJI Mimo to update its firmware. The remote controller does not support simultaneous connections to a mobile device and Osmo Pocket 4P. Disconnect Osmo Pocket 4P before updating.
3. When using with DJI Mic series, make sure the transmitter is updated to the latest compatible version:
DJI Mic Mini 2 Transmitter: v02.03.17.00 or above
DJI Mic 3 Transmitter: v02.00.11.01 or above
DJI Mic Mini Transmitter: v01.01.00.56 or above
DJI Mic 2 Transmitter: v04.05.01.11 or above

DJI Osmo Pocket 4P Release Notes

Date:	2026.07.16
Firmware Version:	v01.01.58.03
DJI Mimo App iOS:	v2.10.10
DJI Mimo App Android:	v2.10.9
Osmo FrameTap:	v01.02.08.02

What's New

- Added support for Auto Media Transfer on iOS. Newly captured files can be automatically transferred to your mobile device after the camera powers off. For a more stable experience, it is recommended to pair the camera with an iPhone 16 series (or later) device running iOS 26.4.1 or later, and to ensure the camera battery is above 15%.
- Added HDR 10-bit color mode, supporting 10-bit high dynamic range video capture. Play back footage on a device that supports high dynamic range display for the best viewing experience.
- Added support for automatic brightness and color temperature adjustment for the fill light. When enabled, brightness and color temperature automatically adapt to the current scene without frequent manual adjustments.
- Fixed some known issues.

Notes:

1. If the update fails, follow the steps for troubleshooting.
 - a. Restart Osmo Pocket 4P and DJI Mimo.
 - b. Enable Wi-Fi and Bluetooth on the mobile device.
 - c. Connect Osmo Pocket 4P to DJI Mimo and try the update again.
Contact DJI Support if the update fails again.
2. Accessory updates:
 - a. Once connected to the camera, the battery handle and fill light will be updated together with the camera firmware. A prompt will appear on the camera screen when the update is complete. Do not remove the accessories until the update completes.
 - b. Connect Osmo FrameTap remote controller to DJI Mimo to update its firmware. The remote controller does not support simultaneous connections to a mobile device and Osmo Pocket 4P. Disconnect Osmo Pocket 4P before updating.
3. When using with DJI Mic series, make sure the transmitter is updated to the latest compatible version:
 - DJI Mic Mini 2 Transmitter: v02.03.17.00 or above
 - DJI Mic 3 Transmitter: v02.00.11.01 or above
 - DJI Mic Mini Transmitter: v01.01.00.56 or above
 - DJI Mic 2 Transmitter: v04.05.01.11 or above



DJI Osmo Pocket 4P Release Notes

Date:	2026.06.29
Firmware Version:	v01.01.09.05
DJI Mimo App iOS:	v2.10.2
DJI Mimo App Android:	v2.10.2
Osmo FrameTap:	v01.02.08.02

What's New

- Added support for Frame Tracking. The camera automatically matches and selects an ActiveTrack subject. When the subject frame turns yellow, press the joystick once to start tracking while maintaining the current composition.
- Added Multi-Person Tracking to Smart Gimbal Mode. When enabled, the camera automatically matches and tracks the primary subject and nearby subjects. During tracking, the composition adjusts in real time to maintain tracking even when subjects enter or leave the frame.
- Added support to set the Press & Hold Joystick function to Lock Gimbal or Lock Camera Direction in system settings. When Lock Gimbal is selected, the gimbal responds more naturally to hand movements.
- Press and hold the Zoom Button or Custom Button to continuously zoom in at a constant speed.
- Moved frequently used operations to the front in system settings.
- Improved image quality in certain scenarios.
- Fixed some known issues.

Notes:

1. If the update fails, follow the steps for troubleshooting.
 - a. Restart Osmo Pocket 4P and DJI Mimo.
 - b. Enable Wi-Fi and Bluetooth on the mobile device.
 - c. Connect Osmo Pocket 4P to DJI Mimo and try the update again.Contact DJI Support if the update fails again.
2. Connect Osmo FrameTap remote controller to DJI Mimo to update its firmware. The remote controller does not support simultaneous connections to a mobile device and Osmo Pocket 4P. Disconnect Osmo Pocket 4P before updating.
3. When using with DJI Mic series, make sure the transmitter is updated to the latest compatible version:
 - DJI Mic Mini 2 Transmitter: v02.03.17.00 or above
 - DJI Mic 3 Transmitter: v02.00.11.01 or above
 - DJI Mic Mini Transmitter: v01.01.00.56 or above
 - DJI Mic 2 Transmitter: v04.05.01.11 or above