



Description

Image





Caption

1. Close-up of the material along the grain. © Granta Design 2. Pine table.

The material

Softwoods come from coniferous, mostly evergreen, trees such as spruce, pine, fir and redwood. Wood must be seasoned before it is used. Seasoning is the process of drying the natural moisture out of the raw timber to make it dimensionally stable, allowing its use without shrinking or warping. In air-seasoning the wood is dried naturally in covered but open-sided structure. In kiln-drying the wood is artificially dried in an oven or kiln. Modern kilns are so designed that an accurate control of moisture is achieved. Wood has been used for construction and to make products since the earliest recorded time. The ancient Egyptians used it for furniture, sculpture and coffins before 2500 BC. The Greeks at the peak of their empire (700 BC) and the Romans at the peak of theirs (around 0 AD) made elaborate buildings, bridges, boats, chariots and weapons of wood, and established the craft of furniture making that is still with us today. More diversity of use appeared in Mediaeval times, with the use of wood for large-scale building, and mechanisms such as pumps, windmills, even clocks, so that, right up to end of the 17th century, wood was the principal material of engineering. Since then cast iron, steel and concrete have displaced it in some of its uses, but timber continues to be used on a massive scale, particularly in housing and small commercial buildings.

27.5

37.5

lb/ft^3

Composition (summary)

Cellulose/Hemicellulose/Lignin/12%H2O

General properties

Density

Donony			00	10/11
Price	* 0.304	-	0.608	USD/lb
Date first used	-10000			
Mechanical properties				
Young's modulus	1.22	-	1.49	10^6 psi
Shear modulus	* 0.0899	-	0.11	10^6 psi
Bulk modulus	0.0537	-	0.0595	10^6 psi
Poisson's ratio	* 0.35	-	0.4	
Yield strength (elastic limit)	* 5.08	-	6.53	ksi
Tensile strength	* 8.7	-	14.5	ksi
Compressive strength	* 5.08	-	6.24	ksi
Elongation	* 1.99	-	2.43	% strain
Hardness - Vickers	* 3	-	4	HV
Fatigue strength at 10^7 cycles	* 2.76	-	3.34	ksi
Fracture toughness	* 3.09	-	3.73	ksi.in^0.5
Mechanical loss coefficient (tan delta)	* 0.007	-	0.01	



Softwood: pine, along grain

Ibormal	nror	ACCHICC
Thermal		
	\sim \sim \sim	, 01 1100

Glass temperature	171	-	216	°F
Maximum service temperature	248	-	284	°F
Minimum service temperature	* -148	-	-94	°F

Thermal conductor or insulator? Good insulator

Thermal conductivity * 0.127 - 0.173 BTU.ft/h.ft^2.F Specific heat capacity 0.396 - 0.408 BTU/lb. $^{\circ}$ F Thermal expansion coefficient * 1.39 - 5 μ strain/ $^{\circ}$ F

Electrical properties

Electrical conductor or insulator?	Poor insulator	
Electrical resistivity	* 6e13 - 2e14	µohm.cm
Dielectric constant (relative permittivity)	* 5 - 6.2	
Dissipation factor (dielectric loss tangent)	* 0.05 - 0.1	
Dielectric strength (dielectric breakdown)	* 10.2 - 15.2	V/mil

Optical properties

Opaque
Opa

Processability

Moldability	2	-	3
Machinability	5		

Durability: water and aqueous solutions

Water (fresh)	Acceptable
Water (salt)	Acceptable
Soils, acidic (peat)	Acceptable
Soils, alkaline (clay)	Limited use
Wine	Acceptable

Durability: acids

,	
Acetic acid (10%)	Acceptable
Acetic acid (glacial)	Limited use
Citric acid (10%)	Acceptable
Hydrochloric acid (10%)	Excellent
Hydrochloric acid (36%)	Unacceptable
Hydrofluoric acid (40%)	Unacceptable
Nitric acid (10%)	Acceptable
Nitric acid (70%)	Unacceptable
Phosphoric acid (10%)	Acceptable
Phosphoric acid (85%)	Unacceptable
Sulfuric acid (10%)	Acceptable
Sulfuric acid (70%)	Unacceptable

Durability: alkalis

Sodium hydroxide (10%)	Unacceptable
Sodium hydroxide (60%)	Unacceptable

Durability: fuels, oils and solvents

Amyl acetate	Limited use
Benzene	Limited use
Carbon tetrachloride	Limited use
Chloroform	Limited use
Crude oil	Limited use
Diesel oil	Acceptable



Softwood: pine, along grain

Lubricating oil	Acceptable
Paraffin oil (kerosene)	Acceptable
Petrol (gasoline)	Acceptable
Silicone fluids	Acceptable
Toluene	Acceptable
Turpentine	Acceptable
Vegetable oils (general)	Acceptable
White spirit	Acceptable

Durability: alcohols, aldehydes, ketones

Acetaldehyde	Acceptable
Acetone	Limited use
Ethyl alcohol (ethanol)	Acceptable
Ethylene glycol	Acceptable
Formaldehyde (40%)	Acceptable
Glycerol	Acceptable
Methyl alcohol (methanol)	Acceptable

Durability: halogens and gases

Unacceptable
Unacceptable
Unacceptable
Limited use

Durability: built environments

Industrial atmosphere	Limited use
Rural atmosphere	Acceptable
Marine atmosphere	Acceptable
UV radiation (sunlight)	Good

Durability: flammability

Flammability Highly flammable

Durability: thermal environments

Tolerance to cryogenic temperatures	Acceptable
Tolerance up to 150 C (302 F)	Acceptable
Tolerance up to 250 C (482 F)	Unacceptable
Tolerance up to 450 C (842 F)	Unacceptable
Tolerance up to 850 C (1562 F)	Unacceptable
Tolerance above 850 C (1562 F)	Unacceptable

Geo-economic data for principal component

Annual world production	9.45e8	-	9.55e8	ton/yr
-------------------------	--------	---	--------	--------

Primary material production: energy, CO2 and water

Embodied energy, primary production	* 950	-	1.05e3	kcal/lb
CO2 footprint, primary production	* 0.358	-	0.396	lb/lb
Water usage	* 79.7	-	88.1	gal(US)/lb
Eco-indicator 95	6.6			millipoints/kg
Eco-indicator 99	41.6			millipoints/kg

Material processing: energy

Coarse machining energy (per unit wt removed)	* 133	-	147	kcal/lb
Fine machining energy (per unit wt removed)	* 871	-	962	kcal/lb
Grinding energy (per unit wt removed)	* 1.69e3	-	1.86e3	kcal/lb



Softwood: pine, along grain

Material processing: CO2 footprint

Coarse machining CO2 (per unit wt removed)	* 0.0923	-	0.102	lb/lb
Fine machining CO2 (per unit wt removed)	* 0.603	-	0.666	lb/lb
Grinding CO2 (per unit wt removed)	* 1.17	-	1.29	lb/lb

Material recycling: energy, CO2 and recycle fraction

Recycle	X			
Recycle fraction in current supply	8	-	10	%
Downcycle	✓			
Combust for energy recovery	✓			
Heat of combustion (net)	* 2.24e3	-	2.4e3	kcal/lb
Combustion CO2	* 1.76	-	1.85	lb/lb
Landfill	✓			
Biodegrade	✓			
Toxicity rating	Non-toxio	2		
A renewable resource?	✓			

Environmental notes

Wood is a renewable resource, absorbing CO2 as it grows. Present day consumption for engineering purposes can readily be met by controlled planting and harvesting, making wood a truly sustainable material.

Supporting information

Design guidelines

Wood offers a remarkable combination of properties. It is light, and, parallel to the grain, it is stiff, strong and tough - as good, per unit weight, as any man-made material except CFRP. It is cheap, it is renewable, and the fossil-fuel energy needed to cultivate and harvest it is outweighed by the energy it captures from the sun during growth. It is easily machined, carved and joined, and - when laminated - it can be molded to complex shapes. And it is aesthetically pleasing, warm both in color and feel, and with associations of craftsmanship and quality.

Technical notes

The values for the mechanical properties given for woods require explanation. Wood-science laboratories measure the mean properties of high-quality "clear" wood samples: small specimens with no knots or other defects; the data for woods in the Level 3 CES database is of this type. This is not, however, the data needed for design. All engineering materials have some variability in quality and properties. To allow for this design handbooks list "allowables" - property values that will be met or exceeded by, say, 99% of all samples (meaning the mean value minus 2.33 standard deviations). Natural materials like wood show greater variability than man-made materials like steel, with the result that the allowable values for mechanical properties may be only 50% of the mean. There is a second problem: structures made of wood are much larger than the wood-science test samples. They contain knots, shakes and sloping grain, all of which degrade properties. To deal with this the wood is "stress-graded" by visual inspection or by automated methods, assigning each piece a stress grading G between 0 and 100: a grading of G means that properties are further knocked down by the factor G/100. Finally, in building construction, there is the usual requirement of sound practice - an overall safety factor, typically 2.25. The result is that the permitted stress for design may be as low as 20% of the value quoted in wood-science tabulations. The data in this record is for Scots pine of medium density, and lists wood-science ranges for the properties of clear wood samples.

Wood prices are quoted in Board Feet (BF). 1 BF is 144 cubic inches. Here we list prices in the usual \$/kg.

Typical uses

Flooring; furniture; containers; cooperage; sleepers (when treated); building construction; boxes; crates and palettes; planing-mill products; sub-flooring; sheathing and as the feedstock for plywood, particleboard and hardboard.

Links

Reference

ProcessUniverse

Producers



