


Basic I/O - Digital Writes

Digital Write






Digital Pins

- General Purpose I/O Pin are 2, 3, 4, 5, 6, 7,8, 9, 10, 11, 12, & 13
- Analog I/O can also be used as digital pings; analog input A0 as digital pin 14 through analog input A5 as digital pin 19



Digital Pins

- Pin 13 has a built-in LED connected to it
- When the pin is HIGH value, the LED is on, when the pin is LOW value, it's off



Digital Write – Key Concepts

pinMode(): Configures the specified pin to behave either as an input or an output

- Syntax: pinMode(pin, mode)
- Example: pinMode(13, OUTPUT) set pin 13 to output mode
- Example: pinMode(13, INPUT) set pin 13 to input mode

digitalWrite(): Write a HIGH or a LOW value to a digital pin

- If set to OUTPUT with pinMode(), 5V (or 3.3V on 3.3V boards) for HIGH,
 OV (ground) for LOW.
- Syntax: pinWrite(pin, value)
- Example 1: digitalWrite(13, HIGH) is 5 volts to pin 13
- Example 2: digitalWrite(13, LOW) is 0 volts to pin 13





Digital Write – Blink LED



Project Name: Blink LED (Instructor Lead)

Objective: Turns LED on for one second, then off for one second, repeatedly

Software Elements

- pinMode()
- digitalWrite()
- delay()


Components


- Intel Galileo Board (Qty 1)
- Breadboard (QTY1)
- Jumper Wires
- 5mm LED (Qty 1)
- 220 Ohm Resister (Qty1)



Breadboard Layout

Connected dots represent connectivity








Digital Write – Blink LED



```
Blink
 Turns on an LED on for one second, then off for one second, repeatedly.
 This example code is in the public domain.
 */
// Pin 13 has an LED connected on most Arduino boards.
// give it a name:
int led = 13;
// the setup routine runs once when you press reset:
void setup() {
 // initialize the digital pin as an output.
 pinMode(led, OUTPUT);
// the loop routine runs over and over again forever:
void loop() {
 digitalWrite(led, HIGH); // turn the LED on (HIGH is the voltage level)
 delay(1000);
                     // wait for a second
 digitalWrite(led, LOW); // turn the LED off by making the voltage LOW
 delay(1000);
                     // wait for a second
```




fritzing

^{*} Other names and brands may be claimed as the property of others



Saving a Sketch

To Save Sketch, Use "File" -> "Save" or "Save As..."
 Be careful not to over write Sketches you want to keep



Digital Write - Engineering Challenge



Using your own circuit design and Arduino sketch, design a solution that solves the following challenges.

Use previous Lab example as needed for reference

Challenge 1a: Add a Second LED to the circuit and make them Blink together. 1b: Then make them Blink alternating on and off.


Challenge 2: Add a Third LED to circuit and make them Blink in series and then repeat.



Challenge 1a: Add a Second LED to the circuit and make them Blink together



```
Blink two LEDs together
 Created by Matt Royer May 5, 2014
// Pin 13 has an LED connected on most Arduino boards.
// give it a name:
int led1 = 13;
int led2 = 12; // Additional LED Pin
// the setup routine runs once when you press reset:
void setup() {
 // initialize the digital pin as an output.
 pinMode(led1, OUTPUT);
 pinMode(led2, OUTPUT); // Additional LED Pinmode
// the loop routine runs over and over again forever:
void loop() {
 digitalWrite(led1, HIGH); // turn the LED on (HIGH is the voltage level)
 digitalWrite(led2, HIGH); // turn the LED on (HIGH is the voltage level)
 delay(1000);
                      // wait for a second
 digitalWrite(led1, LOW); // turn the LED off by making the voltage LOW
 digitalWrite(led2, LOW); // turn the LED off by making the voltage LOW
 delay(1000);
                     // wait for a second
```



111121111

^{*} Other names and brands may be claimed as the property of others






Challenge 1b: Make them Blink Alternating on and off.



```
Blink two LEDs together
 Modified by Matt Royer May 5, 2014
// Pin 13 has an LED connected on most Arduino boards.
// give it a name:
int led1 = 13;
int led2 = 12; // Additional LED Pin
// the setup routine runs once when you press reset:
void setup() {
// initialize the digital pin as an output.
 pinMode(led1, OUTPUT);
 pinMode(led2, OUTPUT); // Additional LED Pinmode
// the loop routine runs over and over again forever:
void loop() {
 digitalWrite(led1, HIGH); // turn the LED on (HIGH is the voltage level)
 digitalWrite(led2, LOW); // turn the LED on (HIGH is the voltage level)
                     // wait for a second
 delay(1000);
 digitalWrite(led1, LOW); // turn the LED off by making the voltage LOW
 digitalWrite(led2, HIGH); // turn the LED off by making the voltage LOW
                     // wait for a second
 delay(1000);
```




* Other names and brands may be claimed as the property of others







```
Blink
 Cycle through Array list of LEDs. For each LED in Array turns it on for 1 second.
 Modified by Matt Royer May 5, 2014
const int numberOfLED = 3; // Number of LED in Array
const int lEDToBlink[numberOfLED] = { // Array to store LED Pins
 13,
 12,
 11
};
// the setup routine runs once when you press reset:
void setup() {
// initialize the digital pin as an output
// For each LED in Array, initialize
 for (int initalizeLED = 0; initalizeLED < numberOfLED; initalizeLED++){</pre>
  pinMode(lEDToBlink[initalizeLED], OUTPUT);
// the loop routine runs over and over again forever:
void loop() {
 for (int lightLED = 0; lightLED < numberOfLED; lightLED++){ // For each LED in Array, Blink
  digitalWrite(IEDToBlink[lightLED], HIGH); // turn the LED on (HIGH is the voltage level)
  delay(1000);
  digitalWrite(IEDToBlink[lightLED], LOW); // turn the LED on (HIGH is the voltage level)
                          Project Files - USB Drive:\Lessons\Lesson2-BasicIO\Section1-DigitalWrite\Blink3Serially
```




* Other names and brands may be claimed as the property of others



fritzing

Basic I/O - Digital Reads

Digital Read





Digital Read – Key Concepts

Reminder pinMode(): Configures the specified pin to behave either as an input or an output

- Syntax: pinMode(pin, mode)
- Example: pinMode(2, OUTPUT) set pin 2 to output mode
- Example: pinMode(2, INPUT) set pin 2 to input mode

digitalRead(): Reads the value from a specified digital pin, either HIGH or LOW

- Syntax: pinMode(pin)
- Example 1: digitalRead(2) reads High or Low from pin 2





Digital Read – LED Button Press



Project Name: LED Button Press(Instructor Lead)

Objective: Illuminate LED when button is pressed

Software Elements

- pinMode()
- digitalWrite()
- digitalRead()
- if / else

Components


- Intel Galileo Board (Qty 1)
- Breadboard (QTY1)
- Jumper Wires
- 5mm LED (Qty 1)
- Momentary Switch (Qty 1)
- 220 Ohm Resister (Qty1)
- 10k Ohm Resister (Qty1)



Digital Write – LED Button Press



```
// constants won't change. They're used here to
// set pin numbers:
const int buttonPin = 2; // the number of the pushbutton pin
const int ledPin = 13; // the number of the LED pin
// variables will change:
int buttonState = 0;
                        // variable for reading the pushbutton status
void setup() {
 // initialize the LED pin as an output:
 pinMode(ledPin, OUTPUT);
 // initialize the pushbutton pin as an input:
 pinMode(buttonPin, INPUT);
void loop(){
 // read the state of the pushbutton value:
 buttonState = digitalRead(buttonPin);
 // check if the pushbutton is pressed.
 // if it is, the buttonState is HIGH:
 if (buttonState == HIGH) {
  // turn LED on:
  digitalWrite(ledPin, HIGH);
 } else {
  // turn LED off:
  digitalWrite(ledPin, LOW);
```



fritzing

^{*} Other names and brands may be claimed as the property of others



Digital Write - Engineering Challenge



Using your own circuit design and Arduino sketch, design a solution that solves the following challenges.


Use previous Lab example as needed for reference

Challenge 1: Blink LED continuously while button is pressed



hallense Review Challenge 1: Blink LED continuously while button is pressed.

```
// constants won't change. They're used here to
// set pin numbers:
const int buttonPin = 2; // the number of the pushbutton pin
const int ledPin = 13; // the number of the LED pin
// variables will change:
                        // variable for reading the pushbutton status
int buttonState = 0:
void setup() {
// initialize the LED pin as an output:
 pinMode(ledPin, OUTPUT);
 // initialize the pushbutton pin as an input:
 pinMode(buttonPin, INPUT);
\oid loop(){
// read the state of the pushbutton value:
 buttonState = digitalRead(buttonPin);
 // check if the pushbutton is pressed.
 // if it is, the buttonState is HIGH:
 if (buttonState == HIGH) {
  digitalWrite(ledPin, HIGH);
  delay(500);
  digitalWrite(ledPin, LOW);
  delay(500);
 digitalWrite(ledPin, LOW);
```



fritzing

^{*} Other names and brands may be claimed as the property of others



21

Basic I/O - Serial Writes

Refresher: Galileo Serial Interfaces

- Used for communication between the Arduino board and a computer or other devices.
- Arduino platforms have at least one serial port (also known as a UART or Universal Asynchronous Receiver/Transmitter)
- Serial Communicates through digital pins 0 (RX) & 1 (TX) and via USB to Computer for Sketches
- Serial Communicates through UART for Linux Console

Supported baud rates: 300, 600, 1200, 2400, 4800, 9600, 14400, 19200, 28800, 38400, 57600, or 115200.



Serial Write – Key Concepts

Serial.begin(): Sets the data rate in bits per second (baud) for serial data transmission

- Syntax: Serial.begin(baud)
- Example: Serial.begin(9600) sets serial baud rate to 9600 bits per second

Serial.print(): Prints data to the serial port as human-readable ASCII text without carriage return / Newline Feed character

- Syntax: Serial.print(val) or Serial.print(val, format)
- Parameters:
 - val: the value to print any data type
 - format: specifies the number base or number of decimal places
- Example: Serial.print("Hello world.") gives "Hello world."
- Example: Serial.print(1.23456, 2) gives "1.23"



Serial Write – Key Concepts

Serial.println(): Prints data to the serial port as human-readable ASCII text *followed by a carriage return and a newline character*

- Syntax: Serial.println(val) or Serial.print(val, format)
- Parameters:
 - val: the value to print any data type
 - format: specifies the number base or number of decimal places
- Example: Serial.println("Hello world.") gives "Hello world."
- Example: Serial.println(1.23456, 2) gives "1.23"

Serial.write(): Writes binary data to the serial port. This data is sent as a byte or series of bytes


- Syntax: Serial.write(val)
- Example: Serial.wrtie("Hello world") writes "Hello world"




Bring up Serial Monitor

Select "Tools" -> "Serial Monitor" or click Serial Monitor Icon

Note: Sketch must be loaded first; else, Serial Monitor will close on Sketch upload







Serial Write – Printing to Serial Monito

Project Name: Printing to Serial Monitor (Instructor Lead)

Objective: Demonstrate different means to print to Serial monitoring

Software Elements

- Serial.Begin()
- Serial.print()
- Serial.println()
- concat()
- delay()


Components


Intel Galileo Board (Qty 1)



Serial Write – Printing to Serial Monito

Source Code: Lesson2-BasicIO\Section3-SerialWrite\SerialExample





* Other names and brands may be claimed as the property of others



Serial Write - Engineering Challenge



Using your own circuit design and Arduino sketch, design a solution that solves the following challenges.

Use previous Lab example as needed for reference

Challenge 1: Store your Name in a variable and write it to serial interface

Challenge 2: Write every number from 0-100 to Serial interface



Challenge 1: Store your Name in a variable and write it to serial interface



```
COM7
 Store your Name in a variable and write it to serial interface
                                                                                                         Matt Rover
 Created by Matt Royer
String myName = "Matt Royer";
// the setup routine runs once when you press reset:
void setup() {
// initialize the Serial Interface
 Serial.begin(9600):
// the loop routine runs over and over again forever:
void loop() {
                                                                                                                                  No line ending 😛 9600 baud
 Serial.println(myName);
 delay(2000);
```

fritzing * Other names and brands may be claimed as the property of others


Project Files - USB Drive:\Lessons\Lesson2-BasicIO\Section3-SerialWrite\SerialName



Challenge 2: Write every number from 0-100 to Serial interface



```
Write every number from 0-100 to Serial interface
 Created by Matt Royer
int maxNum = 100;
// the setup routine runs once when you press reset:
void setup() {
// initialize the Serial Interface
 Serial.begin(9600):
// the loop routine runs over and over again forever:
void loop() {
 Serial.println("-----");
for (int numIndex = 0; numIndex <= maxNum; numIndex++){</pre>
  Serial.println(numIndex);
 Serial.println("-----");
 delay(10000);
```




* Other names and brands may be claimed as the property of others





Using Alternative Terminals

- Although nicely integrated into Arduino IDE, you are not required to use the integrated Serial Monitor.
- Use any Terminal connecting to the proper COM port at the correct baud rate
- Simultaneous use (multiple sessions to COM port), not viable



Arduino Serial Monitor

```
Total of 3 + 4 = 7
-----
Example 1 - Print Char on 1 line
Hello World
-----
Example 2 - Print multiple on 1 line
Hello World
-----
Example 3 - Print Each Character on new line
H
e
1
1
0

W
o
r
1
d
d
-----
Example 4 - Combine String and Print on Single Line
Total of 3 + 4 = 7
```

PuTTY



Basic I/O - Serial Reads

Serial Read – Key Concepts

Reminder Serial.begin(): Sets the data rate in bits per second (baud) for serial data transmission

- Syntax: Serial.begin(baud)
- Example: Serial.begin(9600) sets serial baud rate to 9600 bits per second

Serial.availible(): Get the number of bytes that have already arrived and been stored in the serial receive buffer (which holds 64 bytes).

Syntax: Serial.availible()

Serial.read(): Reads incoming serial data. Removes data from serial buffer

Syntax: Serial.read()



Serial Read – Read Input



Project Name: Read Input (Instructor Lead)

Objective: Read input from Serial Monitor input and write it back out

Software Elements

- Serial.begin()
- Serial.availible()
- Serial.read()
- Serial.print()
- Serial.write()
- Serial.println()

Components

Intel Galileo Board (Qty 1)




Serial Read - Read Input



```
/* Simple Serial ECHO script : Written by ScottC 03/07/2012 */
/* Use a variable called byteRead to temporarily store
    the data coming from the computer */
byte incomingByte;

void setup() {
    // Turn the Serial Protocol ON
    Serial.begin(9600);
}

void loop() {
    /* check if data has been sent from the computer: */
    if (Serial.available()) {
        /* read the most recent byte */
        incomingByte = Serial.read();
        /*ECHO the value that was read, back to the serial port. */
        Serial.write(incomingByte);
    }
}
```



* Other names and brands may be claimed as the property of others

Project Files - USB Drive:\Lessons\Lesson2-BasicIO\Section4-SerialRead\SerialReadWrite




Serial Read-Read Entire Buffer



```
Read entire input from Serial Monitor input buffer, then write it back out
                                                                                                                                                     _ _
                                                                                                                                    COM7
 Create by Matt Royer
                                                                                                               Hello World
                                                                                                               Hello World
char character;
String content = "";
void setup() {
 Serial.begin(9600); // opens serial port, sets data rate to 9600 bps
void loop() {
 while(Serial.available()) {
  character = Serial.read();
  content.concat(character); //Concatenate to existing string
                                                                                                               Autoscroll
                                                                                                                                         No line ending 😛 9600 baud
                                                                              *****
                                                                                                                     DESIGNED
IN IRELAND
 if (content != "") {
  Serial.println(content); //Print string to serial
  content = ""; //Empty string
                                                                                                                                    fritzing
```

* Other names and brands may be claimed as the property of others






Serial Write – Read Input and Format



Source Code: Lessons\Lesson2-BasicIO\Section4-SerialRead\Serial_ReadWriteFormates




```
COM7
                                                            Send
I received, ASCII: H, dec: 72, hex: 48, oct: 110, bin: 1001000
I received, ASCII: e, dec: 101, hex: 65, oct: 145, bin: 1100101
I received, ASCII: 1, dec: 108, hex: 6C, oct: 154, bin: 1101100
I received, ASCII: 1, dec: 108, hex: 6C, oct: 154, bin: 1101100
I received, ASCII: o, dec: 111, hex: 6F, oct: 157, bin: 1101111
I received, ASCII: , dec: 32, hex: 20, oct: 40, bin: 100000
I received, ASCII: W, dec: 87, hex: 57, oct: 127, bin: 1010111
I received, ASCII: o, dec: 111, hex: 6F, oct: 157, bin: 1101111
I received, ASCII: r, dec: 114, hex: 72, oct: 162, bin: 1110010
I received, ASCII: 1, dec: 108, hex: 6C, oct: 154, bin: 1101100
I received, ASCII: d, dec: 100, hex: 64, oct: 144, bin: 1100100
 Autoscroll
                                      No line ending
                                                     9600 baud
```

* Other names and brands may be claimed as the property of others



Serial Read – Read Convert to int, then Add

```
char character;
String content = "";
int additionSum = 0;
void setup() {
 Serial begin (9600);
                      // opens serial port, sets data rate to 9600 bps
void loop() {
 //Read Input Buffer
 while(Serial.available()) {
  character = Serial.read();
  content.concat(character);
 if (content != "") {
  if (content.toInt() > 0) { //Make sure input is a number greater than zero
   Serial.print(additionSum);
   Serial print(" + ");
   Serial.print(content);
   Serial.print(" = ");
   additionSum = additionSum + content.toInt(); // Perform Addition
   Serial.println(additionSum);
  } else {
   Serial println("Input my be a number greater than 0");
  content = ""; //Empty string
```



* Other names and brands may be claimed as the property of others

Project Files - USB Drive:\Lessons\Lesson2-BasicIO\Section4-SerialRead\Serial_ReadAdd



Serial 1 – Reading and Writing



```
char character;
String content = "";
void setup() {
 Serial begin(115200); // opens serial port, sets data rate to 115200 bps
 Serial1.begin(115200); // opens serial port, sets data rate to 115200 bps
void loop() {
 Serial1.write("Hello World"); // Write content to Serial1 interface
 while(Serial1.available()) {
  character = Serial1.read();
  content.concat(character); //Concatenate to existing string
 if (content != "") {
  Serial println(content); //Print string to serial
  content = ""; //Empty string
 delay(2000);
```




```
UART USB DISCIPLATION OF THE SERVICE OF THE SERVICE
```


* Other names and brands may be claimed as the property of others

Project Files - USB Drive:\Lessons\Lesson2-BasicIO\Section4-SerialRead\Serial1ToSerial



Other Serial 1 Possibilities





fritzing

* Other names and brands may be claimed as the property of others



Serial Write - Engineering Challenge



Using your own circuit design and Arduino sketch, design a solution that solves the following challenges.

Use previous Lab example as needed for reference


Challenge 1: Type in the number of times to blink an LED




Engineering Challenge Review

Challenge 1: Type in the number of times to blink an LED

hallense Reviewnk Source Code: Lessons\Lesson2-BasicIO\Section4-SerialRead\Serial_Read





fritzing


^{*} Other names and brands may be claimed as the property of others





Using Alternative Terminals

- Although nicely integrated into Arduino IDE, you are not required to use the integrated Serial Monitor.
- Use any Terminal connecting to the proper COM port at the correct baud rate
- Simultaneous use (multiple sessions to COM port), not viable



Arduino Serial Monitor

```
Total of 3 + 4 = 7

-----

Example 1 - Print Char on 1 line
Hello World

-----

Example 2 - Print multiple on 1 line
Hello World

-----

Example 3 - Print Each Character on new line
H
e
1
1
0

W
0
0
r
1
1
d
-----


Example 4 - Combine String and Print on Single Line
Total of 3 + 4 = 7
```

PuTTY



Basic I/O - Analog Writes


Analog Write





Pulse Width Modulation


- PWM is a technique for getting analog results with digital means
- Can be used to light a LED at varying brightness or drive a motor at various speeds
- PWM is supported on Pin 3, 5, 6, 9, 10, and 11





Pulse Width Modulation

- Digital control is used to create a square wave, a signal switched between on and off.
- This on-off pattern can simulate voltages in between full on (5 Volts) and off (0 Volts) by changing the portion of the time the signal spends "On" (5volts) versus "Off" (0volts)
- To get varying analog values, you change, or modulate, that pulse width
- A call to <u>analogWrite()</u> is on a scale of 0 – 255...
 - analogWrite of 255 requests a 100% duty cycle (always on)
 - analogWrite of 127 is a 50% duty cycle (on half the time)
 - analogWrite of 0 is a 0% duty cycle (Always off)





Analog Write – Key Concepts

Reminder pinMode(): Configures the specified pin to behave either as an input or an output

- Syntax: pinMode(pin, mode)
- Example: pinMode(11, OUTPUT) set pin 11 to output mode

analogWrite(): Writes an analog value (Pulse Width Modulation wave) to a pin.

- Syntax: analogWrite(pin, value)
- Example: analogWrite (11, 32) send PWM of 100 to pin 11
- What's the Duty Cycle if analogWrite is 32?



Serial Read – LED Fade



Project Name: LED Fade (Instructor Lead)

Objective: Change the brightness of an LED to make it appear to fade in and out

Software Elements

- analogWrite()
- pinMode()

Components


- Breadboard (QTY1)
- Jumper Wires
- 5mm LED (Qty 1)
- 220 Ohm Resister (Qty1)



Analog Write – Fade LED



```
Fade
This example shows how to fade an LED on pin 11
using the analogWrite() function.
This example code is in the public domain.
                 // the pin that the LED is attached to
int led = 11;
int brightness = 0; // how bright the LED is
int fadeAmount = 5; // how many points to fade the LED by
// the setup routine runs once when you press reset:
void setup() {
 // declare pin 11 to be an output:
 pinMode(led, OUTPUT);
// the loop routine runs over and over again forever:
void loop() {
 // set the brightness of pin 9:
 analogWrite(led, brightness);
 // change the brightness for next time through the loop:
 brightness = brightness + fadeAmount;
 // reverse the direction of the fading at the ends of the fade:
 if (brightness == 0 || brightness == 255) {
  fadeAmount = -fadeAmount;
 // wait for 30 milliseconds to see the dimming effect
 delay(30);
```




* Other names and brands may be claimed as the property of others



Basic I/O Analog Read

Analog Read



Analog Pins

- Analog Pins are A0-A5
- Will map input voltages between 0 and 5 volts into integer values between 0 and 1023
- Can also be used as digital pins: analog input 0 as digital pin 14 through analog input 5 as digital pin 19






Analog Read – Key Concepts

analogRead(): Reads the value from the specified analog pin.

- Syntax: analogRead(pin)
- Example: analogRead(A0) reads analog value of pin A0

map(): Re-maps a number from one range to another. Value can be mapped to values that are out of range.

- Syntax: map(Source, fromLow, fromHigh, toLow, toHigh)
- Example: map(val, 0, 1023, 0, 254)





Analog Read – POT Value Read



Project Name: Reading Analog Values (Instructor Lead)

Objective: Read POT value and map to alternative range

Software Elements

- analogRead()
- Serial.println()
- map()

Components

- Breadboard (QTY1)
- Jumper Wires
- Potentiometer



Analog Read – Read and Write POT Value




```
AnalogReadSerial
Reads an analog input on pin 0, prints the result to the serial monitor.
Attach the center pin of a potentiometer to pin A0, and the outside pins to +5V and ground.

This example code is in the public domain.

*/
```

```
// the setup routine runs once when you press reset:
void setup() {
    // initialize serial communication at 9600 bits per second:
    Serial.begin(9600);
}

// the loop routine runs over and over again forever:
void loop() {
    // read the input on analog pin 0:
    int sensorValue = analogRead(A0);
    // print out the value you read:
    Serial.println(sensorValue);
    delay(500);    // delay in between reads for stability
}
```




* Other names and brands may be claimed as the property of others



Analog Read – Read and Write Map Value



```
const int analogInPin = A0; // Analog input pin that the potentiometer is attached to
//const int analogOutPin = 11; // Analog output pin that the LED is attached to
int sensorValue = 0;
                        // value read from the pot
                        // value output to the PWM (analog out)
int outputValue = 0;
void setup() {
 // initialize serial communications at 9600 bps:
 Serial.begin(9600);
void loop() {
 // read the analog in value:
 sensorValue = analogRead(analogInPin);
 // map it to the range of the analog out:
 outputValue = map(sensorValue, 0, 1023, 0, 255);
 // change the analog out value:
// analogWrite(analogOutPin, outputValue);
 // print the results to the serial monitor:
 Serial.print("sensor = " );
 Serial.print(sensorValue);
 Serial.print("\t output = ");
 Serial.println(outputValue);
 // wait 2 milliseconds before the next loop
 // for the analog-to-digital converter to settle
 // after the last reading:
 delay(200);
```



Project Files - USB Drive:\Lessons\Lesson2-BasicIO\Section6-AnalogRead\AnalogReadSerialMap



Analog Write- Engineering Challenge



Using your own circuit design and Arduino sketch, design a solution that solves the following challenges.

Use previous Lab example as needed for reference

Challenge 1: Fade LED based on POT Value



Engineering Challenge Review

Challenge 1: Fade LED based on POT Value



```
// These constants won't change. They're used to give names
// to the pins used:
const int analogInPin = A0; // Analog input pin that the potentiometer is attached to
const int analogOutPin = 11; // Analog output pin that the LED is attached to
int sensorValue = 0;
                        // value read from the pot
int outputValue = 0;
                        // value output to the PWM (analog out)
void setup() {
 // initialize serial communications at 9600 bps:
 Serial.begin(9600):
void loop() {
// read the analog in value:
 sensorValue = analogRead(analogInPin);
 // map it to the range of the analog out:
 outputValue = map(sensorValue, 0, 1023, 0, 255);
 // change the analog out value:
 analogWrite(analogOutPin, outputValue);
 // print the results to the serial monitor:
 Serial print("sensor = ");
 Serial.print(sensorValue);
 Serial.print("\t output = ");
                                                                                  Image Source from Fritzing*
 Serial.println(outputValue);
 // wait 2 milliseconds before the next loop for the analog-to-digital converter to settle after the last reading:
 delay(2);
                      Project Files - USB Drive:\Lessons\Lesson2-BasicIO\Section6-AnalogRead\AnalogReadMapFade
```

^{*} Other names and brands may be claimed as the property of others




fritzing

Section Review Challenge

Reaction Timer



Source Code: Lesson2-BasicIO\Section7-Review\ReactionTimerInital



fritzing

Project Files - USB Drive:\Lessons\Lesson2-BasicIO\Section7-Review\ReactionTimerInital



62

^{*} Other names and brands may be claimed as the property of others

Capstone - Engineering Challenge



Using your own circuit design and Arduino sketch, design a solution that solves the following challenges.


Use previous Lab example as needed for reference

Challenge 1: Add additional Reaction Button and Indicator

Challenge 2: Add variable knob to change the number of times the game ready indicator blinks before the start of game



Capstone – Reaction Timer Source Code: Lesson2-BasicIO\Section7-Review\ReactionTimerCharge Capstone – Reaction Timer Source Code: Lesson2-BasicIO\Section7-Review\ReactionTimerCharge Capstone – Reaction Timer Source Code: Lesson2-BasicIO\Section7-Review\ReactionTimerCharge Capstone – Reaction Timer



fritzing

Project Files - USB Drive:\Lessons\Lesson2-BasicIO\Section7-Review\ReactionTimerChallenge



^{*} Other names and brands may be claimed as the property of others

But wait there's more... Reapplying Concepts Learned



Project Files - USB Drive:\Lessons\Lesson2-BasicIO\Section7-Capstone\RelayExample



Questions

Legal Disclaimer

INFORMATION IN THIS DOCUMENT IS PROVIDED IN CONNECTION WITH INTEL PRODUCTS. NO LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, TO ANY INTELLECTUAL PROPERTY RIGHTS IS GRANTED BY THIS DOCUMENT. EXCEPT AS PROVIDED IN INTEL'S TERMS AND CONDITIONS OF SALE FOR SUCH PRODUCTS, INTEL ASSUMES NO LIABILITY WHATSOEVER AND INTEL DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY, RELATING TO SALE AND/OR USE OF INTEL PRODUCTS INCLUDING LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.

A "Mission Critical Application" is any application in which failure of the Intel Product could result, directly or indirectly, in personal injury or death. SHOULD YOU PURCHASE OR USE INTEL'S PRODUCTS FOR ANY SUCH MISSION CRITICAL APPLICATION, YOU SHALL INDEMNIEY AND HOLD INTEL AND ITS SUBSIDIARIES, SUBCONTRACTORS AND AFFILIATES, AND THE DIRECTORS, OFFICERS, AND EMPLOYEES OF EACH, HARMLESS AGAINST ALL CLAIMS COSTS, DAMAGES, AND REASONABLE ATTORNEYS' FEES ARISING OUT OF, DIRECTLY OR INDIRECTLY, ANY CLAIM OF PRODUCT LIABILITY, PERSONAL INJURY, OR DEATH ARISING IN ANY WAY OUT OF SUCH MISSION CRITICAL APPLICATION. WHETHER OR NOT INTEL OR ITS SUBCONTRACTOR WAS NEGLIGENT IN THE DESIGN. MANUFACTURE. OR WARNING OF THE INTEL PRODUCT OR ANY OF ITS PARTS.

Intel may make changes to specifications and product descriptions at any time, without notice. Designers must not rely on the absence or characteristics of any features or instructions marked "reserved" or "undefined". Intel reserves these for future definition and shall have no responsibility whatsoever for conflicts or incompatibilities arising from future changes to them. The information here is subject to change without notice. Do not finalize a design with this information.

The products described in this document may contain design defects or errors known as errata which may cause the product to deviate from published specifications. Current characterized errata are available on request.

Contact your local Intel sales office or your distributor to obtain the latest specifications and before placing your product order.

Copies of documents which have an order number and are referenced in this document, or other Intel literature, may be obtained by calling 1-800-548-4725, or go to: http://www.intel.com/design/literature.htm%20 Performance tests and ratings are measured using specific computer systems and/or components and reflect the approximate performance of Intel products as measured by those tests. Any difference in system hardware or software design or configuration may affect actual performance. Buyers should consult other sources of information to evaluate the performance of systems or components they are considering purchasing. For more information on performance tests and on the performance of Intel products, visit Intel Performance Henchmark Limitations

All products, computer systems, dates and figures specified are preliminary based on current expectations, and are subject to change without notice.

Celeron, Intel, Intel logo, Intel Core, Intel Inside, Intel Inside, Intel Inside, Intel Inside, VTune, Xeon, and Xeon Inside are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Intel® Active Management Technology requires the platform to have an Intel® AMT-enabled chipset, network hardware and software, as well as connection with a power source and a corporate network connection. With regard to notebooks, Intel AMT may not be available or certain capabilities may be limited over a host OS-based VPN or when connecting wirelessly, on battery power, sleeping, hibernating or powered off. For more information, see http://www.intel.com/technology/iamt.

64-bit computing on Intel architecture requires a computer system with a processor, chipset, BIOS, operating system, device drivers and applications enabled for Intel® 64 architecture. Performance will vary depending on your hardware and software configurations. Consult with your system vendor for more information.

No computer system can provide absolute security under all conditions. Intel® Trusted Execution Technology is a security technology under development by Intel and requires for operation a computer system with Intel® Virtualization Technology, an Intel Trusted Execution Technology-enabled processor, chipset, BIOS, Authenticated Code Modules, and an Intel or other compatible measured virtual machine monitor. In addition, Intel Trusted Execution Technology requires the system to contain a TPMv1.2 as defined by the Trusted Computing Group and specific software for some uses. See http://www.intel.com/technology/security/ for more information.

†Hyper-Threading Technology (HT Technology) requires a computer system with an Intel® Pentium® 4 Processor supporting HT Technology and an HT Technology-enabled chipset, BIOS, and operating system. Performance will vary depending on the specific hardware and software you use. See www.intel.com/products/ht/hyperthreading_more.htm for more information including details on which processors support HT Technology.

Intel® Virtualization Technology requires a computer system with an enabled Intel® processor, BIOS, virtual machine monitor (VMM) and, for some uses, certain platform software enabled for it. Functionality, performance or other benefits will vary depending on hardware and software configurations and may require a BIOS update. Software applications may not be compatible with all operating systems. Please check with your application vendor.

* Other names and brands may be claimed as the property of others.

Other vendors are listed by Intel as a convenience to Intel's general customer base, but Intel does not make any representations or warranties whatsoever regarding quality, reliability, functionality, or compatibility of these devices. This list and/or these devices may be subject to change without notice.

Copyright © 2014, Intel Corporation. All rights reserved.





Backup

