

Enlarging Schematics

Using Posterazor to enlarge Fusion360 schematic diagrams

Here's What To Do

1. Go to <https://posterazor.sourceforge.io> in Safari or Chrome
2. Click "**Use the WebAssembly-based version**"
3. It will walk you through **5 steps**:
 - **Step 1:** Load your PNG file
 - **Step 2:** Set paper size to **US Letter**, orientation **Landscape** (recommended for schematics)
 - **Step 3:** Set the **overlap** between pages — try **0.5 inches** so adjacent sheets align easily when assembled
 - **Step 4:** Set the poster size — you can specify either total dimensions or **number of pages** (e.g. $2 \times 2 = 4$ sheets, $3 \times 2 = 6$ sheets, etc.)
 - **Step 5:** Save as a **multi-page PDF**, then print that PDF
4. Print the resulting PDF at **100% scale** — do not scale to fit

The overlap feature ensures a seamless transition between pages, which is really helpful when you're trying to read a schematic across sheets.