RPAS OPERATOR QUICK REFERENCE

Remote Pilot Quick Reference Card

SIDE 1: FLY & NAVIGATE

SOLO: AVIATE ▶ NAVIGATE ▶ COMMUNICATE ▶ ADMINISTRATE

MULTI-CREW: COMMUNICATE ▶ AVIATE ▶ NAVIGATE ▶ COMMUNICATE ▶ ADMINISTRATE

1 AVIATE

Fly the aircraft first

120 m	30 m	5.5 km	3 NM
MAX ALTITUDE (AGL)	MIN DISTANCE FROM PEOPLE	FROM TOWERED AERODROMES	FROM UNCONTROLLED AERODROMES / HLS
		RADIO CALL TOWER CLEARANCE	RADIO CALL CTAF BROADCAST
		see Communicate	*see Communicate*

AIRBORNE SEPARATION

Maintain both from ALL crewed aircraft:

500 ft VERTICAL | **1500 m** HORIZONTAL

! CREWED AIRCRAFT BREACH

If horizontal separation is lost: **DESCEND IMMEDIATELY** to lowest safe altitude, or land.

AIRCRAFT VLOS LIMITS (FROM HOME POINT)

DJI Mavic Mini	500 m
DJI Matrice 30T	1000 m

2 NAVIGATE

Airspace & weather

VTC / VNC MAP LEGEND

———	**Solid Blue**	Class C Controlled	(Clearance req)
- - - -	**Dash Blue**	Class D Controlled	(Clearance req)
- - - -	**Dash Red**	Restricted Area	(Check NOTAMs)
- - - -	**Dash Magenta**	Danger Area	(Flight permitted, high alert)

METAR / TAF / NOTAM TERMS

CAVOK: Ceiling & Visibility OK
VMC: Visual Met Conditions
SIGMET: Severe weather warning (turbulence, etc.)

CLOUDS (oktas)
FEW (1-2) • **SCT** (3-4)
BKN (5-7) • **OVC** (8)

HAZARDS: TS (Storm) • **RA** (Rain) • **SH** (Showers) • **FG** (Fog)

RPAS OPERATOR QUICK REFERENCE

Remote Pilot Quick Reference Card

SIDE 2: COMMUNICATE & ADMINISTRATE

3 COMMUNICATE

Radio scripts

RULE: Always use callsign **"Uncrewed RPA"** and report the **AIRCRAFT's location**, not your physical location.

CTAF / BLIND BROADCAST

15 min prior & at intervals

WHEN: **Within 3 NM of an uncontrolled aerodrome / HLS**

*"**[Location]** Traffic, Uncrewed RPA, operating **[Dist/Bearing]** from **[Aerodrome/Landmark]**, surface to 400 feet. Operations continuing for the next **[Time Amount]**, **[Location]**."*

TOWER / ATC REQUEST

Controlled airspace

WHEN: **Within 5.5 km of a towered aerodrome (controlled airspace)**

*"**[Tower Name]**, Uncrewed RPA **[Your Name/ID]**, request clearance to operate at **[Location]**, surface to 400 feet, for **[Duration]**."*

DIRECT TO AIRCRAFT

Traffic avoidance

WHEN: **Crewed aircraft nearby / separation at risk**

*"**[Aircraft Callsign]**, Uncrewed RPA, I have you on sight. I am descending to surface / holding at **[Altitude]** at **[Location]** to remain clear."*

END OF FLIGHT / OPERATIONS COMPLETE

WHEN: **When landed and operations are complete**

*"**[Location]** Traffic / Tower, Uncrewed RPA has landed and operations are complete, **[Location]**."*

! LOSS OF TOWER COMMS

Land immediately. Use mobile phone to contact tower.

4 ADMINISTRATE

Key contacts

EMERGENCY SERVICES
000

AUAVS AIR DESK (URGENT)
02 9457 1027

Oliver Heys AUAVS Chief Remote Pilot	**0472 651 733**
Cassie Lock RFS RPAS Capability	**0417 358 704**
Mark Atkins Deputy Chief Remote Pilot	**0419 918 409**
Brett Hagan Mgr Ops Field Support	**0429 449 885**