



STRAPPING PINS CONFIGURATION

Strapping Pin	Default Configuration
RTNS (GPIO4)	FLOATING (-)
MTD0 (GPIO8)	FLOATING (-)
GPIO0	FLOATING (-)
GPIO9	PULL UP (1)
GPIO55	FLOATING (-)

