

Dell 1545 Key Matrix Teensy 4.1

FPC# - GPIO#	18 - 8	19 -14	20 -9	21 -10	22-11	23 -12	24 -24	25 -25
1 -23		Insert		F12				Arrow-Right
2 -0		Delete		F11				Arrow-Down
3 -22	Arrow-Up	Home	Menu	End				Arrow-Left
4 -1		F8	F7	9	O	L	Period	
5 -21	Quote	Minus	[	0	P	;		/
6 -2	F6	Equal	]	8	I	K	Comma	
7 -20	H	6	Y	7	U	J	M	N
8 -3	F5	F9	Back Space	F10		\	Enter	Space
9 -19	G	5	T	4	R	F	V	B
10 -4	F4	F2	F3	3	E	D	C	
11 -18		F1	Caps-Lock	2	W	S	X	
12 -5	Esc	Back-Tick	Tab	1	Q	A	Z	
13 -17	Alt-L			Print Screen	Num-Lock			Alt-R
14 -6			Shift-L				Shift-R	
15 -16		Cntrl-L					Cntrl-R	
16 -7				GUI	Page-Up	Page-Down		
17 -15						Fn		