



Presented by The High End

CARDBOARD PLAYHOUSE

Full-Size Walk-In House with Door, Windows & Roof

Build a full-size cardboard house they can actually walk into. Move-in ready.

AGES 3–8	BOXES 4–6 Large Boxes	TIME 2–3 Hours	DIFF Intermediate **	PIECES 4 pcs
-------------	--------------------------	-------------------	-------------------------	-----------------

CARDBOARD NEEDED:
4–6 Large Boxes (at least 24" × 36" (61 × 91 cm) each)


MISSION GOAL:
Build a full-size walk-in playhouse: 4 walls, working door, 2 windows, peaked roof, chimney.

1

STEP 1: FLATTEN & PLAN

Flatten all boxes. Lay all 4 Wall Panels on the floor. Mark which wall gets the door and which 2 get windows BEFORE cutting anything.

PIECES USED IN THIS STEP



BUILD TO MATCH THIS


2

STEP 2: BUILD 4 WALLS

Stand the 4 Wall Panels upright and tape all 4 corners — 3+ layers inside AND outside. House must be square. Measure the two diagonals — they must be equal. Adjust corners before tape dries.

SAFETY: Two people needed to hold walls while taping each corner.

PIECES USED IN THIS STEP



! ADULT ASSIST NEEDED

3

STEP 3: CUT THE DOOR

On the door wall: cut 3 sides of the door (cut marks on template — left side, right side, bottom). Leave the TOP EDGE uncut as the hinge. Fold it open. Add a cardboard handle tab on one side.

SAFETY: Adult cuts only. Door bottom edge must be smooth — no tripping hazard.

! ADULT ASSIST NEEDED

4

STEP 4: CUT THE WINDOWS

On 2 side walls: cut 4-sided window openings (cut marks on template — 12 inch x 12 inch (30 x 30 cm) each). Leave 3 inch (8 cm) frame on all sides. Add cardboard cross-strips through each window.

SAFETY: Adult cuts all window openings.


! ADULT ASSIST NEEDED

5

STEP 5: ADD GABLE ENDS

Cut both Gable Triangles (taper marks on template). These fill the triangular gap between the top of the front/rear walls and the roof peak. Tape to front and rear wall tops.

PIECES USED IN THIS STEP



6


STEP 6: ADD THE ROOF

! ADULT ASSIST NEEDED

Lay both Roof Panels across the top — one on each side, meeting at the center ridge (score line on template marks the ridge). Tape the ridge seam from the inside. Tape roof panels to the tops of all 4 walls.

SAFETY: Two people needed — one holds roof panels, one tapes.

PIECES USED IN THIS STEP




7

STEP 7: BUILD THE CHIMNEY

Tape all 4 Chimney Panels into a rectangular tube (fold marks on template show attachment edges). Mount off-center on the roof. Tape through the roof into the chimney sides.

PIECES USED IN THIS STEP



8

STEP 8: DECORATE

Paint the child's favorite colors. Draw brick lines. Add flower boxes under windows. Paint a name on the door. Draw a welcome mat at the entrance.

9

STEP 9: QUALITY CHECK

Child walks through door without ducking. Windows visible. Roof fully covered. Chimney upright. House stands without being held. Compare to cover photo. That's the standard.

QUALITY CHECK!

Does your build match the cover photo? Compare side by side before you call it done.


"Build It. Own It." — Tatum & Kash Cardboard Creations



WALL PANEL

36" × 48" (91 × 122 cm) | Cut ×4

CUT
x4



MARK LEGEND FOR THIS PIECE:

CUT — scissors or box cutter on this line

NOTE: All 4 walls equal height



ROOF PANEL

24" x 36" (61 x 91 cm) | Cut x2

CUT
x2

ROOF PANEL

x2

24" x 36" (61 x 91 cm)
Two panels meet at the ridge

MARK LEGEND FOR THIS PIECE:

FOLD — score lightly, then fold at this line	SCORE — press hard with ruler but do NOT cut through
--	--

NOTE: Two panels meet at the ridge

PIEZAS DE CARTÓN — 4 EN TOTAL (4-6 cajas grandes (al menos 24" × 36" (61 × 91 cm) cada una))

×4

Panel de pared

36" × 48"

Las 4 paredes con la misma altura

×2

Panel de techo

24" × 36"

Dos paneles se juntan en la cumbrera

×2

Triángulo del frontón

24" × 18"

Rellena el hueco entre la parte alta de la pared y la cima del techo

×4

Panel de chimenea

8" × 12"

4 paneles forman la caja de la chimenea

HERRAMIENTAS Y MATERIALES

+ 4-6 cajas de cartón grandes (tamaño electrodoméstico)

+ Cúter: SOLO PARA ADULTOS

+ Cinta de embalar (3 o más rollos)

+ Pintura o marcadores en los colores favoritos del niño

+ Cartón extra para la manija de la puerta y los marcos de ventana

+ Regla y lápiz

¡DATO CURIOSO!

La casa más pequeña en la que alguien vivió a tiempo completo medía 8 pies de ancho. Tu casa de cartón puede que sea más grande.

¡DESAFÍO!

¡Fiesta de inauguración! Una vez construida, pon una mesa dentro, invita a los peluches y merienden. ¿Cuántos cabes como máximo?

1

PASO 1: DESARMA Y PLANIFICA

Desarma todas las cajas. Coloca los 4 paneles de pared en el suelo. Marca qué pared lleva la puerta y cuáles 2 llevan ventanas ANTES de cortar nada.

2

PASO 2: ARMA LAS 4 PAREDES

! AYUDA DE UN ADULTO

Pon de pie los 4 paneles de pared y pega las 4 esquinas con cinta: 3 o más capas por dentro Y por fuera. La casa debe quedar a escuadra. Mide las dos diagonales: deben ser iguales. Ajusta las esquinas antes de que se seque la cinta.

SEGURIDAD: Se necesitan dos personas para sujetar las paredes mientras se pega cada esquina.

3

PASO 3: CORTA LA PUERTA

! AYUDA DE UN ADULTO

En la pared de la puerta: corta 3 lados de la puerta (marcas de corte en la plantilla: lado izquierdo, lado derecho y abajo). Deja el BORDE DE ARRIBA sin cortar, como bisagra. Ábrela. Añade una pestaña de cartón como manija en un lado.

SEGURIDAD: Solo el adulto corta. El borde inferior de la puerta debe quedar liso: que no haga tropezar.

4

PASO 4: CORTA LAS VENTANAS

! AYUDA DE UN ADULTO

En 2 paredes laterales: corta aberturas de ventana de 4 lados (marcas de corte en la plantilla: 12" x 12" (30 x 30 cm) cada una). Deja un marco de 3" (8 cm) en todos los lados. Añade tiras cruzadas de cartón en cada ventana.

SEGURIDAD: El adulto corta todas las aberturas de las ventanas.

5

PASO 5: AÑADE LOS FRONTONES

Corta los dos triángulos del frontón (marcas de inclinación en la plantilla). Estos rellenan el hueco triangular entre la parte alta de las paredes delantera/trasera y la cima del techo. Pégalos en la parte de arriba de las paredes delantera y trasera.

6

PASO 6: AÑADE EL TECHO

! AYUDA DE UN ADULTO

Coloca los dos paneles de techo encima, uno a cada lado, juntándose en la cumbrera central (la línea marcada en la plantilla indica la cumbrera). Pega la costura de la cumbrera desde dentro. Pega los paneles de techo a la parte de arriba de las 4 paredes.

SEGURIDAD: Se necesitan dos personas: una sujeta los paneles de techo y la otra pega.

7

PASO 7: ARMA LA CHIMENEA

Pega los 4 paneles de chimenea formando un tubo rectangular (las marcas de doblez en la plantilla muestran los bordes de unión). Móntala descentrada sobre el techo. Pega a través del techo hacia los lados de la chimenea.

8

PASO 8: DECORA

Pinta con los colores favoritos del niño. Dibuja líneas de ladrillos. Añade jardineras debajo de las ventanas. Pinta un nombre en la puerta. Dibuja un felpudo de bienvenida en la entrada.

9

PASO 9: CONTROL DE CALIDAD

El niño pasa por la puerta sin agacharse. Ventanas visibles. Techo totalmente cubierto. Chimenea de pie. La casa se mantiene sin que la sujeten. Compáralo con la foto de portada. Ese es el estándar.

¡CONTROL DE CALIDAD!

¿Tu construcción se parece a la foto? Compárala lado a lado antes de darla por terminada.

"Build It. Own It." — Tatum & Kash Cardboard Creations