```
% Prompt user inputs
weight of cloth = input('Enter weight of the cloth (kg): ');
quantity of dirt = input('Enter quantity of dirt (low, medium, high): ', 's');
type of fabric = input('Enter type of fabric (cotton, synthetic, delicate,
wool): ', 's');
% Call the washing machine function
[water_level, detergent_quantity, wash time] =
washing machine(weight of cloth, quantity of dirt, type of fabric);
% Display results in the Command Window
fprintf('Water Level: %d liters\n', water level);
fprintf('Detergent Quantity: %.2f grams\n', detergent_quantity);
fprintf('Wash Time: %d minutes\n', wash time);
% Function definition
function [water level, detergent quantity, wash time] =
washing machine(weight of cloth, quantity of dirt, type of fabric)
  % Determine dirt level
  if stremp(quantity of dirt, 'low')
     dirt level = 1;
  elseif strcmp(quantity of dirt, 'medium')
     dirt level = 2;
  else
     dirt level = 3;
  end
  % Determine fabric type
  if stremp(type of fabric, 'cotton')
     fabric type = 1;
  elseif strcmp(type_of_fabric, 'synthetic')
     fabric type = 2;
  elseif strcmp(type of fabric, 'delicate')
     fabric type = 3;
  else
     fabric type = 4;
  end
  % Determine water level based on weight of cloth
  if weight of cloth <= 5
     water \overline{level} = 1;
  elseif weight of cloth <= 10
```

```
water level = 2;
  else
     water level = 3;
  end
  % Adjust water level for high dirt level
  if dirt level == 3
    water level = min(water level + 1, 3);
  end
  % Determine detergent quantity based on weight of cloth
  if weight of cloth <= 5
    detergent quantity = 50;
  elseif weight_of_cloth <= 10
     detergent quantity = 100;
  else
     detergent quantity = 150;
  end
  % Adjust detergent quantity for high dirt level
  if dirt level == 3
     detergent quantity = min(detergent quantity + 50, 200);
  end
  % Determine wash time based on weight of cloth
  if weight of cloth <= 5
    wash time = 30;
  elseif weight of cloth <= 10
     wash time = 45:
  else
     wash time = 60;
  end
  % Adjust wash time for high dirt level
  if dirt level == 3
    wash time = wash time + 15;
% Adjust wash time for fabric type
  if fabric type == 3 % Delicate
     wash time = wash time - 10;
     water level = 1;
     detergent quantity = 50;
```

```
elseif fabric_type == 4 % Wool

wash_time = wash_time + 10;

water_level = 3;

detergent_quantity = 150;

end

end
```