VOLTAGE/AMPERAGE CHART:

240 Volt Installation Units Electrical Requirements
Requirement
- 240 volt/60 amp, 50 amp, 40 amp, or 30 amp. - 60 Hz - Single phase - 4-wire service (line 1, line 2 neutral and ground)
NOT NORTH AMERICAN - 240 volt - 50 Hz - Single-, two-, or three- phase service - Refer to wiring diagram or pouch on control system inside cabinet for specific wiring and phase information.

120 Volt Installation Units Electrical Requirements
Requirement
- 120 volt/30 amp or 15 amp. - 60 Hz - Single phase - 3-wire service (line 1, neutral and ground)

THIS SECTION APPLIES TO SPAS INSTALLED OUTSIDE OF NORTH AMERICA

Number	Meaning
1	The heater will only remain running with no more than two pumps on high speed. All pumps will run on high speed when heater is off.
2	The heater will only remain running with Pump 1 on low speed. Only the spa light can operate at the same time without disabling the heater. All pumps will run on high speed when heater is off.

DEDICATED 240V UNITS North America				
MODELS	**240V/60A**	**240V/50A**	**240V/40A**	**240/30A**
VM8 (Spa Side)		1		2
VM8 (Swim Side)	1	2		
VM6	1			
VM5	1			
XL5		1		2
VB4	1	2		
VL4	1	2		
XB4	1		2	
XL4	1		2	
XF2	1		2	
Mystique	1	2		
Rendezvous	1	2		
Riviera	1	2		
Vivre	1	2		
Cabaret	1	2		
Joli	1		2	
Trio			1	2
Prestige	1		2	
Monarque	1		2	
Envie	1		2	
Grand	1		2	
Luxe		1	2	
Sensation		1	2	
Elegant		1	2	
Intrigue			1	2
Amour			1	2
Salon	1		2	

See previous page for explanation of corresponding letters and numbers.

NOTE: ALL SPAS IN THIS TABLE LEAVE THE FACTORY AS 240V AND CAN BE CONVERTED DOWN TO 120V

SPAS THAT ARE CONVERTIBLE (240V TO 120V) North America				
Model	120V/30A	120V/15A	240V/40A	240V/30A
Lune	1	2	1	2
Duet	1	2	1	2
Voeux	1	2	1	2
Image	1	2	1	2

NOTE: Electrical service requirements will change after conversion.

See previous page for explanation of corresponding letters and numbers.