

MikroTik Router As Switch Using Bridge (MTCNAPP3) by @themmfuad

STEP-1: Turn on RoMON on all 3 routers and change their hostname serially SW1, SW2, and SW3.

STEP-2: Go to "Bridge -> Add", set "Name=LAN_BRIDGE" apply & OK.

STEP-3: Go to "Bridge -> Ports -> Add" Select the interface to add to this LAN and select "Bridge= LAN_BRIDGE", and use this method to add all the interfaces that are in this LAN.

STEP-4: Assign the appropriate IP Address to the Hosts.

STEP-5: Check the connection between the Hosts.