

# **System Specifications**

**Standardised Interfaces** 

**Application Programmer's Interface** 

#### Summary

This document defines the standardised Application Programmer's Interfaces (API's) for standardised bus devices.

Version 01.01.01 is a KNX Approved Standard.

This document is part of the KNX Specifications v2.1.

3

6

1

# **Document updates**

Version	Date	Modifications	
0.3	2001.05.22	nclusion from comments from RfV.	
1.0	2002.02.28	Preparation of the Approved Standard. Inclusion of mask 0021, added specification for functions U_EE_WriteHI and U_Char_Out.	
1.1	2008.10.27	AN015 "API CU" integration started	
1.1	2009.06.24	Preparation for inclusion in the KNX Specifications v2.0.	
01.01.01	2013.10.28	Editorial updates for the publication of KNX Specifications 2.1.	

### References

[01] Chapter 3/6/3 "External Message Interface"

[02] Part 3/7 "Interworking"

[03] Part 9/4 "BCUs and BIMs"

Filename: 03\_06\_01 Application Programmers Interface v01.01.01 AS.docx

Version: 01.01.01

Status: Approved Standard

Savedate: 2013.10.28

Number of pages: 53

# **Contents**

1		cteristics of BCU RAM and EEPROM Variables	
		API RAM Variables and RAM Space	
		1.1 Registers B to N	
		1.2 Stack Space available for the Internal Application	
		1.3 Internal Application (i.e. "User") RAM	
		API EEPROM Variables and EEPROM Space	
		2.1 Group Object Table pointer "CommsTabPtr" and "CommsTabPtr2"	
		User Initialisation Routine pointer "UsrInitPtr" and "UsrIntiPtr2"	
		User Program Pointer "UsrPrgPtr" and "UsrPrgPtr2"	
		2.4 User Save Routine Pointer "UsrSavPtr" and "UsrSavPtr2"	
		2.5 Internal User Application (i.e. "user") EEPROM space	7
		API Tables	
		3.1 OR_TAB	
		3.2 AND_TAB	
		System Timer	
	1.5 U	Jser Timer	8
2	API F	unction Reference	10
_		Group Object Manipulation Functions	
		1.1 U_flagsGet Reading RAM Flags	
		1.2 U_flagsSet Writing RAM flags	
		1.3 U_testObj Testing RAM flags	
		1.4 U_transRequest Setting Transmit Request	
		1.5 Standard Callback	
		EPROM Manipulation Support Functions	
		2.1 Eewrite Writing to EEPROM	
		2.2 EEsetChecksum Updating the checksum	
		2.3 U_EE_WriteBlock Write Block to EEPROM	1 <i>3</i> 1 <i>1</i>
		2.4 U_EE_WriteHI	
		Application Support Functions	
		3.1 U_debounce Debouncing	
		3.2 U_delMsgs Ignoring messages to the user	
		3.3 U_readAD Doing AD conversion	
		3.4 U_map Characterisation function	
		3.5 U GetAccess Get actual Access Level	
		3.6 U_SetPollingRsp Set Polling Response	
		PEI Support Functions	
	2.4 r 2.4		
		4.2 S_AstShift /S_LastShift Data-Block Exchange via Serial Synchronous	10
	۷.۰	PEI (PEI-Type 14 only)	20
	2	4.3 U_SerialShift Octet exchange via Serial PEI	20 20
		Finer Functions	
	2.5	= 6	
		5.2 TM_GetFlg Reading the Timer Status	
		5.3 U_SetTM Setting a User Timer	
		5.4 U_GetTM Reading the User Timer Status	
		5.5 U_Delay	
	2.5	5.6 BCU 2 Timer System	26

	2.5	5.6.1 U_TS_Set Set a BCU 2 Timer	26
	2.5	5.6.2 U_TS_Del Delete BCU 2 Timer	27
	2.5	5.6.3 U_TS_Seti Set Timer Interrupt Event	
	2.6 Mess	sage Handling Functions	28
	2.6.1	AllocBuf Buffer Allocation	
	2.6.2	FreeBuf Buffer Release	28
	2.6.3	PopBuf Message request	
	2.6.4	U_MS_Post Post Messages	
	2.6.5	U_MS_Switch Message redirection	
	2.7 Arith	nmetic Functions	
	2.7.1	multDE_FG Unsigned Integer Multiplication	31
	2.7.2	divDE_BC Unsigned Integer Division	32
	2.7.3	FP_Flt2Int Float to Integer	
	2.7.4	FP_Int2Flt Integer to Float	
	2.8 Misce	ellaneous Functions	
	2.8.1	shlAn Accu shift left n	33
	2.8.2	shrAn Accu shift right n	34
	2.8.3	rolAn Accu rotate Left	
	2.8.4	U_SetBit Bit write	35
	2.8.5	U_GetBit	35
	2.9 Loads	able PEI-Support	
	2.9.1	U_FT12_Reset Reset FT 1.2 Protocol	36
	2.9.2	U_FT12_GetStatus Get FT 1.2 Protocol Status	36
	2.9.3	U_SCI_Init Initialize Serial Communication Interface	37
	2.9.4	U_SPI_Init Initialize Serial Peripal Interface	
3	API for BI	IM M112	38
	3.1 Over	view	38
	3.2 Desci	ription of API functions	39
	3.2.1	API Function: _AL_isSapLinked	39
	3.2.2	API Function: _check	
	3.2.3	API Function: _copyMem	40
	3.2.4	API Function: _getAPIVersion	40
	3.2.5	API Function: _installCallback	
	3.2.6	API Function: _modulMode	41
	3.2.7	API Function: _MSG_allocBuffer	42
	3.2.8	API Function: _MSG_freeMessage	42
	3.2.9	API Function: _MSG_getMessage	43
	3.2.10	API Function: _MSG_postMessage	43
	3.2.11	API Function: _MSG_staticRedirection	44
	3.2.12	API Function: _PEI_addEvent	44
	3.2.13		44
	3.2.14	API Function: _PEI_analogueIn	
		<u> </u>	
	3.2.15	API Function: _PEI_binaryInOut	45
	3.2.15 3.2.16	API Function: _PEI_binaryInOutAPI Function: _PEI_getActualPeiType	45 45
		API Function: _PEI_binaryInOut	45 45 45
	3.2.16	API Function: _PEI_binaryInOut	45 45 45
	3.2.16 3.2.17	API Function: _PEI_binaryInOut	45 45 46 46
	3.2.16 3.2.17 3.2.18	API Function: _PEI_binaryInOut	
	3.2.16 3.2.17 3.2.18 3.2.19	API Function: _PEI_binaryInOut	

3.2.22	API Function: _PEI_rcvBufferWrite	48
3.2.23	API Function: _PEI_sendBufferRead	49
3.2.24	API Function: _PEI_sendBufferWrite	49
3.2.25	API Function: _PEI_sendByteSerial	49
	API Function: _PEI_setTimer	
3.2.27	API Function: _runRomModule	50
3.2.28	API Function: _setParam	51
3.2.29	API Function: _taskSwitch	52
3.2.30	API Function: _TM_getSystemTime	52
	API Function: _TM_getUserTicks	

### 1 Characteristics of BCU RAM and EEPROM Variables

# 1.1 API RAM Variables and RAM Space

#### 1.1.1 Registers B to N

The RAM area of 50h to 5Ch can be used as register memory space or as temporary RAM storage by the application programmer.

Attention: "registers" B to N may also be used by ROM functions or for parameter passing or as temporary variables. See description of API functions!

Registers can be used to store parameters for functions to be called.

Attention: Before the next complete execution of the user program all registers are cleared by the

system firmware.

# 1.1.2 Stack Space available for the Internal Application

Internal applications can use the microprocessors' stack for own purposes. Applications shall take care not to use more than the maximimum indicated stack space for the implementation. If an application uses more stack space, this can result in severe conflicts with the stack needs by the BCU firmware. The stack space is for the various implementations defined in [03].

# 1.1.3 Internal Application (i.e. "User") RAM

The internal application gets next to the processor's registers also processor RAM memory available. The proper size and organization of this RAM can be found in in [03].

# 1.2 API EEPROM Variables and EEPROM Space

# 1.2.1 Group Object Table pointer "CommsTabPtr" and "CommsTabPtr2"

CommsTabPtr is a one octet EEPROM variable. CommsTabPtr contains the octet offset to the location of the Group Object Table in EEPROM, if it is not zero. If CommsTabPtr is not zero then the Group Object Table starts at address 100h+[CommsTabPtr].

If CommsTabPtr is zero then the EEPROM variable CommsTabPtr2 exists which contains a Big Endian absolute pointer to the Group Object Table location.

#### 1.2.2 User Initialisation Routine pointer "UsrInitPtr" and "UsrIntiPtr2"

If CommsTabPtr is not zero then UsrInitPtr exists and contains the octet offset to the start address of the user initialisation routine in EEPROM. The initialisation routine starts at 100h+[UsrInitPtr].

If CommsTabPtr is zero then the EEPROM variable UsrInitPtr2 exists which contains a Big Endian absolute pointer to the start address of the user initialisation routine.

The initialisation routine is called once at the startup time of the internal user application. It must be written as a subroutine, i.e. it must be terminated by "rts".

# 1.2.3 User Program Pointer "UsrPrgPtr" and "UsrPrgPtr2"

If CommsTabPtr is not zero then UsrPrgPtr exists and contains the octet offset to the start address of the internal user application program in EEPROM. Then the internal user application program starts at 100h+[UsrPrgPtr].

If CommsTabPtr is zero then the EEPROM variable UsrPrgPtr2 exists which contains a Big Endian absolute pointer to the start address of the internal user application program.

This routine is called periodically if the BCU is in normal operation mode and the PEI type expected is equal to the PEI adaptor's PEI type measured by the A/D converter of the BCU.

This routine must be written as a subroutine, i.e. it must be terminated by "rts".

#### 1.2.4 User Save Routine Pointer "UsrSavPtr" and "UsrSavPtr2"

If CommsTabPtr is not zero then UsrSavPtr exists and contains the octet offset to the start address of the user save routine in EEPROM. The user save routine starts at 100h+[UsrSavPtr].

If CommsTabPtr is zero then the EEPROM variable UsrSavPtr2 exists which contains a Big Endian absolute pointer to the start address of the user save routine.

This routine is called if a bus power loss is detected at a bus-powered device and the internal user application program is not inactivated.

After calling this routine the BCU is reset. Nonetheless this routine must be written as a subroutine, i.e. it must be terminated by "rts".

# 1.2.5 Internal User Application (i.e. "user") EEPROM space

This is the EEPROM space usable by the internal user application program and the optional application programmer-written PEI driver for PEI 10.

Size: see [03].

#### 1.3 API Tables

# 1.3.1 OR\_TAB

Symbol: **OR\_TAB** 

Address: Mask 0010h: 0020h

Mask 0011h: 0020h Mask 0020h: 0020h Mask 1013h: 0020h

OR TAB

Addr. (hex)	Value (binary)
20	0000 0001
21	0000 0010
22	0000 0100
23	0000 1000
24	0001 0000
25	0010 0000
26	0100 0000
27	1000 0000

# **1.3.2 AND\_TAB**

Symbol: AND\_TAB

Address: Mask 0010h: 0028h

Mask 0011h: 0028h Mask 0020h: 0028h Mask 1013h: 0028h

AND\_TAB

Addr.(hex)	Value (binary)
28	1111 1110
29	1111 1101

2A	1111 1011
2B	1111 0111
2C	1110 1111
2D	1101 1111
2E	1011 1111
2F	0111 1111

Both tables are helpfull for masking-operation. If you need a value of these tables, you need only a one-octet-offset. This is helpfull for loops.

#### **Example**

	ldx	#AND_TAB	;ptr to AND_TAB
loop	lda		
	and	,Х	;MASK-operation
	sta		
:			
	incx		
	bra	loop	

# 1.4 System Timer

There are 4 software-timers: 0 to 3.

The timers 0 and 1 are reserved for the system software.

The timers 2 and 3 are available to the user.

The timer 2 is also used by the debounce-function. Do not use it a second time, if debouncing is used.

A timer can be used in one of two operation modes.

In operation mode, 0 a timer is initialized with a run-time. If this time is expired, then this is flagged. The timer may be restarted during operation.

In operation mode 1, the timer calculates the time since the last call to the timer function. The user must take care to avoid range overflows.

A timer has a resolution of 8 bits. It can be operated in five different time-ranges. E.g. a timer-value of 5 in time-range 2 means about 40 ms.

Range	Time-Unit		
1	± 0,55 ms		
2	± 8,0 ms		
3	± 130 ms		
4	± 2,1 s		
5	± 33 s		

NOTE A not-initialized timer has the status of an expired timer.

#### 1.5 User Timer

There is another set of support routines that can be used to define additional User timers.

Each pair of User-Timers can have a different time base. But each timer must be updated at least one time per timer-tick in its own time base.

A description-block in EEPROM is used to describe the User timers. Each User timer function needs a pointer to this description block.

The structure of the EEPROM description block is:

Offset in block	Length (octets)	Meaning
0	1	Pointer to RAM-data
1	1	Time base 1) 0 and 1
2	1	Time base 2 and 3

Time bases:

Number	Minimu	m Time	Resolution
0	ca.	130	ms
1	ca.	260	ms
2	ca.	520	ms
3	ca.	1,0	S
4	ca.	2,1	S
5	ca.	4,2	S
6	ca.	8,4	S
7	ca.	17	S
8	ca.	34	S
9	ca.	1,1	min
10	ca.	2,2	min
11	ca.	4,5	min
12	ca.	9,0	min
13	ca.	18	min
14	ca.	35	min
15	ca.	1,2	h

For each user timer, one octet must be reserved in RAM. All of these octets must by allocated in one block. The first octet in this block corresponds with the first user timer, the second octet corresponds with the second user timer and so on. The bit 7 in each octet is reserved, the bits 0-6 is used for the timer value (0 to 127). This value will be decremented only if you use the (update function) U\_GetTM. You can set the user timer if you use the function U\_SetTM, or you can load the corresponding RAM directly with the value. The bit7 must be 0.

<sup>1)</sup> In the mask-version 1.0 only the low nibble is evaluated. It serves as the time base for both timers.

# 2 API Function Reference

The API function reference lists all the API functions that support the task of the programmer of the internal user application. The interface to the functions is a pure assembler interface. If you want to interface at e.g. C language level then you must write your own interface adaptations (header files).

The estimated value given for "Watchdog-time" is an indication of how much watchdog-time this routine needs for processing. I.e. processing-time since latest triggering of watchdog (inside that routine).

This value is necessary to estimate when the watchdog must be triggered.

# 2.1 Group Object Manipulation Functions

### 2.1.1 U\_flagsGet Reading RAM Flags

Symbol: U\_flagsGet

Description: gets the RAM-flags of the specified Group Object.

Inputs: A = Group Object number

	Call Address	Outputs	Changed Registers
Mask 0010h	0C8Ch	See below	A, X, RegC, RegJ
Mask 0011h	0C9Dh	See below	A, X, RegC, RegJ
Mask 0012h	0C9Dh	See below	A, X, RegC, RegJ
Mask 0020h	505Ah	See below	A, X, RegC, RegJ
Mask 1013h	3D14h	See below	A, X, RegJ RegA = RAM-flags

Watchdog-time: (to be completed) us

Outputs: RegB

Bit #	7	6	5	4	3	2	1	0
Meaning	undefined Mask 1013h: zero			update flag	data request flag	transn sta	nission tus	

# 2.1.2 U\_flagsSet Writing RAM flags

Symbol: U\_flagsSet

Description: sets the RAM-flags of the specified Group Object.

Inputs: A = Group Object number

RegB = RAM-flags

Bit #	7	6	5	4	3	2	1	0
Meaning	undefined		update flag	data request flag	transmiss	sion status		

	Call Address	Outputs	Changed Registers
Mask 0010h	0C94h	None	A, X, RegB, RegC, RegJ
Mask 0011h	0CB3h	None	A, X, RegB, RegC, RegJ
Mask 0012h	0CB3h	None	A, X, RegB, RegC, RegJ
Mask 0020h	505Dh	None	A, X, RegB, RegC, RegJ
Mask 1013h	3D11h	None	A, X, RegB, RegJ

Watchdog-time: (to be completed) µs

# 2.1.3 U\_testObj Testing RAM flags

Symbol: U\_testObj

Description: fetches the RAM-flags from the specified object and resets the Update-flag.

Inputs: A = Group Object number

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	0CA5h		A, X, RegB, RegC, RegJ
Mask 0012h	0CA5h		A, X, RegB, RegC, RegJ
Mask 0020h	507Bh		A, X, RegB, RegC, RegJ
Mask 1013h	3D17h		A, X, RegJ

Watchdog-time: (to be completed) µs

Outputs: RegC = RAM-flags (right adjusted)

Zero-flag = NOT Update-flag

# 2.1.4 U\_transRequest Setting Transmit Request

Symbol: U\_transRequest

Description: sets a transmit-request in the specified Group Object. If a telegram is being currently

transmitted for this object then the transmit-request is not set.

Inputs: A = Group Object number

	Call Address	Outputs	Changed Registers
Mask 0010h	0D91h		A, X, RegB, RegC, RegJ
Mask 0011h	0DB9h		A, X, RegB, RegC, RegJ
Mask 0012h	0DB9h		A, X, RegB, RegC, RegJ
Mask 0020h	507Eh		A, X, RegB, RegC, RegJ
Mask 1013h	3D0Eh		A, X, RegJ

Watchdog-time: (to be completed) µs

Outputs: Carry

0 = OK

1 = transmit-request not set

#### Note

• Mask 1013h: Due to a slower bus-transmission speed its strongly recommended to evaluate the

return value of this function. Changing the object value while transmission-request is

set may cause unpredictable telegrams on the bus.

#### 2.1.5 Standard Callback

Symbol: AL\_SAPcallback

Description: Complete handling of Group Objects and Application Interface Objects

Inputs: X Index to message

Carry 0 : Polling mode: call one time in a cycle

1 : Message mode: call if a message for an object is received either a Group Object

or a Interface Object (SAP = FFh)

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	-	-	-
Mask 0012h	-	-	-
Mask 0020h	5081h	See below	A, X, RegB -RegN
Mask 0021h	5081h	See below	A, X, RegB -RegN
Mask 1013h	-	-	-

Watchdog-time: (to be completed)  $\mu$ s Outputs: X Index to message

A state

0 Ok (Return messagebuffer to system)

1 break and free buffer

2 hold buffer and break

3 send message and break

#### Example

KNXMSG\_ASAP EQU 24

; the offset of the ASAP in the message buffer

AppCallBack

bcc Nomsg

\* Message received

lda KNXMSG\_ASAP,x Load SAP number

cmp #SPECIAL\_SAP

bne STDcallback

\*handle special SAP

...

STDcallback

sec ;mark message

Nomsg jmp AL\_SAPcallback ;Use standard callback

# 2.2 EEPROM Manipulation Support Functions

# 2.2.1 Eewrite Writing to EEPROM

Symbol: **EEwrite** 

Description: writes an octet to the specified location in memory.

The write operation takes up to 20ms. Attention: Update checksum if necessary!

Inputs: A =value to write

X = offset in EEPROM

	Call Address	Outputs	Changed Registers
Mask 0010h	0C2Dh	None	RegB, RegC, RegH
Mask 0011h	0C38h	None	RegB, RegC, RegH
Mask 0012h	0C38h	None	RegB, RegC, RegH
Mask 0020h	503Fh	None	RegB, RegC, RegH
Mask 1013h	3D08h	None	RegB, RegC, RegH

Watchdog-time: internally set by function

# 2.2.2 EEsetChecksum Updating the checksum

Symbol: **EEsetChecksum** 

Description: updates the checksum octet of the EEPROM. This function must be called if any octet

inside the check range is modified by the user.

Inputs: None

	Call Address	Outputs	Changed Registers
Mask 0010h	0C5Dh	None	A, X, RegB, RegC, RegH
Mask 0011h	0C68h	None	A, X, RegB, RegC, RegH
Mask 0012h	0C68h	None	A, X, RegB, RegC, RegH
Mask 0020h	503Ch	None	A, X, RegB, RegC, RegH
Mask 1013h	3D05h	None	A, X, RegB, RegC, RegH

Watchdog-time: internally set by function

### 2.2.3 U\_EE\_WriteBlock Write Block to EEPROM

Symbol: U\_EE\_WriteBlock

Description: Write a block of 4 octets to the EEPROM

Inputs RegH:RegI Memory Address

RegK,RegL,RegM,RegN Memory Block to write

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	-	-	-
Mask 0012h	-	-	-
Mask 0020h	5099h	None	A, X, RegB, RegC, RegJ
Mask 0021h	5099h	None	A, X, RegB, RegC, RegJ
Mask 1013h	-	-	-

Watchdog-time: internally set by function µs

### 2.2.4 U\_EE\_WriteHI

Symbol: U\_EE\_WriteHI

Description: Write one octet to the EEPROM.

Inputs RegH:RegI Memory Address

A Octet to write

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	-	-	-
Mask 0012h	-	-	-
Mask 0020h	-	-	-
Mask 0021h	50B2h	None	A, X, RegB, RegG, RegJ
Mask 1013h	-	-	-

Watchdog-time: internally set by function µs

# 2.3 Application Support Functions

### 2.3.1 U\_debounce Debouncing

Symbol: **U\_debounce** 

Description: debounces a complete octet. As long as the debounce-time is not yet expired or the

value is changing the latest debounced value is returned.

• Mask 00xx: UserRAM = last input value

UserRAM+1 = debounced value

*Note:* It is not necessary to initialize the software timer 2.

• Mask 10xx: UserRAM1 = last input value

UserRAM1+1 = debounced value

*Note:* It is not necessary to initialize the system-timer #2.

Inputs: A = value (octet) to debounce

X = debounce-time in 0.5 ms-units

	Call Address	Outputs	Changed Registers
Mask 0010h	0C64h	See below	X, RegB, RegC, RegD, RegE, RegF, RegG
Mask 0011h	0C75h	See below	X, RegB, RegC, RegD, RegE, RegF, RegG
Mask 0012h	0C75h	See below	X, RegB, RegC, RegD, RegE, RegF, RegG
Mask 0020h	C5051h	See below	X, RegB, RegC, RegD, RegE, RegF, RegG
Mask 1013h	3D26h	See below	X, RegB, RegC, RegD, RegE, RegF, RegG

Watchdog-time: (to be completed) µs

Outputs: A = debounced value (octet)

Effects:

• Mask 00xx uses software-timer 2

changed RAM-locations: UserRAM, UserRAM + 1

• Mask 10xx uses system-timer #2

changed RAM-locations: UserRAM1, UserRAM1 + 1

Symbol: U\_deb10

Description: This function is the same as U\_debounce except that a fixed debounce-time of 10 ms

is used. Therefore the X register has not to be loaded.

Inputs: A = value (octet) to debounce

	Call Address	Outputs	Changed Registers
Mask 0010h	-		
Mask 0011h	0C73h	See U_debounce	See U_debounce
Mask 0012h	0C73h	See U_debounce	See U_debounce
Mask 0020h	504Bh	See U_debounce	See U_debounce
Mask 1013h	3D23h	See U_debounce	See U_debounce

Symbol: U\_deb30

Description: This function is the same as U\_debounce except that a fixed debounce-time of 30 ms

is used.

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	0C6Fh	See U_debounce	See U_debounce
Mask 0012h	0C6Fh	See U_debounce	See U_debounce
Mask 0020h	504Eh	See U_debounce	See U_debounce
Mask 1013h	3D20h	See U_debounce	See U_debounce

# 2.3.2 U\_delMsgs Ignoring messages to the user

Symbol: **U\_delMsgs**<sup>2</sup>

Description: removes any messages addressed to the user program. Call this function in the USER

main routine, if you do not expect any messages. Otherwise the buffer resources in the

BCU may become exhausted due to external faults.

Inputs: None

	Call Address	Outputs	Changed Registers
Mask 0010h	0C82h	None	A, X, RegB
Mask 0011h	0C93h	None	A, X, RegB
Mask 0012h	0C93h	None	A, X, RegB
Mask 0020h	5057h	None	A, X, RegB
Mask 1013h	3D89h	None	A, X, RegB

Watchdog-time: (to be completed) µs

# 2.3.3 U\_readAD Doing AD conversion

Symbol: U\_readAD

Description: starts A/D conversion for the specified port (not necessarily a PEI I/O port!) and reads

the result. This operation is repeated the specified number of times. The sum of the

values of all read operations is returned.

Note: This function is valid for A/D conversion of any analog port values in the bus access

module, no matter whether the port line is connected to a PEI input line.

Inputs: A =channel number of analog port

X = number of read operations

	Call Address	Outputs	Changed Registers
Mask 0010h	0D35h	See below	A, X
Mask 0011h 0D54h See below		See below	A, X
Mask 0012h	0D54h	See below	A, X
Mask 0020h	Mask 0020h 506Ch See below		A, X
Mask 1013h	3D38h	See below A = value of last AD- conversion	A, X

Watchdog-time: (to be completed) µs

Outputs: RegD:RegE = sum of read values. Precision is implementation-specific.

Note:

• Mask 1013h: If only one AD-conversion was requested the contents of the Accu is identical

with the contents of RegD:RegE

### 2.3.4 U\_map Characterisation function

Symbol: U\_map

The same effect as calling this function can be achieved, for the mask-version 0011h and upward, and the masks 0021h and 0022h, if bit 7 in the EEPROM-parameter RouteCnt is set.


Description:

maps the input value by the use of a conversion table. Input value and result are 16-bit signed integer numbers and cover all 4 quadrants. For the conversion a table of x-y-value pairs is used. The input value must be inside the x-value range. For values in between two x-y-value pairs linear interpolation is used.

The interpolation-formula used is:

$$Y = [(X-X1)*(Y2-Y1)]/(X2-X1) + Y1$$

All intermediate results must not exceed the signed integer value range.



The conversion table is assumed to be in EEPROM and has the following format: (x-values in ascending order, LSOctet is the high octet).

Length (x-y-pair count) (1 octet)				
X0	Y0			
X1	Y1			

low word

high word

Inputs:

RegB:RegC = value to be mapped (signed integer) X = pointer to conversion table (EEPROM-offset)

	Call Address	Outputs	Changed Registers
Mask 0010h	0C9Bh	See below	A, X, RegD, RegE, RegF, RegG, RegH, RegI
Mask 0011h	0CBAh	See below	A, X, RegD, RegE, RegF, RegG, RegH, RegI
Mask 0012h	0CBAh	See below	A, X, RegD, RegE, RegF, RegG, RegH, RegI
Mask 0020h	5069h	See below	A, X, RegD, RegE, RegF, RegG, RegH, RegI
Mask 1013h	3D86h	See below	A, X, RegD, RegE, RegF, RegG, RegH, RegI

Watchdog-time: (to be completed) µs

Outputs: RegB:RegC = result (signed integer)

Carry = 0 OK

1 conversion error, result not valid

Note:

• Masks 0010h, 0011h: These mask versions only operate in the first quadrant!

#### **Get actual Access Level** 2.3.5 **U\_GetAccess**

Symbol: **U** GetAccess

Description: gets the actual accesslevel of the system

Inputs None

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	-	-	-
Mask 0012h	-	-	-
Mask 0020h	5096h	A = Accesslevel	None
Mask 0021h	5096h	A = Accesslevel	None
Mask 1013h	-	-	-

Watchdog-time: (to be completed) µs

#### 2.3.6 **U\_SetPollingRsp Set Polling Response**

U\_SetPollingRsp Symbol:

Set the value to response at poll request. Description:

Inputs Value to response

Reserved Values

FFh No user running / not set from user

F0h-Fdh Reserved

FEh Fill character no slave responding

00h Set at Userstartup

1: Systemstate Bit 7

0: Userstate

Bit 6 Error Bit 5 Alarm Bit 4 Reseverd Bit 0-3: Usercode

For more informations please refer to [02].

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	-	-	-
Mask 0012h	-	-	-
Mask 0020h	50AEh	None	None
Mask 0021h	50AEh	None	None
Mask 1013h	-	-	-

#### **PEI Support Functions** 2.4

#### $U\_ioAST$ 2.4.1 **Binary Port Access**

Symbol: U\_ioAST Description:

Digital ports can be accessed by the function U\_ioAST that allows reading and/or writing digital I/O pins 1 to 4. Reading or writing can be selected for each PEI I/O line via I/O flags. Accumulator and RegB serve as parameters for U\_ioAST.

Via I/O-flags reading or writing can be selected for each bit/pin. For both input and output the bits are mapped to the PEI-port as follows:

I/O-Bit #	Input # or Output #	PEI-Pin
0	1	3
1	2	2
2	3	4
3	4	7

Encoding of read / write bits:

0 means off, i.e. 0 V

1 means on, i.e. 5 VDC

Inputs:

Accumulator: for I/O flags and values

bit #	7	6	5	4	3	2	1	0
meaning	I/0-flags 0 = read 1 = write				(val	ite bit id on ected bi	ly if w I for t	/rite
I/O bit #	3	2	1	0	3	2	1	0

	Call Address	Outputs	Changed Registers
Mask 0010h	0DA7h	See below	A, X, RegB, RegC, RegD
Mask 0011h	0DCFh	See below	A, X, RegB, RegC, RegD
Mask 0012h	0DCFh	See below	A, X, RegB, RegC, RegD
Mask 0020h	5066h	See below	A, X, RegB, RegC, RegD
Mask 1013h	3D35h	See below	A, X, RegB, RegC

Watchdog-time:

(to be completed) µs

Outputs:

RegB: for bit values to be read

bit #	7	6	5	4	3	2	1	0
meaning	_		es of ead/w		(va	ad bit ilid on cted f	ly if re	ad
I/O bit #	3	2	1	0	3	2	1	0

Note:

Digital Input Value Sampling

Digital input value sampling must be done in the internal user application program with the help of several calls of U\_ioAST. This means, that the sampling rate per time unit and debouncing is left to the user application programmer.

# 2.4.2 S\_AstShift/S\_LastShift Data-Block Exchange via Serial Synchronous PEI

(PEI-Type 14 only)

Symbol: S\_AstShift / S\_LastShift

Description: The specified data block is exchanged via the serial PEI-interface. The synchronous

protocol, that runs at PEI type 14, and the data block format are described in [01] of

these KNX Specifications.

The function "S\_AstShift" uses a ca. 130 ms timeout and the function "S\_LAstShift" uses a ca. 1 s timeout. I.e. the data block exchange must be completed within these

timeout times.

The data format is shown below:

Message length in octets (1 octet) data

Inputs: X = pointer to data block

	Call Address		Outputs	Changed Registers
	S_AstShift S_LAstShift			
Mask 0010h	1103h	1101h	See below	A, RegB, RegC, RegD, RegE, RegF, RegG, RegH, RegI
Mask 0011h	1117h	1115h	See below	A, RegB, RegC, RegD, RegE, RegF, RegG, RegH, RegI
Mask 0012h	1117h	1115h	See below	A, RegB, RegC, RegD, RegE, RegF, RegG, RegH, RegI
Mask 0020h	5042h	5045h	See below	A, RegB, RegC, RegD, RegE, RegF, RegG, RegH, RegI
Mask 1013h	3D3Eh	3D3Bh	See below	A, RegB, RegC, RegD, RegE, RegF, RegG, RegH, RegI

Outputs: X = pointer to data block (contains response)

Carry: 0 = communication Ok 1 = communication failed

Note: When using the serial interface, it is very important to change the "own" handshake

signal not before the end of the stop bit. Otherwise, the transmission will fail.

### 2.4.3 U\_SerialShift Octet exchange via Serial PEI

Symbol: U\_SerialShift

Description: The specified octet is exchanged via the serial PEI-interface. The function

U\_SerialShift" uses a ca. 130 ms-timeout. I.e. the octet-exchange must be completed

within the timeout-time.

Inputs: A = Octet to be transferred

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	-	-	-
Mask 0012h	0C90h	See below	A, RegB, RegC, RegD, RegE, RegF, RegG,RegI
Mask 0020h	5048h	See below	A, RegB, RegC, RegD, RegE, RegF, RegG,RegI
Mask 1013h	3D41h	See below	A, RegB, RegC, RegD, RegE, RegF, RegG,RegH

Watchdog-time: (to be completed)  $\mu$ s

Outputs: A = received octet

Carry = 0 : communication O.K.

Note: Important Remarks to the functions S\_AstShift, S\_LastShift and U\_SerialShift

1. These functions may only be used in combination with PEI-type 14.

2. Long wait times may cause serious problems on the bus (busy-acknowledges).

# 2.4.4 U\_Char\_Out SPI/SCI Interface

Symbol: U\_Char\_Out

Description: The specified octet is exchanged via the serial SPI/SCI PEI interface (depends on

PEI-type).

no timeout

• no flow control activ (RTS/CTS handling)

• use %SyncRate for SPI/U\_SCI\_Init for SCI baudrate (if not, 9600 baud is preselected on the SCI by the system initialisation)

• 8 and 9 databits are possible

Inputs: A = octet to be transferred

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	-	-	-
Mask 0012h	-	-	-
Mask 0020h	508Ah	-	X (if 9 databits are used)
Mask 0021h	508Ah	-	X (if 9 databits are used)
Mask 1013h	-	-	-

Watchdog-time: (to be completed) µs

### 2.5 Timer Functions

# 2.5.1 TM\_Load Starting the timer

Symbol: TM\_Load

Description: The specified timer is initialized with operation mode and time-range.

In addition, in operation mode 0 the run-time is set and the timer is started.

Inputs: A = (see below)

X = run-time (operation mode 0 only)

Input in A:

• Mask 0010h, 0011h, 0012h, 0020h:

Bit #	7	6	5	4	3	2	1	0
Meaning	must	be 0	time	er#	operation mode	tim	ner ran	ge

Mask 1013h:

Bit #	7	6	5	4	3	2	1	0
Meaning		time	er#		operation mode	tim	ner ran	ge

	Call Address	Outputs	Changed Registers
Mask 0010h	0E0Ch	None	A, X, RegB, RegC, RegD, RegE, RegF
Mask 0011h	0E2Bh	None	A, X, RegB, RegC, RegD, RegE, RegF
Mask 0012h	0E2Bh	None	A, X, RegB, RegC, RegD, RegE, RegF
Mask 0020h	5039h	None	A, X, RegB, RegC, RegD, RegE, RegF
Mask 1013h	3D1Ah	None	A, X, RegB, RegC, RegD, RegE, RegF

Watchdog-time: (to be completed) µs

# 2.5.2 TM\_GetFlg Reading the Timer Status

Symbol: TM\_GetFlg

Description: The timer-status is returned.

In operation mode 0, it returns if the run-time is expired.

In operation mode 1, the time since the last call to this function is returned.

Inputs: A = timer number

	Call Address	Outputs	Changed Registers
Mask 0010h	0E2Ah		A, X, RegB, RegC, RegD, RegE
Mask 0011h	0E49h		A, X, RegB, RegC, RegD, RegE
Mask 0012h	0E49h		A, X, RegB, RegC, RegD, RegE
Mask 0020h	5036h		A, X, RegB, RegC, RegD, RegE
Mask 1013h	3D1Dh		A, X, RegB, RegC, RegD, RegE

Watchdog-time: (to be completed) µs

Outputs:

Operation Mode 0	Operation Mode 1
Carry = 0 time not yet expired 1 time expired	A = time since the last call

# 2.5.3 U\_SetTM Setting a User Timer

Symbol: U\_SetTM

Description: loads a User-Timer.

Inputs:

• Mask 0010h, 0011h, 0012h, 0020h:

A = user-timer number

X = pointer to EEPROM description block

RegE = time to be set

#### • Mask 1013h:

#### A = See table below

Bit #	7	6	5	4	3	2	1	0
	Location of timer-RAM- block 0 = UserRAM1 1 = UserRAM2			User-'	Timer n	umber		

X = pointer to EEPROM-description-block

RegE = (see below)

Bit #	#	7	6	5	4	3	2	1	0
Meani	ng	not evaluated			tin	ne to be	set		

	Call Address	Outputs	Changed Registers
Mask 0010h	0D8Ah	None	A, X, RegB, RegC, RegD
Mask 0011h	0DB3h	None	A, X, RegB, RegC, RegD
Mask 0012h	0DB3h	None	A, X, RegB, RegC, RegD
Mask 0020h	506Fh	None	A, X, RegB, RegC, RegD
Mask 1013h	3D32h	None	A, X RegE if Bit #7 is set

Watchdog-time: (to be completed) µs

Symbol: U\_SetTMx

Description: This function is the same as U\_SetTM except that the pointer to the pointer to

EEPROM description block is fetched from the octet directly before the user main

program.

Inputs: See U\_SetTM

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	0DAFh	See U_SetTM	See U_SetTM
Mask 0012h	0DAFh	See U_SetTM	See U_SetTM
Mask 0020h	5072h	See U_SetTM	See U_SetTM
Mask 1013h	3D2Fh	See U_SetTM	See U_SetTM

Watchdog-time: (to be completed) µs

Note: If you load the timer with the timer value 0, the timer is always expired. If you load

the timer with 1, the timer can be immediately expired, because the timer tolerance is one timer tick. If you load the timer with a value >127, the bit 7 will be ignored.

# 2.5.4 U\_GetTM Reading the User Timer Status

Symbol: U GetTM

Description: gets the status of a user timer. This function is the only function that updates this

(specified) timer.

Inputs:

• Mask 0010h, 0011h, 0012h, 0020h:

A = user-timer number

X = pointer to EEPROM-description-block

• Mask 1013h:

A = See table below

X = pointer to EEPROM-description-block

Bit #	7	6	5	4	3	2	1	0
Meaning	Location of timer-RAM- block 0 = UserRAM1 1 = UserRAM2			User-'	Timer n	umber		

	Call Address	Outputs	Changed Registers
Mask 0010h	0D4Dh	See below	A, X, RegB, RegC, RegD
Mask 0011h	0D71h	See below	A, X, RegB, RegC, RegD
Mask 0012h	0D71h	See below	A, X, RegB, RegC, RegD
Mask 0020h	5060h	See below	A, X, RegB, RegC, RegD
Mask 1013h	3D2Ch	See below	A, X, RegB, RegC, RegD

Watchdog-time: (to be completed) µs

Outputs: Zero-Flag = 0 timer not yet expired

1 timer expired

Note: Periodically update the User-Timer. Otherwise some "timer-ticks" may be lost.

Symbol: U\_GetTMx

Description: This function is the same as U\_GetTM, except that the pointer to the pointer to

EEPROM description block is fetched from the octet directly before the user main

program.

Inputs: See U\_GetTM

	Call Address	Outputs	Changed Registers
Mask 0010h	-		-
Mask 0011h	0D6Ch	See U_GetTM	See U_GetTM
Mask 0012h	0D6Ch	See U_GetTM	See U_GetTM
Mask 0020h	5063h	See U_GetTM	See U_GetTM
Mask 1013h	3D29h	See U_GetTM	See U_GetTM

### 2.5.5 **U\_Delay**

Symbol: U\_Delay Delay

Description: waits the specified amount of time.

The delay is based upon the internal hardware-timer.

Inputs: A = delay time in 0.5 ms

Note: No delay times above 15 ms should be used.

	Call Address	Outputs	Changed Registers
Mask 0010h	0DDBh	None	A, X, RegB
Mask 0011h	0DFAh	None	A, X, RegB
Mask 0012h	0DFAh	None	A, X, RegB
Mask 0020h	5054h	None	A, X, RegB
Mask 1013h	3D02h	None	A, X, RegB

Watchdog-time: triggers watchdog internally

Th example below shows how a delay can be implemented using the user timers.

RAM-Data:

UsrTmr0 DS 1

**EEPROM-Data:** 

UsrTmr DB LowOctet(UsrTmr0)

DB 0 ; time base = 130ms

**Code:** 

... other code ...

; start of timer

lda #10

sta RegE ; time = 1.3 sec

lda#0 ;user-timer 0

ldx #LowOctet(UsrTmr);ptr to description

jsr U\_SetTM

... other code ...

; or other way to start a timer

lda #10 sta UsrTmr0

; check of timer status

lda #0 ; user-timer 0 ldx #LowOctet(UsrTmr); ptr to description

jsr U\_GetTM

beq ; branch if timer

; expired

... other code ... Message handling functions

# 2.5.6 BCU 2 Timer System

For the interpretation of the following 3 API-functions U\_TS\_Set, U\_TS\_Del and U\_TS\_Seti, please refer to the system implementation descriptions in [03].

The BCU 2 has a maximum of 3 system timers (1 to 3) available for the user. If a serial protocol is active it will use timer 1. If the U\_debounce function is used, it will use timer 2.

The following modes and scales are possible:

#### Modes

TS_TYPE_EVT	020h	Event only used with TS_Seti fixed scale of 6.6ms generates an event in PEI-driver event queue.
TS_TYPE_MSG	030h	Message generates a timerindication message
TS_TYPE_MSG_CYC	040h	Message cyclically generates a timerindication message
TS_TYPE_DOWN	050h	Down counter reserved for compatible function used with TM_Load
TS_TYPE_DIFF	060h	Difference counter reserved for compatible function used with TM Load

#### • Scales

TS_SCALE041MS	00h	0.416	ms
TS_SCALE6_6MS	02h	6.6	ms
TS_SCALE106S	04h	106	ms
TS_SCALE1_6S	06h	1,6	sec
TS_SCALE26S	08h	26	sec

#### • Cyclic Scales (only for type messagecyclic)

TS_100MS	04h	100	ms
TS_1SEC	08h	1	sec
TS_1MIN	0ch	1	min

#### 2.5.6.1 U\_TS\_Set Set a BCU 2 Timer

Symbol: U\_TS\_Set

Description: Set an BCU 2 Timer

X

RegD

Inputs

A	Timermode
RegB	Timer Scale / Cyclic Scale
RegC	TimerValue (not for Mode TS_TYPE_MSG_CYC)

TimerParameter (only Mode TS\_TYPE\_MSG)

Timernumber

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	-	-	-
Mask 0012h	-	-	-
Mask 0020h	5090h	None	A, X, RegB-RegF
Mask 0021h	5090h	None	A, X, RegB-RegF
Mask 1013h	-	-	-

Watchdog-time: (to be completed) µs

### 2.5.6.2 U\_TS\_Del Delete BCU 2 Timer

Symbol: U\_TS\_Del

Description: Delete Timer

Inputs: X Timer number

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	-	-	-
Mask 0012h	-	-	-
Mask 0020h	5093h	None	None
Mask 0021h	5093h	None	None
Mask 1013h	-	-	-

Watchdog-time: (to be completed) µs

# 2.5.6.3 U\_TS\_Seti Set Timer Interrupt Event

Symbol: U\_TS\_Seti

Description: Set BCU 2 Timer for Event Generation (only use in Interrupts)

Inputs:

X Timernumber

iRegD message queue ID or TS\_TYPE\_EVT

iRegC Timervalue

A Timer Parameter max. 6 bit

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	-	-	-
Mask 0012h	-	-	-
Mask 0020h	50ABh	None	None
Mask 0021h	50ABh	None	None
Mask 1013h	-	-	-

# 2.6 Message Handling Functions

### 2.6.1 AllocBuf Buffer Allocation

Symbol: AllocBuf

Description: allocates a message buffer.

Note: There is a distinction between long and short buffers. But non-system-software

requires only long buffers.

Inputs: Carry: = buffer type

0 = short buffer 1 = long buffer

	Call Address	Outputs	Changed Registers
Mask 0010h	116Ah	See below	A
Mask 0011h	117Eh	See below	A
Mask 0012h	117Eh	See below	A
Mask 0020h	5000h	See below	A
Mask 1013h	3D8Fh	See below	A

Watchdog-time: (to be completed)  $\mu$ s

Outputs: X = pointer to buffer

Carry = 1 buffer allocated

0 no buffer allocated (all buffers in use) (X invalid)

### 2.6.2 FreeBuf Buffer Release

Symbol: FreeBuf

Description: releases a previously allocated buffer.

Inputs: X = pointer to buffer

	Call Address	Outputs	Changed Registers
Mask 0010h	118Ch	None	A, X, RegB
Mask 0011h	11A0h	None	A, X, RegB
Mask 0012h	11A0h	None	A, X, RegB
Mask 0020h	5006h	None	A, X, RegB
Mask 1013h	3D8C	None	A, X, RegB

# 2.6.3 PopBuf Message request

Symbol: **PopBuf** 

Description: searches for a certain message type.

Inputs:

• Mask 0010h, 0011h, 0012h, 0020h:

A = message and buffer type

Bit #	7	6	5	4	3	2	1	0
Meaning	buffer type $0 = \text{short}$ $1 = \text{long}$	lay	er addr	ess		must	be 0	

#### • Mask 1013h:

A = message and buffer type

Bit #	7	6	5	4	3	2	1	0
Meaning	buffer type 0 = short 1 = long	lay	er addr	ress	requ	iested s	service	or 0

	Call Address	Outputs	Changed Registers
Mask 0010h	11ACh	See below	A, RegB
Mask 0011h	11C0h	See below	A, RegB
Mask 0012h	11C0h	See below	A, RegB
Mask 0020h	5003h	See below	A, RegB
Mask 1013h	3D92h	See below	A, RegB

Watchdog-time: (to be completed)  $\mu$ s Outputs: X = pointer to buffer

Carry = 1 = message found

0 = no such message (X invalid)

### 2.6.4 U\_MS\_Post Post Messages

Symbol: U\_MS\_Post

Description: Post the message pointed by X to the message queue A

Inputs:

X pointer to messageA message queue ID

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	-	-	-
Mask 0012h	-	-	-
Mask 0020h	508Dh	None	A, X, RegB, RegL, RegM, RegN
Mask 0021h	508Dh	None	A, X, RegB, RegL, RegM, RegN
Mask 1013h	-	-	-

Watchdog-time: (to be completed) µs

#### Example

...

jsr PopBuf ; get message from user queue bcc no\_message ; jump out if no message in queue lda #TASK\_PM\_ID ; load queue/task id from PEI

jsr U\_MS\_Post

... other code...

no\_message

; continued here if no messages to post

# 2.6.5 U\_MS\_Switch Message redirection

Symbol: U\_MS\_Switch

Description: redirects messages from one task to an other ,all messages posted to queue ID X now

posted to queue ID A.

Inputs:

X message queue ID to redirect

A new destination for queue X

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	-	-	-
Mask 0012h	-	-	-
Mask 0020h	508Ah	None	A, X, RegC
Mask 0021h	508Ah	None	A, X, RegC
Mask 1013h	-	-	-

#### **Example**

lda #TASK\_AL\_ID ;load queue/task id from applicationlayer
lda #TASK\_US\_ID ;load queue/task id from user
jsr U\_MS\_Switch ;now all messages for the applicationlayer
;are send to the user
;receive messages
;handle messages for application layer

clrx

clra

jsr U\_MS\_Switch ;reset all redirections

# 2.7 Arithmetic Functions

# 2.7.1 multDE\_FG Unsigned Integer Multiplication

Symbol: multDE\_FG

Description: multiplies the unsigned integer values in the registers RegD:RegE and RegF:RegG.

Inputs: RegD:RegE = factor

RegF:RegG = factor

	Call Address	Outputs	Changed Registers
Mask 0010h	0B3Ch	See below	A, X
Mask 0011h	0B4Bh	See below	A, X
Mask 0012h	0B4Bh	See below	A, X
Mask 0020h	5033h	See below	A, X
Mask 1013h	3D80h	See below	A, X

Watchdog-time: (to be completed)  $\mu$ s

Outputs: RegB:RegC = product

Carry = 0 ok

1 overflow

#### Note:

• Mask 1013h: In case of overflow the product is RegB:RegC = FFFFh.

# 2.7.2 divDE\_BC Unsigned Integer Division

Symbol: **divDE\_BC** 

Description: divides the unsigned integer value in the registers RegD:RegE by the unsigned integer

value in the registers RegB:RegC.

Inputs: RegD:RegE = dividend

RegB:RegC = divisor

	Call Address	Outputs	Changed Registers
Mask 0010h	0AFCh	See below	A, X, RegB, RegC
Mask 0011h	0B0Bh	See below	A, X, RegB, RegC
Mask 0012h	0B0Bh	See below	A, X, RegB, RegC
Mask 0020h	5030h	See below	A, X, RegB, RegC
Mask 1013h	3D83h	See below	A, X, RegB, RegC

Watchdog-time: (to be completed) µs

Outputs: RegF:RegG = quotient

RegD:RegE = remainder

Carry = 0 ok

1 divide by zero

# 2.7.3 FP\_Flt2Int Float to Integer

Symbol: FP\_Flt2Int

Description: Converts a 4 octet IEEE floatingpoint to 2 octet integer

Inputs:

X pointer to 32 bit float RegF offset to exponent

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	-	-	-
Mask 0012h	-	-	-
Mask 0020h	5087h	See below	A, X, RegD, RegE
Mask 0021h	5087h	See below	A, X, RegD, RegE
Mask 1013h	-	-	-

Watchdog-time: (to be completed) µs

Outputs RegB:RegC 2 octet integer

# 2.7.4 FP\_Int2Flt Integer to Float

Symbol: FP\_Int2Flt

Description: Converts an 2 octet integer to 4 octet IEEE floatingpoint

Inputs:

RegB:RegC 2 octet integer

X pointer to 32 bit float RegF offset to exponent

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	-	-	-
Mask 0012h	-	-	-
Mask 0020h	5084h	See below	A, X, RegD
Mask 0021h	5084h	See below	A, X, RegD
Mask 1013h	-	-	-

Watchdog-time: (to be completed) µs

Outputs 4 octet IEEE float at address X

# 2.8 Miscellaneous Functions

### 2.8.1 shlAn Accu shift left n

Symbol: shlAn

Description: shifts the accu left by n bits. The values possible for n are 4, 5, 6, and 7. The new bits

are set to zero.

Inputs: A = value

	Call Address				Outputs	Changed Registers
	shlA4	shlA5	shlA6	shlA7		
Mask 0010h	0B9Ah	0B99h	0B98h	0B97h	A = shifted value	None
Mask 0011h	0BA9h	0BA8h	0BA7h	0BA6h	A = shifted value	None
Mask 0012h	0BA9h	0BA8h	0BA7h	0BA6h	A = shifted value	None
Mask 0020h	5018h	501Bh	501Eh	5021h	A = shifted value	None
Mask 1013h	3D59h	3D5Ch	3D5Fh	3D62h	A = shifted value	None

# 2.8.2 shrAn Accu shift right n

Symbol: shrAn

Description: shifts the accu right by n bits. The values possible for n are 4, 5, 6, and 7. The new bits

are set to zero.

Inputs: A = value

		Call A	.ddress		Outputs	Changed Registers
	shrA4 shrA5 shrA6 shrA7			shrA7		
Mask 0010h	0BDAh	0BD9h	0BD8h	0BD7h	A = shifted value	None
Mask 0011h	0BE9h	0BE8h	0BE7h	0BE6h	A = shifted value	None
Mask 0012h	0BE9h	0BE8h	0BE7h	0BE6h	A = shifted value	None
Mask 0020h	5024h	5027h	502Ah	502Dh	A = shifted value	None
Mask 1013h	3D4Dh	3D50h	3D53h	3D56h	A = shifted value	None

Watchdog-time: (to be completed) µs

# 2.8.3 rolAn Accu rotate Left

Symbol: rolAn

Description: rotates the accu left by n bits. The values possible for n are 1, 2, 3, 4 and 7.

Inputs: A = value

	Call Address					Outputs	Changed Registers
	rolA1	rolA2	rolA3	rolA4	rolA7		
Mask 0010h	-	-	-	-	-	-	-
Mask 0011h	-	-	-	-	-	-	-
Mask 0012h	0AF4h	0AF2h	0AF0h	0AEEh	0AECh	A = rotated value	None
Mask 0020h	5009h	500Ch	500Fh	5012h	5015h	A = rotated value	None
Mask 1013h	3D77h	3D74h	3D71h	3D6Eh	3D6Bh	A = rotated value	None

# 2.8.4 U\_SetBit Bit write

Symbol: U\_SetBit

Description: sets the specified bit in register RegH.

Inputs: A = bit number

RegH = octet to modify Carry = bit value to set

	Call Address	Outputs	Changed Registers
Mask 0010h	0DF9h	A = RegH = modified octet	RegB
Mask 0011h	0E18h	A = RegH = modified octet	RegB
Mask 0012h	0E18h	A = RegH = modified octet	RegB
Mask 0020h	5078h	A = RegH = modified octet	RegB
Mask 1013h	3D47h	A = RegH = modified octet	RegB

Watchdog-time: (to be completed)  $\mu s$ 

# 2.8.5 U\_GetBit

Symbol: U\_GetBit

Description: reads the specified bit in register RegH.

Inputs: A = bit number

RegH = octet to be read from

	Call Address	Outputs	Changed Registers
Mask 0010h	0DEDh	See below	A, X, RegB
Mask 0011h	0E0Ch	See below	A, X, RegB
Mask 0012h	0E0Ch	See below	A, X, RegB
Mask 0020h	5075h	See below	A, X, RegB
Mask 1013h	3D44h	See below	A, RegB

Watchdog-time: (to be completed) µs

Outputs: Zero-flag = 0 if bit set

1 if bit clear

# 2.9 Loadable PEI-Support

# 2.9.1 U\_FT12\_Reset Reset FT 1.2 Protocol

Symbol: U\_FT12\_Reset

Description: Reset FT 1.2 protocol with specified baudrate

Inputs: A Baudrate

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	-	-	-
Mask 0012h	-	-	-
Mask 0020h	509Ch	None	A, X, RegB-RegN
Mask 0021h	509Ch	None	A, X, RegB-RegN
Mask 1013h	-	-	-

Watchdog-time: (to be completed) µs

### 2.9.2 U\_FT12\_GetStatus Get FT 1.2 Protocol Status

Symbol: U\_FT12\_GetStatus

Description: Gets the FT 1.2 Protocollstatus

Inputs: Carry 0 get status

l force status request

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	-	-	-
Mask 0012h	-	-	-
Mask 0020h	509Fh	See below	A
Mask 0021h	509Fh	See below	A
Mask 1013h	-	-	-

Watchdog-time: (to be completed) µs

Outputs: Carry = 0 no new State

 $\begin{array}{ll} Carry & = 1 & new \ state \\ A & = 0 & State \ OK \\ & \neq 0 & State \ not \ OK \end{array}$ 

### 2.9.3 U\_SCI\_Init Initialize Serial Communication Interface

Symbol: U\_SCI\_Init

Description: Initialize the SCI of the 68HC05BE12

(for Serial Asynchronous Communication)

(enable SCI-System, disable SPI-System, 8 databits, receiver enable, transmitter

enable configure PCMUX, set Baudrate)

Inputs A Baudrate

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	-	-	-
Mask 0012h	-	-	-
Mask 0020h	50A2h	None	A, X
Mask 0021h	50A2h	None	A, X
Mask 1013h	-	-	-

Watchdog-time: (to be completed) µs

# 2.9.4 U\_SPI\_Init Initialize Serial Peripal Interface

Symbol: U\_SPI\_Init

Description: Initialize the SPI of the 68HC05BE12

(for Serial Synchronous Communication)

(enable SPI-System, disable SCI-System, configure PCMUX, set baudrate from

EE\_SyncRate, CPOL and CPHA from EE\_ConfigDes)

Inputs None

	Call Address	Outputs	Changed Registers
Mask 0010h	-	-	-
Mask 0011h	-	-	-
Mask 0012h	-	-	-
Mask 0020h	50A5h	None	A, X
Mask 0021h	50A5h	None	A, X
Mask 1013h	-	-	-

Watchdog-time: (to be completed) µs

# 3 API for BIM M112

# 3.1 Overview

Function	Description	Clause			
Message handling					
_MSG_allocBuffer	allocates a message buffer	clause 3.2.7			
_MSG_freeMessage	releases a message buffer	clause 3.2.8			
_MSG_getMessage	retrieves a message from the message queue	clause 3.2.9			
_MSG_postMessage	posts an message to specified module	clause 3.2.10			
_MSG_staticRedirection	sets and returns a static redirection	clause 3.2.11			
Miscellaneous		0.0000 0.2			
_AL_isSapLinked	returns if a AL-SAP is linked via the Association Table	clause 3.2.1			
• _check	checks the system (or a part of it)	clause 3.2.2			
_copyMem	copies a block of memory	clause 3.2.3			
• _getAPIVersion	returns the version of the Application Programming Interface	clause 3.2.4			
_runRomModule	executes a ROM-system module referenced by the module ID	clause 3.2.27			
<ul><li>_setParam</li></ul>	sets the initial values of the maximum restart counters or the routing counter	clause 3.2.28			
PEI-IO					
_PEI_analogueIn	reads an analogue value from the PEI	clause 3.2.13			
<ul> <li>_PEI_binaryInOut</li> </ul>	reads from and writes to the binary PEI-ports	clause 3.2.14			
_PEI_sendByteSerial	sends one byte via the serial interface	clause 3.2.25			
PEI event queue					
<ul> <li>_PEI_addEvent</li> </ul>	adds one event to the PEI event queue	clause 3.2.12			
_PEI_getEvent	gets the oldest event	clause 3.2.16			
_PEI_initEventQueue	initialises the event queue of the PEI.	clause 3.2.20			
PEI buffer		-			
_PEI_getFreeBufferSpace	return the free space of the PEI buffers	clause 3.2.17			
_PEI_initBuffer	initialises the PEI receive and send buffers	clause 3.2.19			
_PEI_rcvBufferRead	reads byte(s) from the PEI-receive buffer	clause 3.2.21			
_PEI_rcvBufferWrite	writes byte(s) to the PEI-receive buffer	clause 3.2.22			
_PEI_sendBufferRead	reads byte(s) from the PEI-send buffer	clause 3.2.23			
_PEI_sendBufferWrite	writes byte(s) to the PEI-send buffer	clause 3.2.24			
PEI (miscellaneous)					
_PEI_getActualPeiType	returns the value of the actual PEI-type	clause 3.2.15			

551.1.11	1.20 -Para dia DEL	.1 0.040			
_PEI_init	initialises the PEI	clause 3.2.18			
_PEI_setTimer	start/stop the PEI-timer	clause 3.2.26			
Timer					
_TM_getSystemTime	returns the system counter	clause 3.2.30			
_TM_getUserTicks	returns the 25ms-time	clause 3.2.31			
Scheduler					
_installCallback	installs the call-back function	clause 3.2.5			
_modulMode	changes the state of a module and returns the actual state	clause 3.2.6			
_taskSwitch	enables or disables task-switching	clause 3.2.29			

### 3.2 Description of API functions

#### 3.2.1 API Function: \_AL\_isSapLinked

Description: returns if a AL-SAP is linked via the Association Table. The function searches for

the first entry in the Association Table with a matching ASAP number.

Inputs: B ASAP number

Outputs: Carry 0 link exists

1 not linked

Changed Registers: CCR, A, Y

Call Address: FFA7h

There is no example for this topic.

May be used in: □ call-backs □ interrupts

Task switch: □ must be disabled

#### 3.2.2 API Function: \_check

Description: checks the CRCs of all memory blocks of the given owner.

Inputs: B owner number

0 system1 address table2 Association Table

3 application program (user)

4 PEI program

Outputs: Carry 0 OK

1 CRC error

Changed Registers: CCR, A, B, X, Y

Call Address: FFC8h

May be used in:  $\Box$  call-backs  $\Box$  interrupts

#### **KNX Standard**

# 3.2.3 API Function: \_copyMem

Description: copies a block of data from the source address to the destination address. This

function copies also to EEPROM.

Inputs: B number of bytes

X destination address Y source address

Outputs: none

Changed Registers: CCR, A, B, X, Y

Call Address: FFBFh

May be used in: □ call-backs □ interrupts

# 3.2.4 API Function: \_getAPIVersion

Description: returns the version of the Application Programming Interface

Inputs: none

Outputs: A,B version number

Changed Registers: CCR, A, B
Call Address: FFD1h

May be used in: 

■ call-backs ■ interrupts

#### 3.2.5 API Function: \_installCallback

Description: installs call-back functions or starts user threads.

Inputs: B type of function (PEI state machine, user timer, save routine, ASAP,

user thread 1, thread 2)

Y pointer to call-back function or user start address

X pointer to the highest memory location of the stack (stack top for user

threads only)

Outputs: none

Changed Registers: CCR, A, B, X, Y

Call Address: FFC5h

Note: The call-back function for the ASAP (Application Layer Service Access Point) has

several parameters:

Inputs: accu A: command  $A = 0 \Rightarrow \text{polling SAP's}$ 

 $A = 1 \Rightarrow$  message for specific SAP

accu B: SAP-number

reg X: pointer to message ( if command in A = 1)

Outputs:  $CY = 0 \Rightarrow access without error was possible$ 

if unknown command in A or illegal service then

CY = 0

 $CY = 1 \Rightarrow SAP$  referred to in accu B not available

reg X: is only changed if command indicates polling !!!

 $X = 0 \Rightarrow$  no message for actual SAP generated  $X = 1 \Rightarrow$  message for polled SAP generated

May be used in: □ call-backs □ interrupts

Task switch: □ must be disabled

#### 3.2.6 API Function: modulMode

Description: This function changes the state of a module and returns the actual state of the

module. No other than the specified module IDs are allowed. If you user other IDs

then this may cause malfunctions.

Inputs: A mode of module

FFh no change of module state

B module ID

Outputs: A actual mode of module in the bits 0 and 1.

Changed Registers: CCR, A, X

Call Address: FFC2h

May be used in: □ call-backs □ interrupts

#### 3.2.7 API Function: \_MSG\_allocBuffer

Description: With this function an empty buffer can be allocated from the system. When the

function is successfully, the X-register contains the pointer to the buffer.

Attention: The task switch must be disabled until the buffer is released (freed or

posted) again.

Inputs: B module ID

Outputs: carry indicates, if the function was successfully

0 = success1 = error

X pointer to allocated buffer (only valid when carry = 0)

Changed Registers: CCR, A, B, X, Y

Call Address: FFB0h

May be used in: 

■ call-backs ■ interrupts

### 3.2.8 API Function: \_MSG\_freeMessage

Description: With this function a previous allocated buffer can be released.

Inputs: X pointer to the buffer, which should be released

Outputs: carry indicates, if the function was successfully

0 = always successfully

Changed Registers: CCR, A, X

Call Address: FFB9h

May be used in: 

■ call-backs ■ interrupts

#### 3.2.9 API Function: \_MSG\_getMessage

Description: With this function a module can get a message from a message queue. A message

filter can be used to specify, which message (service) should be returned. If this filter is set to 0, the module gets the oldest message in the specified message-queue. If the filter has another value, the function searches for this service. The messages are received in the same order, as they were posted to the message queue.

**Attention**: The task switch must be disabled until the buffer is released (freed or

posted) again.

Inputs: B module ID

A service filter

0 no filter used (get oldest message)

e>0 get oldest message with the service indicated by the service

filter

Outputs: carry indicates, if the function was successfully

0 = success (message found)

1 = error

X pointer to message-buffer (only valid when carry = 0)

Changed Registers: CCR, A, X

Call Address: FFB6h

May be used in:  $\Box$  call-backs  $\Box$  interrupts

### 3.2.10 API Function: \_MSG\_postMessage

Description: With this function a message can be sent to another module. Only message buffers

which are received from MSG\_allocBuffer or MSG\_getMessage may be posted.

There are three modes of this function:

post a message and execute the active redirections

post a message without executing a redirection

• post a message and set a temporary redirection

Use only one message with a temporary redirection at one time!

Inputs: A temporary redirection (if requested)

B target module ID

X pointer to the buffer, which should be sent

Y mode of MSG postMessage

0 = MSG\_normalPost normal posting

1 = MSG\_noRedir post without executing any redirection 2 = MSG\_tempRedir post and set a temporary redirection

Outputs: carry indicates, if the function was successfully

0 = success (always successfully)

1 = error

Changed Registers: CCR, A, B, X, Y

Call Address: FFB3h

May be used in: 

■ call-backs ■ interrupts

#### 3.2.11 API Function: \_MSG\_staticRedirection

Description: Sets a static redirection for a specific module and returns the current redirection

(after set). In register A the module ID, to which module all messages for the module referenced in B will be sent, is specified. If register A is FFh, the

redirection is not changed.

Inputs: A Redirection (module ID)

B module ID

Outputs: A actual Redirection (module ID)

(carry indicates, if the function was successfully

0 = success1 = error)

Changed Registers: CCR, A, B, X, Y

Call Address: FFBCh

May be used in:  $\Box$  call-backs  $\Box$  interrupts

Task switch: □ must be disabled

#### 3.2.12 API Function: \_PEI\_addEvent

Description: Adds one event to the PEI event queue and executes the PEI state machine (if not

running). For internally generated events no data can be transferred.

Inputs: Y event ID

Outputs: none

Changed Registers: CCR, A, B, X, Y

Call Address: FF98h

May be used in: □ call-backs ■ interrupts

#### 3.2.13 API Function: \_PEI\_analogueIn

Description: This function reads an analogue value from the PEI. This function can only read

one channel at a time.

Inputs: A number of PEI channel

B number of read operations > 0

Outputs: D sum of read values

Changed Registers: CCR, A, B, X, Y

Call Address: FF8Fh

There is no example for this topic.

#### 3.2.14 API Function: \_PEI\_binaryInOut

Description: This function reads from and writes to the binary PEI-ports. All ports are read, also

the ports, which are set to output. But only those ports are written which are

specified in the output mask.

For both the output data as well as the write mask the following bit definitions

apply:

Bit 7 Bit 6 Bit 5 Bit 4 Bit 3 Bit 2 Bit 1 Bit 0

0 0 1/0 5 1/0 4 1/0 3 1/0 2 1/0 1

Inputs: A output data

B write mask, one bit per port (0 = read only, 1 = write)

Outputs: B data read from the PEI- ports after the write to the ports.

Changed Registers: CCR, A, B, X, Y

Call Address: FF8Ch

There is no example for this topic.

May be used in: 

■ call-backs ■ interrupts

#### 3.2.15 API Function: \_PEI\_getActualPeiType

Description: returns the value of the current PEI-type.

Inputs: none

Outputs: A current PEI-type

Changed Registers: CCR, A, B, X, Y

Call Address: FFA4h

May be used in:  $\Box$  call-backs  $\Box$  interrupts

#### 3.2.16 API Function: \_PEI\_getEvent

Description: Gets the oldest event from the PEI event queue.

Inputs: none

Outputs: Zero flag 0 event found

1 no event in event queue

D, Y event data (see description of event queue)

D (high byte) event ID

Changed Registers: CCR, A, B, X, Y

Call Address: FF9Bh

May be used in: □ call-backs ■ interrupts

### 3.2.17 API Function: \_PEI\_getFreeBufferSpace

Description: returns the free space of the PEI buffers.

Inputs: none

Outputs: Y free space in receive buffer in bytes

X free space in send buffer in bytes

Changed Registers: CCR, A, B, X, Y

Call Address: FF7Dh

May be used in: □ call-backs □ interrupts

#### 3.2.18 API Function: \_PEI\_init

Description: initialises the serial interface and sets the port directions.

The operations which are executed are specified in the B-register. You must call this function before you can use the serial interface.

Inputs: B Bit 0: 0 disable function

1 execute initialisation of serial interface

Bit 1: 0 disable function

1 set CTS usage according bit 2

Bit 2: 0 no CTS interrupt

1 CTS interrupt

Bit 3: 0 disable function (Y then not needed)

1 set PEI\_SerConfig & PEI\_SerBaud

Bit 4: 0 disable function (X then not needed)

1 set PEI direction register

Y Bit 0 - 7: PEI\_SerBaud

0 = 2400

1 = 4800

2 = 9600

3 = 19200

4 = 38400

 $5 = 76\,800$ 

Bit 8 - 15: PEI\_SerConfig

Bit 8: 0 disable asynchron interface

1 enable asynchron interface

Bit 9: 0 enable TC transmit complete interrupt

1 enable TDRE transmit data register empty interrupt

Bit 10:0 must be 0

Bit 11:0 must be 0

Bit 12:0 must be 0

Bit 13:0 BCU like

1 PC like

Bit 14:0 must be 0

Bit 15:0 8 data bits

1

9 data bits

X PEI direction register (0=input, 1=output)

Bit 0: I/O 1 Bit 1: I/O 2 Bit 2: I/O 3 Bit 3: I/O 4 Bit 4: I/O 5 Bit 5 must be 0 Bit 6 must be 0 Bit 7 must be 0

Outputs: none

Changed Registers: CCR, A, B, X, Y

Call Address: FFA1h

May be used in: □ call-backs □ interrupts

#### 3.2.19 API Function: \_PEI\_initBuffer

Description: This function initialises the PEI receive and send buffers. You must call this

function before any use of these buffers.

If you only want to clear a buffer, you must remove all the data by read operations.

For buffer description details see: PEI Buffer Description

Inputs: X pointer to the buffer description

Outputs: none

Changed Registers: CCR, A, B, X, Y

Call Address: FF7Ah

May be used in: □ call-backs □ interrupts

Task switch: ■ must be disabled See also: Structure of the PEI Software

#### 3.2.20 API Function: \_PEI\_initEventQueue

Description: initialises the event queue of the PEI. All events currently in the queue are deleted.

Inputs: none
Outputs: none
Changed Registers: CCR
Call Address: FF95h

May be used in:  $\Box$  call-backs  $\Box$  interrupts

#### 3.2.21 API Function: \_PEI\_rcvBufferRead

Description: Reads data from the PEI-receive buffer.

If the X-register is set to '0' the function reads one byte only. If the X-register is non-zero, it must point to a memory block.

Inputs: X 0 byte-mode

<> 0 block-mode: pointer to memory block

B length of data block (only in block mode) excluding length-byte

Outputs: carry indicates if bytes are read

0 bytes read1 no bytes read

B byte-mode: data byte, read from buffer

block-mode: number of bytes read

Changed Registers: CCR, A, B, X, Y

Call Address: FF80h

May be used in: □ call-backs ■ interrupts

#### 3.2.22 API Function: \_PEI\_rcvBufferWrite

Description: writes data to the PEI-receive buffer.

If the X-register is set to '0' the function writes one byte.

If the X-register is non-zero, then it must point to a memory block, which contains

the data. The B-register contains the number of bytes.

In block-mode the complete block including a leading length byte is sent.

Inputs: X 0 byte-mode

block-mode: pointer to memory block

B byte-mode: byte

block-mode: length of data block, excluding length-byte

Outputs: carry indicates if the data are written successfully

0: bytes written

1: error

Changed Registers: CCR, A, B, X, Y

Call Address: FF83h

May be used in: □ call-backs ■ interrupts

#### 3.2.23 API Function: \_PEI\_sendBufferRead

Description: reads data from the PEI-send buffer.

If the X-register is set to '0' the function reads one byte only. If the X-register is non-zero, it must point to a memory block.

Inputs: X 0 byte-mode

<> 0 block-mode: pointer to memory block

B length of data block (only in block mode) excluding length-byte

Outputs: carry indicates if bytes are read

0 bytes read1 no bytes read

B byte-mode: data byte, read from buffer

block-mode: number of bytes read

Changed Registers: CCR, A, B, X, Y

Call Address: FF86h

May be used in: □ call-backs ■ interrupts

#### 3.2.24 API Function: \_PEI\_sendBufferWrite

Description: writes data to the PEI-send buffer.

If the X-register is set to '0' the function writes one byte.

If the X-register is non-zero, then it must point to a memory block, which contains

the data. The B-register contains the number of bytes.

In block-mode the complete block including a leading length byte is sent.

Inputs: X 0 byte-mode

<> 0 block-mode: pointer to memory block

B byte-mode: byte

block-mode: length of data block, excluding length-byte

Outputs: carry indicates if the data are written successfully

0: bytes written

1: error

Changed Registers: CCR, A, B, X, Y

Call Address: FF86h

May be used in: □ call-backs □ interrupts

#### 3.2.25 API Function: \_PEI\_sendByteSerial

Description: sends one byte via the serial interface.

Inputs: A byte to send

B MSB = 9th data bit or parity bit

Outputs: none

Changed Registers: CCR, A, B

Call Address: FF92h

May be used in: 

 □ call-backs □ interrupts

Known BUG in the 0700 MASK version:

- The parity bit is not set correctly due to a mistake in the handling of the parity bit.

Work around:

- set this: bclr 02ch,#040h

immediately before calling \_PEI\_sendByteSerial if you use parity!

#### 3.2.26 API Function: PEI setTimer

Description: starts and stops a timer for the PEI-state-machine.

There are two timer available. The time-base of the timer is 0,407 µs. The

maximum value is 2<sup>3</sup>1.

If a timer expires then a timer event is generated in PEI event queue. is stop then also pending timer events are changed to NOP-events.

Inputs: A timer number (0, 1)

X:Y timer value (0 = stop)

Outputs: none

Changed Registers: CCR, A, B, X, Y

Call Address: FF9Eh

There is no example for this topic.

May be used in: □ call-backs ■ interrupts

#### 3.2.27 API Function: \_runRomModule

Description: executes a ROM-system module referenced by the module ID.

Inputs: A 0 normal call

1 initialisation

B module ID

Outputs: none

Changed Registers: CCR, A, B, X, Y

Call Address: FFCBh

May be used in: □ call-backs □ interrupts

#### 3.2.28 API Function: \_setParam

Description: sets the initial values of the maximum restart counters or the routing counter

Inputs: A 0 set restart counters

1 set routing counter

2 set the runtime for user task 1 in system ticks

3 set the runtime for user task 2 in system ticks

4 set the runtime for user task 3 in system ticks

B value to set:

- Setting the restart counters:

The high nibble defines the maximum number of repetitions, when busy-acknowledgements are received, the low nibbles defines the maximum number of repetitions, when not-acknowledgements or no acknowledgements are received.

- Setting the routing counter:

Values from 0 to 7 are allowed.

- Setting the runtime for a user task:

Values from 1 (2,5 ms) to 10 (25 ms) are allowed. The default value is 2 (5 ms). A value bigger then 15 does not guarantee retriggering of the watch dog .

Outputs: none

Changed Registers: CCR, A, B

Call Address: FF77h

May be used in: 

■ call-backs ■ interrupts

#### 3.2.29 API Function: \_taskSwitch

Description: Enables or disables the task switch. Each time this function is called a counter is

incremented (disable) or decremented (enable). Only when the counter is zero a

task switch of a user task may be executed.

In addition a user task can use to release the CPU immediately.

Inputs: A = 0 disable task switch

1 enable task switch

FFh release CPU

**Warning:** If you disable the task switch in a user application for longer time (>100ms) a COP

(watch dog) reset may occur. In normal operation the system restarts the watchdog.

For manually restarting the watchdog execute this sequence:

ldaa #055h

staa 03Ah

coma

staa 03Ah

Outputs: none

Changed Registers: CCR, A

Call Address: FFCEh

May be used in: □ call-backs □ interrupts

Task switch: □ must be disabled

## 3.2.30 API Function: \_TM\_getSystemTime

For the 0700 and 0701 MASK version only!

Description: Returns the current system time.

The system time is the value of the internal free running 16-bit counter extended to

32-bits. The time is directly derived from the crystal.

For a crystal frequency of 9,830 4 MHz the time unit for this counter is

406,901 042 ns.

Inputs: none

Outputs: X low counter word

D high counter word

Changed Registers: CCR, D, X

Call Address: FFAAh

May be used in: □ call-backs □ interrupts

# 3.2.31 API Function: \_TM\_getUserTicks

Description: Returns the user time.

The user time is the value of a free running 3 octet counter.

The time unit for this counter is 25 ms.

Inputs: none

Outputs: X low counter word

B most significant counter byte

Changed Registers: CCR, B, X
Call Address: FFADh

May be used in: □ call-backs □ interrupts