

VC FACTOR COMMAND TABLE

log	voice command	reply	Command code (Hex)	function
wakeup_uni	hey pudding hello pudding	Hi, how can i help? Hi, whats up? Yes, Im here	0x5a 0x0 0x0 0x0 0x5a	Enter wake-up and turn on the blue light of the development board
exitUni	goodbye see you	see you later	0x5a 0x1 0x0 0x0 0x5b	Exit wake-up and turn on the blue light of the development board
LearnMatchAC	match the air conditioner	ok, match the air conditioner	0x5a 0x2 0x0 0x0 0x5c	/
ACTurnOn	turn on the air conditioner	ok, turn on the air conditioner	0x5a 0x3 0x0 0x0 0x5d	/
ACTurnOff	turn off the air conditioner	ok, turn off the air conditioner	0x5a 0x4 0x0 0x0 0x5e	/
ACModeAuto	automatic mode	ok, automatic mode	0x5a 0x5 0x0 0x0 0x5f	/
ACModeCool	cold mode	ok, cold mode	0x5a 0x6 0x0 0x0 0x60	/
ACModeHeat	heat mode	ok, heat mode	0x5a 0x7 0x0 0x0 0x61	/
ACModeDry	dry mode	ok, dry mode	0x5a 0x8 0x0 0x0 0x62	/
ACModeFan	fan mode	ok, fan mode	0x5a 0x9 0x0 0x0 0x63	/
ACModeSleep	sleeping mode	ok, sleeping mode	0x5a 0xa 0x0 0x0 0x64	/
ACWindAuto	automatic fan	ok, automatic fan	0x5a 0xb 0x0 0x0 0x65	/
ACWindLow	low fan	ok, low fan	0x5a 0xc 0x0 0x0 0x66	/
ACWindMid	medium fan	ok, medium fan	0x5a 0xd 0x0 0x0 0x67	/
ACWindHigh	high fan	ok, high fan	0x5a 0xe 0x0 0x0 0x68	/
ACWindInc	higher the fan	ok, higher the fan	0x5a 0xf 0x0 0x0 0x69	/
ACWindDec	lower the fan	ok, lower the fan	0x5a 0x10 0x0 0x0 0x6a	/
ACTmp16	sixteen centigrade	ok, sixteen centigrade	0x5a 0x11 0x0 0x0 0x6b	/
ACTmp17	seventeen centigrade	ok, seventeen centigrade	0x5a 0x12 0x0 0x0 0x6c	/
ACTmp18	eighteen centigrade	ok, eighteen centigrade	0x5a 0x13 0x0 0x0 0x6d	/
ACTmp19	nineteen centigrade	ok, nineteen centigrade	0x5a 0x14 0x0 0x0 0x6e	/
ACTmp20	twenty centigrade	ok, twenty centigrade	0x5a 0x15 0x0 0x0 0x6f	/
ACTmp21	twenty one centigrade	ok, twenty one centigrade	0x5a 0x16 0x0 0x0 0x70	/
ACTmp22	twenty two centigrade	ok, twenty two centigrade	0x5a 0x17 0x0 0x0 0x71	/
ACTmp23	twenty three centigrade	ok, twenty three centigrade	0x5a 0x18 0x0 0x0 0x72	/
ACTmp24	twenty four centigrade	ok, twenty four centigrade	0x5a 0x19 0x0 0x0 0x73	/
ACTmp25	twenty five centigrade	ok, twenty five centigrade	0x5a 0x1a 0x0 0x0 0x74	/
ACTmp26	twenty six centigrade	ok, twenty six centigrade	0x5a 0x1b 0x0 0x0 0x75	/

ACTmp27	twenty seven centigrade	ok, twenty seven centigrade	0x5a 0x1c 0x0 0x0 0x76	/
ACTmp28	twenty eight centigrade	ok, twenty eight centigrade	0x5a 0x1d 0x0 0x0 0x77	/
ACTmp29	twenty nine centigrade	ok, twenty nine centigrade	0x5a 0x1e 0x0 0x0 0x78	/
ACTmp30	thirty centigrade	ok, thirty centigrade	0x5a 0x1f 0x0 0x0 0x79	/
ACTmpInc	warmer	ok, warmer	0x5a 0x20 0x0 0x0 0x7a	/
ACTmpDec	cooler	ok, cooler	0x5a 0x21 0x0 0x0 0x7b	/
ACSweptOn	start to fan	ok, start to fan	0x5a 0x22 0x0 0x0 0x7c	/
ACSweptOff	stop to fan	ok, stop to fan	0x5a 0x23 0x0 0x0 0x7d	/
ACSweptVert	air swing up and down	ok, air swing up and down	0x5a 0x24 0x0 0x0 0x7e	/
ACSweptCross	air swing left and right	ok, air swing left and right	0x5a 0x25 0x0 0x0 0x7f	/
SetRestore	air conditioner reset	ok, air conditioner reset	0x5a 0x26 0x0 0x0 0x80	/
TurnOn	turn on the light	ok, turn on the light	0x5a 0x27 0x0 0x0 0x81	Turn on the cold light
TurnOff	turn off the light	ok, turn off the light	0x5a 0x28 0x0 0x0 0x82	Turn off the cold light
ColdOn	cold light turn on	ok, cold light turn on	0x5a 0x29 0x0 0x0 0x83	Turn on the cold light
ColdOff	cold light turn off	ok, cold light turn off	0x5a 0x2a 0x0 0x0 0x84	Turn off the cold light
WarmOn	warm light turn on	ok, warm light turn on	0x5a 0x2b 0x0 0x0 0x85	Turn on the warm light
WarmOff	warm light turn off	ok, warm light turn off	0x5a 0x2c 0x0 0x0 0x86	Turn off the warm light