Parking Brake SET Landing Gear DOWN N/W STRG OFF Spoiler Lever RETRACTED Throttle SHUT OFF Flaps UP/0 WX Radar OFF ADG NOT DEPLOYED Emergency Flaps NORMAL Hydraulics Pumps all OFF	AP Altitude & Rwy HDG  V-Speeds  Transponder  SET  Trims  SET FOR TAKEOFF  Boost Pumps L & R  Hydraulic Pumps  AUTO/ON  ENGINE START  Beacon  Engine 1  START  When 20% N2, Thrust Lever  Engine 2  START
COCKPIT PREPARATION  Battery Switch	When 20% N2, Thrust LeverIDLE
AC Switch (if GPU available)       ON         APU and Main Battery       > 22V         APU PWR/FUEL       ON         APU Start/Stop       START         GEN Switches       all AUTO         NAV Lights       ON         LOGO Lights       ON         IRS 1 & 2       NAV         FMS       SETUP         Packs L & R       ON	Probes LH & RH ON Anti-Ice AS REQ Taxi Lights ON APU Start/Stop STOP APU PWR OFF N/W STRG ARMED
Recirc Fan ON Windshield Heating LH % RH LOW ELT ARM/RESET Stall warning (first flight of the day) TEST Anti-Skid test (first flight of the day) COMPLETE MLG BAY OVHT TEST (first flight of the day) COMPLETE Anti-Skid ARM Engine Sync N1 Spoilers GND Lift Dump AUTO Thrust Reverser LH & RH ARMED Flaps SET FOR TAKEOFF	BEFORE TAKE-OFFLanding LightsONStrobeONBeacon & Taxicheck ONFuel XFLOW Auto OverrideMANTransponderONTCASAS REQRadar/Terrain DisplayAS REQCASCHECK AND CLEARED
TCAS Test         COMPLETE           TCAS         AS REQ           Back-Up COM         STBY           Stab Trim & Mach Trim         ON           Yaw Damper         ON	AFTER TAKE-OFF / CLIMB  Landing Gear
BEFORE ENGINE START  Ground Equipment	Thrust Reverser LH & RH
Wheel Chocks REMOVED Doors CLOSED Passenger Signs ON LDG Elevation SET Baro QNH SET FMS SET	DESCENT  LDG Elevation

Radar/Terrain Display AS REG		
Landing DataSI	E	
APPROACH  Baro	E.	
BEFORE LANDINGPassenger SignsOThrust Reverser LH & RHARMELanding GearDOWFlapsSI	/N	
AFTER LANDING  Spoilers check RETRACTE APU PWR/FUEL O APU Start/Stop STAI Transponder STE Radar / Terrain Display OI Flaps RETRACTE Landing Lights OI Strobes OI Taxi Lights O Probes LH & RH O	N R 8 F E F F N	
SHUTDOWN  Parking Brake SI Throttles SHUT OI Anti-Ice OI Passenger Signs OI Boost Pumps L & R Hydraulic Pumps OI Beacon OI N/W STRG OI IRS 1 & 2 OI External Lights OI APU PWR OI Internal Lights OI Battery OI Battery OI	FIFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF	