If Poor fat suppression

Add an additional STIR

IF METAL

Increase bandwith
Use STIR instead of other fat saturated fluid sensitive sequences

Potential future changes

Wrist arthrogram: Add T1 non fat sat

Sacrum: Add Sag PDfat sat