




About V-Drums Play

V-Drums Play is an app that lets you control the main functions of a drum sound module by using your smartphone (iOS/Android).

This makes it simple to operate the functions that are unique to electronic drums like changing the drum kits, turning the click (metronome) on/off, configuring MIDI recording using your smartphone and so on.

Connecting V-Drums Play to your drum sound module

Pairing

1 Set the “Bluetooth MIDI” settings of your drum sound module to “ON”.

Refer to the manual of your drum sound module for details on how to operate it.

2 On your smartphone, turn Bluetooth on.

3 Launch the V-Drums Play app that you’ve installed on your smartphone, and tap the [Search for V-Drums] button.

Start Bluetooth Connection with the Drum


- Make sure Bluetooth is enabled for the app.
- Make sure the Bluetooth settings on your V-Drums sound module are configured correctly

Search for V-Drums

Bluetooth Permission
Settings




- 4** Tap the name of the drum sound module you're using from the list of drums shown on the screen, and tap the [CONNECT TO DEVICE] button.




If you see a request to make the pairing settings, follow the onscreen instructions to configure the pairing.

Once you see the following screen, the connection is established. Wait until the data has been fully loaded from the drum sound module.



The next time you launch the V-Drums Play app, the drum sound module to which you connected last time is connected automatically.

About the main screen



1 Currently selected drum kit

Shows the kit that's currently selected on the drum sound module.

This shows the drum kit image, number/name, and whether the kit has been marked as a favorite (★). You can change the drum kit when you swipe the currently selected drum kit left or right.

Display	Operation	Explanation
Currently selected drum kit	Swipe	Changes the drum kit.
Kit image, kit name	Tap	Returns to the main screen.
Favorite (★)	Tap	Lets you register or remove the currently selected drum kit from the favorites.

2 Drum kit group

You can register up to six drum kits in each group. This is useful for grouping together the drum kits you use often, or for registering your drum kits as a group by genre or situation.

The + mark is shown if there are fewer than six kits registered. Tap + to register a drum kit.

3 Drum kit group tab

Tap the GROUP A/B/C/D tabs to switch between the four drum kit groups.

You can also show all of the drum kits (the ALL tab) or the drum kits you've registered as favorites (★) as a list.

Tab	Explanation
GROUP A/B/C/D	Switches between the groups that are shown in the drum kit group area.
ALL	Shows all of the drum kits as a list. Swipe up/down to scroll through the list.
★	Shows only the drum kits registered as favorites, as a list. Swipe up/down to scroll through the list.

About the main screen

4 Click (metronome)

Tap the switch to make the click of the drum sound module play/stop.

Tap the metronome icon to switch to the click settings screen ([Setting the click \(metronome\) \(p. 7\)](#)).

5 RECORDER

Tap the RECORDER icon to switch to the recording screen ([Recording \(p. 9\)](#)).

6 Menu

Tap the menu icon to show a menu list on the left side of the screen.

Menu	Explanation
KIT COLOR	Lets you change the illumination colors of the drum sound module buttons, dials and so forth.
KIT NAME	Lets you edit the kit name and the sub kit name. Use the keyboard that's shown to input the name (Editing the kit name (p. 12)).
KIT IMAGE IMPORT	You can import an image for the background of the drum kit screen from the V-Drums Play app into the drum sound module. This is useful when you want to make your own drum kits easier to select (Importing a kit image (p. 13)).
KIT GROUP EDIT	Switches to the KIT GROUP edit screen (Editing the drum kit group (p. 14)).
SETTINGS	Switches to the screen where you can configure the app settings or view information about the app (Configuring and Checking the app information (p. 15)).


7 History

Tap the history icon to show the HISTORY screen. This displays the history of up to 10 drum kits you've switched to. Tap a kit name to switch to that drum kit.

Setting the click (metronome)

On the click settings screen, you can set the click tempo and how it plays.

Common parameters for the settings screens



Display	Explanation
Tempo	Drag these dials up and down to change the tempo. You can also use the [V] [^] buttons to change the tempo.
Beat	Tap the [V] [^] buttons to edit the value.


RHYTHM LEVEL screen



Display	Explanation
Template	You can select the volume for each click timing from the templates. When you change the template, the values of the sliders to the right also change.
Accent	
(Quater)	
(Eighth)	
(Sixteenth)	
(Triplet)	

Setting the click (metronome)


SETUP screen



Display	Explanation
Sound	Selects the click sound.
Level	Adjusts the overall volume for the click.
Pan	Sets the pan position of the click.


TAP TEMPO screen

You can set the tempo by pressing the snare icon on the screen repeatedly at the desired interval (tap tempo).



Recording

On the main screen, tap the RECORDER icon to switch to the recording screen.



Display	Explanation
Recording time 	When you start recording, the elapsed recording time is shown.
 icon	When you tap the icon, “REC STANDBY” is shown onscreen.
 icon	The current click tempo value is shown. Tap the switch under the metronome icon to make the click of the drum sound module play/stop.
 icon	Tap the trash icon to show a confirmation message, asking whether to delete the current data or not. To delete the data, tap the [Delete the recording] button.
 icon	Shows the REC DATA screen, where you can see a list of recorded data (REC DATA screen (p. 10)).

1 Tap the RECORDER icon.


The screen display changes to “REC STANDBY”.

2 Play the drums.

Recording begins.


3 Tap the stop icon.

Recording stops, and a save confirmation message is shown.



4 To save, tap the [SAVE THE RECORDING] button.

A screen for inputting the information for the recorded data is shown.



5 Input the title and description as necessary.


6 Tap the [SAVE] button.

The recording is saved with the information you input, and the display switches to the REC DATA screen.

* Pressing the [Cancel] button shows a delete confirmation message. To delete the data, tap the [Delete the recording] button.

REC DATA screen

This screen shows a list of recorded data.




Display	Explanation	
Recording title	Tap to switch to the playback screen for the selected recording data.	
 icon	Switches to the edit screen for the selected recording data.	
	Edit the recording information	Switches to the screen for inputting the information for the recorded data. You can edit the title and description here for the recorded data.
	Delete this file	A confirmation message is shown. When you tap the [DELETE THIS FILE] button, the recorded data is deleted.
	Cancel	Closes the edit screen for the recorded data.

Editing the kit name

Lets you edit the kit name and the sub kit name. Use the keyboard that's shown onscreen to input the name.

1 From the menu icon, tap "KIT NAME".

A screenshot of a dark-themed mobile application interface. At the top, a dialog box titled 'Edit Kit Name' is displayed with a close button (X) in the top right corner. Below the title, there are two input fields. The first field is labeled 'KIT NAME' and contains the text 'Acoustic Popper'. The second field is labeled 'SUB KIT NAME' and contains the text 'Aggressive - Hip Hop'. Below these fields are two buttons: a blue 'SAVE' button and a white 'Cancel' button with a dark outline.

2 Enter the kit name and sub kit name.

You can input up to 16 characters for the kit name, and up to 64 characters for the sub kit name.
Only the characters that can be used by the drum sound module (ASCII characters) can be input.

3 Once you're finished inputting, press the [SAVE] button.

The data is saved as you inputted it.
If you press the [Cancel] button, the data you inputted is discarded.

Importing a kit image

You can import an image for the background of the kit screen (kit image) from the V-Drums Play app into the drum sound module. This is useful when you want to make your own drum kit easier to select.

- 1** Select the drum kit for which you want to import a kit image.
- 2** From the menu icon, tap “KIT IMAGE IMPORT”.
- 3** Follow the onscreen instructions to select the image you want to import for the selected drum kit.
- 4** Select the part of the image you want to import for the selected drum kit, and tap the [IMPORT] button.

If you select the “High Quality” check box, a high quality version of the image is imported. Note that when you do this, more time is required to import the image data.


- 5** Tap the [IMPORT] button to start importing the image.

Editing the drum kit group

Here's how to edit the order in which the drum kits registered to a drum kit group appear.

1 From the menu icon, tap "KIT GROUP EDIT".

The KIT GROUP EDIT screen appears.



2 Use the operation below to edit the drum kit group.

Operation	Explanation
Dragging a drum kit	You can drag the drum kits to sort them in order. The drum kit moves to the position where you dragged it.
Tapping the trash icon (with a drum kit selected)	Deregisters the selected drum kit. The remaining drum kits are moved backward to fill the space.
Tapping the [SAVE] button	Saves the drum kit group in the drum kit order that's shown.
Tapping the [Revoke] button	Cancels the reordering of the drum kits and returns to the main screen.

Configuring and Checking the app information

1 From the menu icon, tap “SETTINGS”.

2 Select the setting or the parameter to reference.

Display	Explanation
App Settings	Configures the settings for the V-Drums Play app.
App Feature Description	Shows a basic explanation of functions for the V-Drums Play app.
Manual Website	Shows the V-Drums Play app manual (external website).
Terms of Use	Shows the Terms of Use for the V-Drums Play app.
Version License	Shows the V-Drums Play app version and software license.
Privacy Policy	Shows the privacy policy for the V-Drums Play app (external website).

About intellectual property right

- Roland and V-Drums are either registered trademarks or trademarks of Roland Corporation in the United States and/or other countries.
- Company names and product names appearing in this document are registered trademarks or trademarks of their respective owners.

V-Drums Play Operating Guide

03

Roland Corporation

© 2025 Roland Corporation