On installe une VM avec Debian V12 en mode console (cocher SSH et outils systèmes seulement)

pour afficher l'adresse IP de la machine avant le login : echo "IPv4 \4" >> /etc/issue

echo "IPv6 \6" >> /etc/issue

On autorise ssh sur le compte root :
echo "PermitRootLogin Yes" > /etc/ssh/sshd\_config.d/ssh.conf

On installe les paquets necessaires pour compiler Asterisk : apt install git curl build-essential libedit-dev git curl wget libnewt-dev libssl-dev libncurses5-dev subversion libsqlite3-dev build-essential libjansson-dev libxml2-dev uuid-dev avahi-daemon



On Télécharge la dernière version d'asterisk cd /usr/src apt install wget wget http://downloads.asterisk.org/pub/telephony/asterisk/asterisk-20-current.tar.gz tar xfv asterisk-20-current.tar.gz rm asterisk-20-current.tar.gz cd asterisk-20\*

./configure
contrib/scripts/get\_mp3\_source.sh



On configure les options par : make menuselect

### Asterisk Module and Build Option Selection Add-ons (See README-addons.txt) --- Extended ---Applications XXX chan mobile Bridging Modules [\*] chan ooh323 [\*] format\_mp3 Call Detail Recording Channel Event Logging XXX res\_config\_mysql Channel Drivers Codec Translators Format Interpreters Dialplan Functions PBX Modules Resource Modules Test Modules Compiler Flags Utilities



Applications

Bridging Modules

Channel Drivers

PBX Modules

Test Modules

Utilities

Compiler Flags

Codec Translators

Resource Modules

Format Interpreters Dialplan Functions

Call Detail Recording

Channel Event Logging

Asterisk Module and Build Option Selection

Add-ons (See README-addons.txt)

### Applications

Bridging Modules Call Detail Recording Channel Event Logging

Channel Drivers

Codec Translators

Format Interpreters

Dialplan Functions

PBX Modules

Resource Modules

Test Modules

Compiler Flags

Utilities

### --- Core ---

[\*] app\_agent\_pool

[\*] app\_authenticate

[\*] app\_bridgeaddchan

[\*] app\_bridgewait

[\*] app\_cdr

[\*] app\_channelredirect

[\*] app\_chanspy

[\*] app\_controlplayback

[\*] app\_db

[\*] app\_dial

[\*] app\_directed\_pickup

[\*] app\_celgenuserevent

[\*] app\_confbridge

Add-ons (See README-addons.txt)

[\*] bridge\_builtin\_features

[\*] bridge\_builtin\_interval\_features

Asterisk Module and Build Option Selection

[\*] bridge\_holding

[\*] bridge\_native\_rtp

--- Module Options ---

XXX binaural\_rendering\_in\_bridge\_softmix

--- Core ---

[\*] bridge\_simple

[\*] bridge\_softmix



Thierry Rami

Asterisk Module and Build Option Selection

Add-ons (See README-addons.txt)

Applications Bridging Modules

### Call Detail Recording

Channel Event Logging

Channel Drivers

Codec Translators

Format Interpreters

Dialplan Functions

PBX Modules

Resource Modules

Test Modules

Compiler Flags

Utilities

### --- Core ---

[\*] cdr\_custom

[\*] cdr\_manager

--- Extended ---

XXX cdr beanstalkd

[\*] cdr\_csv

XXX cdr\_odbc

XXX cdr\_pqsql

XXX cdr\_radius

[\*] cdr\_sqlite3\_custom

XXX cdr\_adaptive\_odbc

XXX cdr\_tds

--- Core ---

Applications

Bridging Modules

Call Detail Recording

### Channel Event Logging

Add-ons (See README-addons.txt)

Channel Drivers

Codec Translators Format Interpreters

Dialplan Functions

PBX Modules

Resource Modules

Test Modules

Compiler Flags

Utilities

[\*] cel\_custom

[\*] cel\_manager

XXX cel odbc

--- Extended ---

XXX cel beanstalkd

XXX cel\_pgsql XXX cel radius

[\*] cel\_sqlite3\_custom

XXX cel\_tds



Asterisk Module and Build Option Selection —

Add-ons (See README-addons.txt) Applications Bridging Modules Call Detail Recording Channel Event Logging

### Channel Drivers

Codec Translators Format Interpreters Dialplan Functions PBX Modules Resource Modules Test Modules Compiler Flags

Utilities

### --- Core ---

[\*] chan\_bridge\_media

XXX chan\_dahdi

[\*] chan\_iax2

XXX chan\_motif

[\*] chan\_pjsip

[\*] chan\_unistim

[ ] chan\_mqcp

--- Extended ---

[\*] chan audiosocket

--- Deprecated ---

XXX chan alsa

[\*] chan\_rtp

XXX chan\_console

Add-ons (See README-addons.txt)

Applications

Bridging Modules

Call Detail Recording Channel Event Logging

Channel Drivers

### Codec Translators

Format Interpreters Dialplan Functions PBX Modules

Resource Modules

Test Modules

Compiler Flags Utilities

--- Core ---

[\*] codec\_a\_mu

[\*] codec\_adpcm

[\*] codec\_alaw

XXX codec codec2

XXX codec dahdi [\*] codec\_g722

[\*] codec\_g726

[\*] codec\_gsm

[\*] codec\_ilbc

[\*] codec\_lpc10

[\*] codec\_resample XXX codec\_speex

[\*] codec\_ulaw



Asterisk Module and Build Option Selection

Add-ons (See README-addons.txt)

Applications

Bridging Modules

Call Detail Recording

Channel Event Logging

Channel Drivers

Codec Translators

### Format Interpreters

Dialplan Functions

PBX Modules

Resource Modules

Test Modules

Compiler Flags

Utilities

### --- Core ---

- [\*] format\_q719
- [\*] format\_q723
- [\*] format\_g726
- [\*] format\_gsm
- [\*] format h263
- [\*] format\_h264
- [\*] format\_ilbc
- XXX format\_ogg\_vorbis
- [\*] format\_pcm
- [\*] format\_siren14
- [\*] format\_sln

- [\*] format\_g729

- [\*] format\_siren7

### Add-ons (See README-addons.txt)

Applications

Bridging Modules

Call Detail Recording

Channel Event Logging

Channel Drivers

Codec Translators

Format Interpreters

### Dialplan Functions

PBX Modules

Resource Modules

Test Modules

Compiler Flags

Utilities

### --- Core ---

- [\*] func\_aes
- [\*] func\_base64
- [\*] func blacklist
- [\*] func\_callcompletion
- [\*] func\_callerid
- [\*] func\_cdr
- [\*] func\_channel
- [\*] func\_config
- XXX func\_curl
- [\*] func\_cut
- [\*] func\_db
- [\*] func\_devstate
- [\*] func\_dialgroup



Asterisk Module and Build Option Selection

Add-ons (See README-addons.txt)
Applications
Bridging Modules
Call Detail Recording
Channel Event Logging
Channel Drivers

Codec Translators
Format Interpreters
Dialplan Functions

### PBX Modules

Resource Modules
Test Modules
Compiler Flags
Utilities

### --- Core ---

- [\*] pbx\_config
- [\*] pbx\_loopback
- [\*] pbx\_spool
  --- Extended ---
- [\*] pbx\_ael
- [\*] pbx\_dundi
- XXX pbx\_lua
- [\*] pbx\_realtime

Asterisk Module and Build Option Selection

Add-ons (See README-addons.txt)

Applications

Bridging Modules

Call Detail Recording

Channel Event Logging

Channel Drivers

Codec Translators

Format Interpreters

Dialplan Functions

PBX Modules

### Resource Modules

Test Modules
Compiler Flags
Utilities

### --- Core ---

- [\*] res\_aeap
- [\*] res\_agi
- [\*] res\_ari
- [\*] res\_ari\_applications
- [\*] res\_ari\_asterisk
- [\*] res\_ari\_bridges
- [\*] res\_ari\_channels
- [\*] res\_ari\_device\_states
- [\*] res\_ari\_endpoints
- [\*] res\_ari\_events
- < > res\_ari\_mailboxes
- [\*] res\_ari\_model
- [\*] res\_ari\_playbacks



Applications

Bridging Modules

Channel Drivers

Codec Translators

Format Interpreters

Dialplan Functions

Resource Modules

PBX Modules

Test Modules

Utilities

Compiler Flags

Call Detail Recording

Channel Event Logging

Asterisk Module and Build Option Selection

Add-ons (See README-addons.txt)

Add-ons (See README-addons.txt)

Applications

Bridging Modules

Call Detail Recording

Channel Event Logging

Channel Drivers

Codec Translators

Format Interpreters

Dialplan Functions

PBX Modules

Resource Modules

### Test Modules

Compiler Flags Utilities

### --- Core ---

XXX test\_abstract\_jb

XXX test\_aeap

XXX test\_aeap\_speech

XXX test\_aeap\_transaction

XXX test\_amihooks

XXX test aoc

XXX test\_app

XXX test\_ari\_model

XXX test\_ast\_format\_str\_redu

XXX test\_acl

XXX test\_aeap\_transport

XXX test\_ari

XXX test\_astobj2

--- Core ---

[ ] DONT\_OPTIMIZE

< > COMPILE DOUBLE

[ ] DEBUG THREADS

[ ] DEBUG\_FD\_LEAKS

XXX BETTER\_BACKTRACES

[ ] LOTS\_OF\_SPANS

[ ] MALLOC\_DEBUG

[ ] DEBUG\_CHAOS

[\*] BUILD\_NATIVE

--- Extended ---

[ ] REF\_DEBUG

[ ] AO2\_DEBUG

XXX REBUILD\_PARSERS



Add-ons (See README-addons.txt)
Applications
Bridging Modules
Call Detail Recording
Channel Event Logging
Channel Drivers
Codec Translators
Format Interpreters
Dialplan Functions
PBX Modules
Resource Modules

Test Modules

Utilities

Compiler Flags

[\*] astcanary
[\*] astdb2sqlite3
[\*] astdb2bdb
--- Extended --[ ] check\_expr
[ ] check\_expr2

XXX smsq
[ ] stereorize
[ ] streamplayer

XXX conf\_bridge\_binaural\_hri
--- Deprecated --[ ] aelparse
[ ] astman

Bridging Modules
Call Detail Recording
Channel Event Logging
Channel Drivers
Codec Translators
Format Interpreters

Asterisk Module and Build Option Selection

Dialplan Functions
PBX Modules

Resource Modules
Test Modules

Compiler Flags

Utilities

AGI Samples

Core Sound Packages

Asterisk Module and Build Option Selection

### --- Extended ---

- [ ] agi-test.agi
- [ ] eagi-test
- [] eagi-sphinx-test
- [] jukebox.agi



Asterisk Module and Build Option Selection

Bridging Modules
Call Detail Recording
Channel Event Logging
Channel Drivers
Codec Translators
Format Interpreters
Dialplan Functions
PBX Modules
Resource Modules
Test Modules
Compiler Flags
Utilities
AGI Samples

Core Sound Packages

] CORE-SOUNDS-ES-GSM ] CORE-SOUNDS-ES-G729 ] CORE-SOUNDS-ES-G722 ] CORE-SOUNDS-ES-SLN16 ] CORE-SOUNDS-ES-SIREN7 ] CORE-SOUNDS-ES-SIREN14

### [ ] CORE-SOUNDS-FR-WAV

- [\*] CORE-SOUNDS-FR-ULAW
- [\*] CORE-SOUNDS-FR-ALAW
- [\*] CORE-SOUNDS-FR-GSM
- [\*] CORE-SOUNDS-FR-G729
- [\*] CORE-SOUNDS-FR-G722
- [ ] CORE-SOUNDS-FR-SLN16
- [ ] CORE-SOUNDS-FR-SIREN7

Call Detail Recording Channel Event Logging Channel Drivers Codec Translators

Format Interpreters

Dialplan Functions PBX Modules

Resource Modules

Test Modules

Compiler Flags

Utilities

AGI Samples

Core Sound Packages

Music On Hold File Packages

Asterisk Module and Build Option Selection

### --- Core ---

- [\*1 MOH-OPSOUND-WAV
- [ ] MOH-OPSOUND-ULAW
- [ ] MOH-OPSOUND-ALAW
- [\*] MOH-OPSOUND-GSM
- [\*] MOH-OPSOUND-G729
- [\*] MOH-OPSOUND-G722
- 1 MOH-OPSOUND-SLN16
- MOH-OPSOUND-SIREN7
- [ ] MOH-OPSOUND-SIREN14



Asterisk Module and Build Option Selection Channel Event Logging [ ] EXTRA-SOUNDS-EN\_GB-G729 Channel Drivers [ ] EXTRA-SOUNDS-EN\_GB-G722 Codec Translators [ ] EXTRA-SOUNDS-EN\_GB-SLN16 Format Interpreters [ ] EXTRA-SOUNDS-EN\_GB-SIREN7 Dialplan Functions [ ] EXTRA-SOUNDS-EN\_GB-SIREN14 PBX Modules [ ] EXTRA-SOUNDS-FR-WAV Resource Modules [ ] EXTRA-SOUNDS-FR-ULAW Test Modules [ ] EXTRA-SOUNDS-FR-ALAW Compiler Flags [\*] EXTRA-SOUNDS-FR-GSM Utilities [\*] EXTRA-SOUNDS-FR-G729 AGI Samples [\*] EXTRA-SOUNDS-FR-G722 [ ] EXTRA-SOUNDS-FR-SLN16 Core Sound Packages Music On Hold File Packages [ ] EXTRA-SOUNDS-FR-SIREN7 Extras Sound Packages EXTRA-SOUNDS-FR-SIREN14 French, G.722.1C (Siren14) format Depends on: N/A Can use: N/A Save & Exit Exit Conflicts with: N/A Support Level: core



Une fois la configuration terminée, on compile : make make install make samples

make basic-pbx

make config

Selon la puissance de la machine, l'opération peut être longue.



Une fois terminé, on lance Asterisk et on verifie son statut : service asterisk start

service asterisk status



On va faire une sauvegarde des fichiers que l'on va modifier : mv /etc/asterisk/pjsip.conf /etc/asterisk/pjsip.conf.origin mv /etc/asterisk/voicemail.conf /etc/asterisk/voicemail.conf.origin cp /etc/asterisk/asterisk.conf /etc/asterisk/asterisk.conf.origin

Pour le test, on va créer 3 utilisateurs :

alice, numéro : 6001, mot de passe : bonjour

bob, numéro : 6002, mot de passe : bonjour

martin, numéro : 6003, mot de passe : bonjour



Les fichiers de config sont à récupérer sur : https://github.com/thierry-rami/Asterisk\_config Et a copier dans /etc/asterisk

Une fois les fichiers de config installés faire : asterisk -rx "core restart now"

et on vérifie que Asterisk Toune :
root@pbx:~# ss -nlut | grep -E '5060|State'
Netid State Recv-Q Send-Q Local Address:Port Peer Address:Port
udp UNCONN 0 0 0.0.0.0:5060 0.0.0.0:\*



On lance la commande asterisk -rvvvvvvvvvv On se trouve maintenant dans l'invite de commande d'asterisk :

pjsip list auths

Normalement, on devrait voir les 3 utilisateurs : Alice, Bob, Martin



Maintenant que le serveur Asterisk tourne, on va installer le client sur Windows, Linux, MacOs, Smartphone : Linphone

Dans ce cas, je me connecte en tant que « Alice » et l'adresse IP du serveur asterisk est :10.10.18.150 Une fois connecté dans l'interface CLI d'Asterisk, on a :

- -- Added contact 'sip:alice@10.10.18.151:44678;transport=udp' to AOR 'alice' with expiration of 3600 sec == Endpoint alice is now Reachable
  - -- Removed contact 'sip:alice@10.10.18.151:44678;transport=udp' from AOR 'alice' due to request
- == Contact alice/sip:alice@10.10.18.151:44678;transport=udp has been deleted
- == Endpoint alice is now Unreachable

obx\*CLI>



