


Adjust PS1 to 5.0 V before connecting U1. Open JP1 whenever USB is plugged into U1.



Thies Gerken

Sheet: /
File: hcp.kicad_sch

Title: Hörmann HCP2 ESP32-C3 Adapter

Size: A4
KiCad E.D.A. 10.0.6

Date: 2026-09-05

Rev: 8e51ebe

Id: 1/1