(Ch.9) System Response in the Frequency Domain

The term "frequency response" is used to describe a system's response to a periodic input. Frequency response analysis focuses on a system's response to harmonic inputs, such as sines and cosines. The forcing is, therefore, of the form:

Many systems exhibit sinusoidal forcing: IC engines, rotating machinery, reciprocating pumps, etc. Additionally, Fourier series shows that any periodic function can be represented by a sum of a constant plus a series of sine and rosine terms.

Complex Number Review

Rectangular Representation

$$Z = |z|e^{j\theta} = |z|(\cos\theta + j\sin\theta)$$

where 
$$|z| = \sqrt{x^2 + y^2}$$
,  $\theta = \langle z = \tan^{-1}(\frac{y}{x})$ 

Complex Algebra: let Z,= X, + jy, Zz= Xz+jyz

$$Z_1 + Z_2 = (X_1 + X_2) + j(y_1 + y_2)$$

$$Z_1Z_2 = |Z_1||Z_2| \angle (\theta_1 + \theta_2) = (X_1X_2 - Y_1Y_2) + j(X_1Y_2 + X_2Y_1)$$

$$\frac{Z_{1}}{Z_{2}} = \frac{|Z_{1}|}{|Z_{2}|} \angle (\theta_{1} - \theta_{2}) = \frac{X_{1}X_{2} + y_{1}y_{2}}{|X_{2}|^{2} + y_{1}^{2}} + j \frac{X_{2}y_{1} - X_{1}y_{2}}{|X_{2}|^{2} + y_{2}^{2}}$$

trequency Response Concept

Any linear, time-invariant (LTI) system has a transfer function, Tis), that maps the input/ output relationship. Under sinusoidal excitation (input) with frequency w, if the system is Stable, the transients will eventually dissapear leaving the S.S. response with the same frequency as the input (w) but with different amplitude and shifted in time wirt, the input.

(9.1) Frequency Response of 1st Order Systems

Consider our 1st order mass damper system who's EOM was

$$m\dot{v} + cv = f(t)$$

The time constant was ~= m , so we can write this system as

Zy + y = f(t) (where we have replaced x with y to be generic)

The transfer function is:

$$T(s) = \frac{Y(s)}{F(s)} = \frac{1}{Y(s+1)}$$

If the forcing is sinusoidal (f(t) = Asinwt), then we can solve the time response for zero ICs using Laplace Transforms as:

$$\gamma = A \sin \omega t$$

$$\gamma = Y(s) + Y(s) = \frac{A\omega}{s^2 + \omega^2}$$

$$\gamma = \frac{A\omega}{(s^2 + \omega^2)(\gamma + 1)} = \frac{C_1}{\gamma + 1} + \frac{C_2 s}{(s^2 + \omega^2)} + \frac{C_3 \omega}{(s^2 + \omega^2)}$$

$$\gamma = \frac{A\omega}{(s^2 + \omega^2)(\gamma + 1)} = \frac{C_1}{\gamma + 1} + \frac{C_2 s}{(s^2 + \omega^2)} + \frac{C_3 \omega}{(s^2 + \omega^2)}$$

Solving for C, , Cz, C3 gives:

$$C_1 = \frac{A\omega x^2}{1+\omega^2 x^2}$$
,  $C_2 = \frac{-A\omega x}{1+\omega^2 x^2}$ ,  $C_3 = \frac{A}{1+\omega^2 x^2}$ 

Substituting and inverting gives:

$$y(t) = \frac{Awx}{1+w^2x^2} \left( e^{-t/x} - \cos wt + \frac{1}{wx} \sin wt \right)$$
Transient Steady-State

The steady-state response is

$$y_{ss}(t) = \frac{A}{1+\omega^2 \gamma^2} \left( \sin \omega t - \omega x \cos \omega t \right) = \frac{A}{\sqrt{1+\omega^2 \gamma^2}} \sin \left( \omega t + \phi \right), \text{ where } \phi = -\tan^2 \omega x$$

So we can see that the system responds at the same frequency as the input, but with a different amplitude and a phase shift. The ratio of the response amplitude to the input amplitude can be defined as the amplitude ratio, M:

$$M = \frac{A}{\sqrt{1+\omega^2 x^2}} = \frac{1}{\sqrt{1+\omega^2 x^2}}$$
 Again, the phase shift is:  $\phi = -\tan^2 \omega x$ 

Now, it turns out that the amplitude ratio and phase shift ran be found directly from the transfer function! Consider the TF:

$$T(s) = \frac{1}{\gamma s + 1}$$

Substitute s=jw into the TF:

$$T(j\omega) = \frac{1}{j\omega x + 1} = \frac{1}{1 + j\omega x}$$

The magnitude of this complex number is:


$$|T(j\omega)| = \left|\frac{1}{1+j\omega x}\right| = \frac{|1|}{|1+j\omega x|} = \frac{1}{\sqrt{1+\omega^2 x^2}} = M$$


And the angle is

$$\angle T(j\omega) = \angle 1 - \angle 1 + j\omega x = \tan^{-1}(\frac{\rho}{r}) - \tan^{-1}(\frac{\omega x}{r}) = -\tan^{-1}\omega x = \phi$$


So, the steady-state response can be found by substituting S=jw into the TF and solving for magnitude and phase. The solution can be written as


Now, what does the response look like? It is frequency dependent:





For 1st order systems, the steady-state output decreases with increasing frequency. Also, the large & is, the faster it decreases with frequency and the larger the phase shift is. Graphically:





We typically plot these on logarithmic scales (turns out we can add or subtract the magnitude of plots of simpler TFs to represent a more complicated TF). On log scales, these plots are called Bode Plots.

Basic logarithm properties:

$$\log(xy) = \log x + \log y$$
  $\log(\frac{x}{3}) = \log x - \log y$   $\log x^n = n \log x$ 

Also, we use decibel units for magnitude on Bode Plots


$$m(dB) = 10 \log M^2 = 20 \log M$$
 note:  $M = 10^{m/20}$  (can be used to convert)

So in our case 1

$$m(dB) = 20 \log \frac{1}{\sqrt{1+\omega^2 x^2}} = 20 (\log 1 - \log \sqrt{1+\omega^2 x^2}) = 20 \log 1 - 10 \log (1+\omega^2 x^2)$$

$$m(dB) = -10 \log (1+\omega^2 x^2)$$


Now, let's look at the Bode Plot:



Hand Sketching Bode Plots \*\* See handout on next page

- · m=0 corresponds to M=1, where the output amplitude equals the input magnitude
- · m > 0 corresponds to M>1, where output > input (amplification)
- · m < 0 corresponds to M < 1, where output < input (attenuation)
- 1st Order systems:  $m \le 0$ , so we never have amplification.

Bode Plots for  $T(s) = \frac{1}{\tau s + 1}$ ,  $\tau = 10$ 



To sketch m vs. w, we can approximate m(w) in three frequency ranges

- for  $\gamma \omega << 1$ ,  $(1+\gamma \omega) \approx 1 \Rightarrow m = -10\log(1) = 0 \Rightarrow m = 0$  (low frequency asymptote)
- · for \( \omega \) \( \)
  - \* This gives a straight line vs logw. This is the high frequency asymptote, whose slope is -20 dB/decode
- · for  $\gamma \omega = 1$ ,  $(1 + \gamma^2 \omega^2) = 2 \Rightarrow m = -10 \log 2 = -3.01$ 
  - \* So at W= to, m(w) is 3 dB below the low frequency asymptote.
  - \* w = to is called the "breakpoint frequency" or "corner frequency".

To sketch of us w: (recall \$ = -tan-'(we)

- · for 2w << 1, \$ = tan-1(0) = 00
- · for 2w >71, \$ = -90°
- · for xw = 1, Ø = -tan-(1) =-450

(9.2) Frequency Response of 200 Order Systems

When working in the log scale, a complex transfer function can be analyzed easily because factors in the numerator simply add and factors in the denomenator subtract. Graphically, we just add or subtract the contribution of each term to plot the overall system transfer function. To see this, consider

Substitute 5=jw:

$$T(j\omega) = K \frac{N_1(j\omega) N_2(j\omega)...}{D_1(j\omega) D_2(j\omega)...}$$

Solve for the magnitude:

$$|T(j\omega)| = \frac{|K||N_1(j\omega)||N_2(j\omega)||...}{|D_1(j\omega)||D_2(j\omega)||...} = M$$

In decibel units:

To plot this, we simply plot each component and add (or subtract) them together What about the phase?

$$d(\omega) = \angle T(j\omega)$$

$$= \angle K + \angle N_1(j\omega) + \angle N_2(j\omega) + ...$$

$$-\angle D_1(j\omega) - \angle D_2(j\omega) - ...$$

Similarly, we add and subtract each phase component to form the plot.

Consider our standard mass-spring-damper system with sinusoidal excitation

$$m\ddot{x} + c\dot{x} + Kx = f(t)$$
  $f(t) = A \sin \omega t$ 

The transfer function is

$$T(s) = \frac{X(s)}{F(s)} = \frac{1}{ms^2 + cs + K}$$

$$T(s) = \frac{1/K}{(\frac{m}{K})s^2 + (\frac{c}{K})s + 1} = \frac{1/K}{(\mathcal{T}_1 s + 1)(\mathcal{T}_2 s + 1)}$$

Ti, Ti = time constants of roots

Substitute s=jw

$$T(j\omega) = \frac{1/\kappa}{(\gamma_1 j\omega + 1)(\gamma_2 j\omega + 1)}$$


Solve for amplitude ratio


$$M(\omega) = |T(j\omega)| = \frac{|1/\kappa|}{|T_{i,j\omega+1}||Y_{i,2,j\omega+1}|}$$

Solve for the phase angle

$$\phi(\omega) = \angle \frac{1}{K} - \angle (\gamma_1 \omega_j + 1) - \angle (\gamma_2 \omega_j + 1)$$

So, the magnitude plot consists of a constant term, 20 log | #1, minus the sum of two 1st-order terms. We saw before that a first order term yields a -20 dBl decade slope. Let's sketch this





- 1) Sketch each romponent
  - a) zo log | = 0
  - b) -20 log |Y, wj+1|: first order term, has low freq asymptote = 0, high freq asymptote = -20 dB/decade, breakpoint =  $W = \frac{1}{2}$ ,
  - c) -20 log | Tzwj+1 |: first order term, low freq asymptote =0, high freq asymptote = -20 dB | decade, breakpoint = w-tz
- 2) Draw Composite sketch

  Note: the effects of each first order term

  Kick in after their breakpoints. They also

  add, so for w> 1/22, the slope is

  -40 dB/decade.

1) Sketch each component

a) 
$$\angle \frac{1}{K} = \angle \frac{1}{I} = \angle I = 0$$
  
Constant at  $\beta = 0$ 

- b) \( \langle (\gamma\_i \omega\_j + i) = -\tan'(\omega\_z) :\\
  0° \text{ for } \omega \text{\langle \langle \gamma\_z}, \quad \text{\langle \gamma\_z}, \quad \quad \text{\langle \gamma\_z}, \quad \quad \quad \quad \gamma\_z}, \quad \qu
- c) \( \langle (\pi\_z w \) + 1) = \tan \( \langle (w \pi\_z) \);

  o° \( \text{for } w \rangle \gamma \rangle \pi\_z \),

  90° \( \text{for } w \rangle \gamma \gamma

If the system is underdamped, there are two complex ronjugate roots. Write Tiss as:

recall 
$$w_n = \sqrt{\frac{K}{m}}$$
,  $s = \frac{c}{2\sqrt{mK}}$ 

56

$$T(s) = \frac{K X(s)}{f(s)} = \frac{1}{(\frac{m}{K})s^2 + (\frac{c}{K})s + 1} = \frac{1}{(s/\omega_n)^2 + 2s(s/\omega_n) + 1}$$
factor out K

Now, the roots are only complex if 3 < 1, so we have

$$T(s) = \frac{KX(s)}{F(s)} = \frac{\omega n^2}{s^2 + 2 \Im \omega_n s + \omega_n^2}$$

A By factoring out K, we form the ratio of autput displacement X(s) to input displacement,  $\overline{K}$ . Recall  $F=KX \Rightarrow X=\overline{K}$ . It also allows us to define the TF in terms of 3 + Wn as follows:

Substituting s=jw and multiplying by The gives

$$T(j\omega) = \frac{1}{(j\omega/\omega_n)^2 + (25/\omega_n)j\omega + 1} = \frac{1}{1 - (\omega/\omega_n)^2 + (25\omega/\omega_n)j\omega}$$

To simplify this expression, we can define the frequency ratio, r as:

Substituting

$$T(r) = \frac{1}{1-r^2+25rj}$$

The amplitude ratio is then

$$M = |T_{(r)}| = \frac{1}{\sqrt{(1-r^2)^2 + (25r)^2}} \implies m = 20 \log M = -10 \log \left[ (1-r^2)^2 + (25r)^2 \right]$$

And the phase is

$$\phi = \angle \left( 1 - \angle \left( 1 - r^2 + 25r \right) \right) \Rightarrow \phi = -\tan^{-1} \left( \frac{25r}{1-r^2} \right)$$

To hand sketch m vs. i w, we approximate m in three frequency ranges

- · For r << 1 ( W << wn ): M = -10 log (1) = 0 ( low frequency asymptote)
- · For r >> 1 (w>> wn): m = -10 log (r4 + 432 r2)

2 -10 log r4

=-40 log r => This gives a straight line with a slope of -40dB/decade. (high frequency asymptote).

· For r=1 (W=Wn), we need to consider the phenomenon known as resonance

Resonance

For 2nd order underdamped systems, the response near the breakpoint frequency (natural frequency) depends highly on the damping of the system.

Consider the fact that M is maximum when its denomenator is a minimum. Taking the derivative of the denomenator equal to O gives:

 $M_{\text{max}}$  occurs at  $\Gamma = \sqrt{1-25^2}$   $\Rightarrow \omega = \omega_n \sqrt{1-25^2}$ 

This frequency is the resonance frequency, wr. Note, this peak only exists if the radical is positive => 0 < 5 < 0.707, so

Wr = Wn VI-252 0 = 3 = 0.707

The peak value at resonance is found by substituting this back into M to get

 $M_{\Gamma} = \frac{1}{23\sqrt{1-5^2}}$  0 = \$ = 0.707 in decibels:  $m_{\Gamma} = -20\log(25\sqrt{1-5^2})$ 

So if the damping ratio is above 0.707, we don't get a peak. The phase at the resonance frequency is

 $\phi_r = -\tan^{-1} \frac{\sqrt{1-25^2}}{5}$ 

A Note: because we multiplied the TF by K, we must divide the expressions for M and Mr by K in order to amplitude ratio between input force, f(t) and output displacement Yes (t):

$$M = \frac{1}{K\sqrt{(1-r^2)^2 + (25r)^2}} \Rightarrow M = -20\log(K) - 10\log[(1-r^2)^2 + (25r)^2]$$

$$M_r = \frac{1}{K25\sqrt{1-5^2}} \Rightarrow m_r = -20\log(K) - 20\log(23\sqrt{1-5^2})$$


Hand Sketching 2nd Order Bode Plots

Bode Plots for  $T(s) = \frac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2}$ ,  $\zeta \le 1$  (underdamped)

Amplitude Ratio

30  $\zeta = 0.01$ 20 on frequency 10 -20 high trequency asymptote -30 Slope: -40 dBlderade

(a)



Phase

Approximate m in three frequency ranges

· For r221 (W24Wn), m= -10 log (1) = 0 (low frequency asymptote)

· For r>71 (W>> Wn), m = -10 log (r4+45212) ≈ -10 log +4 = -40 log r

This gives a straight line with a slope of -40 dB/decade for the high frequency asymptote.

· For r=1 (w=wn), we need to consider the phenomenon known as resonance. The resonance frequency is near wh and is given by:

The peak value at the resonance frequency is

So for 3 = 0.707, one finds Wrand Mr and adds the point to the plot. To either side of Wr, the signal decays back to the low and high frequency asymptotes. For smaller values of the damping ratio, the peak is sharper.

We can also add the phase value at the resonance frequency to the phase plot by using the relation

$$\phi_r = -\tan^{-1}\left(\frac{\sqrt{1-23^2}}{5}\right)$$

Approximate the phase in three frequency ranges

· For re((weewn), \$\phi = -tan-'(\frac{0}{1}) = 00

· For r>>1 (w>>wn), d = -tan- (-1) = -tan- (-1) = -180° (2nd order terms result in a 180° phase shift)

• For  $r=1/(w=w_0)$  ,  $\phi = -\tan^{-1}(\frac{23}{0}) = -900$ 

Note: the smaller the damping ratio, the steeper the slope through -90° at the breakpoint frequency (sharper curve).

Example Problem: P9.11

The model of a certain mass-spring-damper system is:

Determine the value of K required so that the maximum response occurs at w=4 rad/sec. Obtain the steady-state response at that frequency. Sketch the Bode Plot of the system.

From the problem statement, we know the system oscillates. The resonance frequency, therefore, is

Solving for wn + 3 in terms of k:

$$\omega_n = \sqrt{\frac{K}{13}}$$
,  $S = \frac{2}{2\sqrt{13 \cdot K'}} = \frac{1}{\sqrt{13 \cdot K'}}$ 

Substituting and setting Wr=4

$$4 = \sqrt{\frac{K}{13}} \sqrt{1 - \frac{2}{13K}} = \sqrt{\frac{1}{13}} \sqrt{K - \frac{2}{13}} = \frac{1}{13} \sqrt{13K - 2} \implies [K = 208.15]$$

The steady state response magnitude and phase at resonance are

$$M_r = \frac{1}{23\sqrt{1-5^2}}$$
  $\phi = -\tan^{-1} \frac{\sqrt{1-25^2}}{5}$ 

A But, recall in deriving this formula for Mr, we factored out K when forming the TF. To use this formula to scale the input force to output displacement, we must divide by K.

Substituting + solving for Mr:

$$M_r = \frac{1}{208.15} \frac{1}{2\frac{1}{52.02}\sqrt{1-\left(\frac{11}{52.02}\right)^2}} = 0.125$$

Solving for p:

$$\phi = -\tan^{-1}\left(\frac{\sqrt{1-2(\frac{1}{52.02})}}{\frac{1}{52.02}}\right) = -\tan^{-1}(52) = -1.55 \text{ rad}$$

So the steady-state response is

To sketch the Bode plot, we can use the general formulas for m + \$p\$ to estimate the response in three regions.

Approximating m for three Frequency ranges:

• For rxx1 (wxxwn), 
$$m = -10 \log(1) = 0$$
  
• For rx71 (wxxwn),  $m = -10 \log(r^{4} + 45^{2}r^{2})$   
 $\approx -10 \log(r^{4})$   
 $= -40 \log(r)$ 

• Resonance: we know from the problem statement that  $\omega_r = 4$ . In terms of r, this corresponds to:

$$V_r = \frac{\omega_r}{\omega_n} = \frac{4}{\sqrt{\frac{208.15}{13}}} = 0.9996 \approx 1.$$

The peak response in dBs at resonance is

$$M_r = 20 \log (M_r) = 20 \log \left( \frac{1}{23\sqrt{1-5^2}} \right)$$

note: this is the original form of Mr so that m gives the amplitude ratio of the output displacement to input displacement.

$$= 20 \log \left( \frac{1}{2 \frac{1}{52.02} \sqrt{1 - \left(\frac{1}{52.02}\right)^2}} \right) = 28.30$$


For the phase,

For real (weeken), 
$$\phi = -\tan^{-1}(\frac{0}{1}) = 0^{\circ}$$

. For 
$$r > 7 \mid (\omega > \omega_n)$$
,  $\phi = -\tan^{-1}(-\frac{r}{r^2}) = -\tan^{-1}(-\frac{1}{r^2}) \Rightarrow -180^\circ$ 

• For 
$$r=1$$
  $(w=\omega_n)$ ,  $\phi=-\tan^{-1}\left(\frac{23}{0}\right)=7-90^\circ$ 


Bode Plot:




(13.1) Base Excitation

A very common vibration input to a system is motion of its base support. This is called base excitation. Consider a car traveling down a bumpy road. The road can be thought of as a moving base. The car's suspension is designed to minimize the motion and force transmitted to the passenger compartment; it is a vibration isolation system. In vibrations, we may want to decrease the force transmitted from an object to its base (force transmissibility) or decrease the motion of the object from the excitation of the base (displacement transmissibility).

Consider the base excited mass-spring-damper





Newton's Method  

$$\Sigma F_X = M\ddot{x} = -C(\dot{x}-\dot{y}) - K(X-y)$$
  
 $M\ddot{x} + C\dot{x} + Kx = C\dot{y} + Ky$ 

The transfer function is:

$$ms^2 X(s) + cs X(s) + k X(s) = cs Y(s) + k Y(s) \Rightarrow T(s) = \frac{X(s)}{Y(s)} = \frac{cs + k}{ms^2 + cs + k}$$

Dividing numerator + denomenator by m, we can write as:

Displacement Transmissibility

$$\frac{\chi(s)}{\gamma(s)} = \frac{23\omega_n s + \omega_n^2}{s^2 + 23\omega_n s + \omega_n^2}$$

Substitute S=jw

$$\frac{X(j\omega)}{Y(j\omega)} = \frac{25\omega_n\omega_j + \omega_n^2}{-\omega^2 + 25\omega_n\omega_j + \omega_n^2}$$

Dividing numerator + denomenator by wn, we can write as

$$\frac{X(j\omega)}{Y(j\omega)} = \frac{25rj + 1}{1 - r^2 + 25rj}$$

The displacement transmissibility magnitude and phase are

$$\left|\frac{\chi_{(j\omega)}}{\gamma_{(j\omega)}}\right| = \frac{\chi}{\gamma} = \sqrt{\frac{(25r)^2 + 1}{(1-r^2)^2 + (25r)^2}} = \sqrt{\frac{45^2r^2 + 1}{(1-r^2)^2 + 45^2r^2}}$$

This can be used to calculate the SS response amplitude, X, caused by a sinuscidal input with amplitude Y.

$$\phi = \angle (2sr_j + 1) - \angle (1 - r^2 + 2sr_j) = \tan^{-1}(\frac{2sr}{1}) - \tan^{-1}(\frac{2sr}{1 - r^2})$$

Now consider solving for the transfer function of the base displacement to output force. First, rerognize that the force transmitted to the mass is

$$f_t = m\ddot{x} = C(\dot{y} - \dot{x}) + K(\dot{y} - x)$$

Laplace Transform:

$$F_{t}(s) = c(sY(s) - sX(s)) + K(Y(s) - X(s)) = (cs+K)[Y(s) - X(s)]$$

Substituting our previous expression for Xis) to eliminate the Xis) term:

$$F_{t}(s) = (cs+k) \left[ Y(s) - \frac{cs+k}{ms^2+cs+k} Y(s) \right] = (cs+k) \frac{ms^2}{ms^2+cs+k} Y(s)$$

So the output force to base displacement is

$$\frac{F_{t}(s)}{Y(s)} = \left(cs+k\right) \frac{ms^2}{ms^2+cs+k}$$

But we typically divide by K to form a dimensionless quantity

$$\frac{F_{t(s)}}{KY(s)} = \frac{Cs+K}{K} \frac{ms^2}{ms^2+Cs+K}$$

Force Transmissibility

Dividing numerator + denomenator by m

$$\frac{F_{t}(s)}{KY(s)} = \frac{25\omega_{n}s + \omega_{n}^{2}}{\omega_{n}^{2}} \frac{s^{2}}{s^{2} + 25\omega_{n}s + \omega_{n}^{2}}$$

Substituting s=jw

$$\frac{F_t(j\omega)}{KY(j\omega)} = \frac{25\omega_n\omega_j + \omega_n^2}{\omega_n^2} \frac{-\omega^2}{-\omega^2 + 25\omega_n\omega_j + \omega_n^2}$$

Dividing numerator + denomenator by wh, we get

$$\frac{F_{\epsilon}(j\omega)}{KY(j\omega)} = \left(2srj+1\right) \frac{-r^2}{1-r^2+2srj}$$

The force transmissibility magnitude and phase are


$$\left| \frac{F_{t}(j\omega)}{K Y(j\omega)} \right| = \frac{F_{t}}{K Y} = r^{2} \sqrt{\frac{45^{2}r^{2}+1}{(1-r^{2})^{2}+45^{2}r^{2}}}$$


This can be used to calculate the SS amplitude of the force transmitted to the mass due to a sinusuidal input with amplitude Y.


$$\phi = \angle (-25r^3j - r^2) - \angle (1-r^2 + 25rj) = \tan^{-1}(25r) - \tan^{-1}(\frac{25r}{1-r^2})$$
 (same as disp. trans.)

Note, the force + displacement transmissibilities are related by

Displacement and Force Transmissibility







Displacement Transmissibility

$$\frac{X}{Y} = \sqrt{\frac{45^2r^2 + 1}{(1-r^2)^2 + 45^2r^2}}$$


- Maximum base motion is transferred to mass around r=1 (at resonance)
- · Below r=VZ, the base motion is amplified
- · Above r= 12, the base motion is attenuated
- · As I decreases, the potential amplification increases
- · As rincreases beyond 12, the displacement transmissibility decreases

Force Transmissibility

$$\frac{F_{t}}{KY} = r^{2} \sqrt{\frac{45^{2}r^{2} + 1}{(1-r^{2})^{2} + 45^{2}r^{2}}}$$

- · For small values of S, force transmissibility decreases above r=12
- · For large values of 3, force transmissibility increases with increasing r.
- · For small values of 3, a peak in force transmissibility is found near r=1.

Base Excitation Example p. 13.3



Machine A causes floor to vibrate with amplitude of 0.01m. For machine B, mass = 1500 kg, stiffness =  $2 \times 10^4 \, \text{N/m}$ , damping ratio = S = 0.04. Find max force transmitted to machine B @ resonance.

The frequency ratio at resonance for a 200 order system is

$$r = \frac{\omega_r}{\omega_n} = \frac{\omega_n \sqrt{1-252^2}}{\omega_n} = \sqrt{1-232} \Rightarrow r = \sqrt{1-2(0.04)^2} = 0.998$$

The force transmissibility is given by

$$\frac{F_t}{KY} = r^2 \sqrt{\frac{45^2r^2 + 1}{(1-r^2)^2 + 45^2r^2}} = 0.998^2 \sqrt{\frac{4(0.04)^2(0.998)^2 + 1}{(1-0.998^2)^2 + 4(0.04)^2(0.998)^2}} = 12.499$$

So the transmitted force is