Introduction to Chapter 9
Review Complex Numbers
Frequency Response of First Order Systems

Frequency Response - Lecture 1

ME3050 - Dynamics Modeling and Controls

April 19, 2020

Frequency Response of First Order Systems

Lecture 1- Frequency Response of First Order Systems

- Introduction to Chapter 9
- Review Complex Numbers
- Frequency Response of First Order Systems
- The Bode Plot

Harmonic Input Function

The term **frequency response** is used to describe a system's response to a periodic input. Frequency response analysis focuses on a system's response to *harmonic* input such as sines and cosines. The input (forcing) function is written below.

$$f(t) = Asin(\omega t)$$

Amplitude of the Input, A (N)

Frequency of Input, ω ($\frac{rad}{s}$)

Why Study Frequency Response?

Why do we care about the way a system responds to harmonic excitation? Why is **frequency analysis** important?

•

•

•

What causes harmonic (or sinusoidal) excitation in the real world?

•

•

•


Harmonic Input Function Why Study Frequency Response? Frequency Response and Transfer Function

Frequency Response and Transfer Function

A linear, time-invariant (LTI) system has a **transfer function** T(s) that describes the **input-output** relationship of the system. Under sinusoidal excitation (input) with frequency ω if the system is stable the transient affects in the response (output) will eventually disappear leaving the **steady state sinusoidal response** of the same frequency as the input but with a phase shift w.r.t. the input.

The Complex Plane

In an underdamped system the roots of the characteristic polynomial are complex. Before we proceed we need to review some rules of arithmetic and complex numbers.



Cartesian Representation:

$$P = x + iy$$

Polar Representation:

$$\mathbf{P} = |\mathbf{P}| \angle \theta$$

Exponential Representation:

$$\mathbf{P} = |\mathbf{P}|e^{j\theta} = |\mathbf{P}|(\cos\theta + j\sin\theta)$$

Complex Number Algebra

Consider two points P_1 and P_2 on the complex plane.

$$\mathbf{P_1} = x_1 + jy_1 \text{ and } \mathbf{P_2} = x_2 + jy_2$$

Addition:
$$P_1 + P_2 = (x_1 + x_2) + j(y_1 + y_2)$$

Multiplication:
$$P_1P_2 = |P_1P_2| \angle (\theta_1 + \theta_2)$$

Division:
$$\frac{P_1}{P_2} = (x_1 + x_2) + j(y_1 + y_2)$$

Frequency Response of First Order Systems Obtain the Transfer Function Sinusoidal Input Function Steady State Time Response Amplitude Ratio

Frequency Response of First Order Systems



Consider our $1^{\underline{st}}$ order mass damper system.

$$m\dot{v} + cv = f(t)$$
 with a **time constant** $\tau = \frac{m}{c}$

The system is commonly re-written as shown below.

$$m\dot{v} + cv = f(t) \rightarrow \tau \dot{y} + y = f(t)$$

Frequency Response of First Order Systems Obtain the Transfer Function Sinusoidal Input Function Steady State Time Response Amplitude Ratio Amplitude Ratio and Phase Angle

Obtain the Transfer Function

$$\tau \dot{y} + y = f(t)$$

Take the Laplace transform of the ODE.

$$\mathcal{L}\{\tau\dot{y}+y\}=\mathcal{L}\{f(t)\}$$

$$\tau(sY(s) + y_0) + Y(s) = F(s)$$
 The initial conditions are zero.

$$T(s) = \frac{Y(s)}{F(s)} = \frac{1}{\tau s + 1}$$
 First Order Transfer Function

This considers a generalized input function f(t) and zero ICs.

Frequency Response of First Order Systems Obtain the Transfer Function Sinusoidal Input Function Steady State Time Response Amplitude Ratio Amplitude Ratio and Phase Angle

Sinusoidal Input Function

Our model is now excited by a sinusoidal input (forcing) function.

$$\tau \dot{y} + y = f(t) = A \sin(\omega t)$$

Take the Laplace Transform of the equation.

$$\tau s Y(s) + Y(s) = \frac{A\omega}{s^2 + \omega^2}$$

Solve for Y(s) and expand.

$$Y(s) = \frac{A\omega}{(s^2 + \omega^2)(\tau s + 1)} = \frac{C_1}{\tau s + 1} + \frac{C_2 s}{(s^2 + \omega^2)} + \frac{C_3 \omega}{(s^2 + \omega^2)}$$

Now solve for the coefficients.

$$C_1 = rac{A\omega au^2}{1 + \omega^2 au^2} ~~, ~~ C_2 = rac{-A\omega au}{1 + \omega^2 au^2} ~~, ~~ C_3 = rac{A}{1 + \omega^2 au^2}$$

Substituting and take the inverse Laplace transform.

$$y(t) = rac{A\omega au}{1+\omega^2 au^2}ig(e^{rac{-t}{ au}}-cos\omega t + rac{1}{\omega au}sin\omega tig)$$

Steady State Time Response

$$y(t) = rac{A\omega au}{1+\omega^2 au^2}ig(e^{rac{-t}{ au}}-cos\omega t + rac{1}{\omega au}sin\omega tig)$$

After some amount of time passes, the transient term will disappear leaving just the sinusoidal terms.

$$y(t) = \frac{A}{1+\omega^2 au^2} (\sin \omega t - \omega au \cos \omega t)$$

This is re-written as a single sinusoidal term with a phase shift.

Steady State Frequency Response of First Order System

$$y(t) = \frac{A}{\sqrt{1+\omega^2\tau^2}} \sin(\omega t + \phi)$$
 , $\phi = -\tan^{-1}\omega \tau$

Frequency Response of First Order Systems Obtain the Transfer Function Sinusoidal Input Function Steady State Time Response Amplitude Ratio Amplitude Ratio and Phase Angle

Amplitude Ratio

$$y(t) = \frac{A}{\sqrt{1+\omega^2\tau^2}} \sin(\omega t + \phi)$$
 , $\phi = -\tan^{-1}\omega \tau$

Notice that the system responds at the same frequency as the input but with a different amplitude and a phase shift. The ratio of the response amplitude to the input amplitude is called the **amplitude ratio**, **M**.

$$M = \frac{\frac{A}{\sqrt{1+\omega^2\tau^2}}}{A} = \frac{1}{\sqrt{1+\omega^2\tau^2}}$$

Fortunately we can find the **amplitude ratio** and **phase shift** directly from the transfer function. Recall the transfer function we derived.

$$T(s) = \frac{1}{\tau s + 1} \quad \text{let } s = j\omega \qquad \Longrightarrow \qquad T(j\omega) = \frac{1}{\tau j\omega + 1}$$
$$|T(j\omega)| = \frac{|1|}{|\tau j\omega + 1|} = \frac{1}{\sqrt{(\tau \omega)^2 + 1^2}} = \frac{1}{\sqrt{1 + \tau^2 \omega^2}} \qquad \text{Look familiar?}$$

Amplitude Ratio and Phase Angle

$$\begin{split} |T(j\omega)| &= \frac{1}{\sqrt{1+\tau^2\omega^2}} = M \\ & \angle T\left(j\omega\right) = \angle 1 - \angle\left(1+j\omega\tau\right) = \tan^{-1}\left(\frac{0}{1}\right) - \tan^{-1}\left(\frac{\omega\tau}{1}\right) = -\tan^{-1}\left(\frac{\omega\tau}{1}\right) = \phi \end{split}$$

Substitute $s=j\omega$ into the transfer function and solve for the magnitude and phase angle of this complex number which represent the magnitude ratio and phase shift.

Therefore the steady state response is written as follows.

$$y_{ss}\left(t\right) = A|T\left(j\omega\right)|sin\left(\omega t + \angle T\left(j\omega\right)\right) = MAsin\left(\omega t + \phi\right)$$

Wasn't that fun? Can you believe we used to do that on the board?!?!

Introduction to Chapter 9
Review Complex Numbers
Frequency Response of First Order Systems

Frequency Response of First Order Systems Obtain the Transfer Function Sinusoidal Input Function Steady State Time Response Amplitude Ratio Amplitude Ratio and Phase Angle

References

 System Dynamics, Palm III, Third Edition - Chapter 8 -System Response in the Time Domain