

# Eachine Pro DVR

## Specification

1. size:41mm\*32.9mm\*9mm
2. weight:only 9.5g
3. Operating Voltage:DC 5V
4. Video Format:PAL/NTSC
5. Video Output Vize:  
VGA(640\*480px) D1(720\*480)HD (1280\*480)
6. Light Frequency:50HZ/60HZ
7. Compress Format:MJPEG
8. Records Frame rate :30 Frames
9. Max support 32gTF Card

## Video recording

1. LED1 lights lit after power
2. Short press “▶” one time, The LED1 flashing it starting video recording,Image 1
3. Short press “▶” once again, The led1 stop flashing ,stopped Video recording, Image 2
4. Long press the “■” button to enter the recording sub menu option, see Figure 3



Image 1




Image 2




Image 3

## Replay mode

1. Hold pressing “◀” for 3 seconds to enter into replay mode,Image 4.
2. please shorts press “◀” and “▶” to select the video, and press “■” to play or pause, press “◀” to forward and “▶” to Rewind when playing. And hold pressing “■” enter into Submenu, include “delete video” “volume set” hold pressing “■” again to exiting submenu and replay mode,Image 5




Image 4




Image 5

## Main menu

1. Short press “▶” to enter into Main menu
2. Format the memory card
3. Interface language selection
4. Restore default settings
5. Display frequency
6. TV output system
7. press “◀” to prev “▶” to next, press “■” to Enter
8. Hold pressing “■” to exiting Main menu



## Wiring diagram

