

## **CH340G Driver Installation Guide**


Go to Device Manager, right click on USB2.0-Serial and click Properties.




## After USB2.0-Serial window appear, click on Update Driver button.




Click on Browse my computer for driver software button.



Click on the Browse button. Then locate the WCH.CN folder and press OK button.



## Then press Next button.



Now your device is ready to be used.

