

ie-SRS CMDR Hub

MOBILE COMMANDER APP

Users Guide & Field Operations Manual

For Base Commanders & Field Operations Teams

Real-time SONAR Alerts, Mobile Messaging & Incident Response

Generated: September 07, 2026

Version: 1.0

TABLE OF CONTENTS

- 1. Platform Overview & Quick Start
- 2. Home Screen & Navigation
- 3. SONAR Alert Composer & Notification Center
- 4. Live Map & Real-Time Operations
- 5. Mission Impact & Acknowledgment System
- 6. Mobile Messaging & Comms Log
- 7. Scenario Builder & Playback
- 8. Settings & Configuration
- 9. Field Workflows & Best Practices
- 10. Troubleshooting & Emergency Procedures

1. PLATFORM OVERVIEW & QUICK START

What is CMDR Hub?

The ie-SRS CMDR Hub is a mobile companion app for base commanders and field operations teams. It provides real-time situational awareness during shore facility outages and energy resilience incidents. The CMDR Hub connects to the ie-SRS platform via secure messaging, allowing commanders to:

- Receive & acknowledge SONAR outage alerts in real time
- Compose custom SONAR alerts for other commanders
- View live interactive map of affected installations
- Track mission impact and critical asset status
- Send mobile-to-mobile encrypted messages with team members
- Build & replay incident scenarios for training
- Log all communications for compliance & after-action reviews

Quick Start (First Time Setup)

1. **Launch CMDR Hub** — Open from home screen or app drawer
2. **Grant Permissions** — Allow location (for map), microphone (optional for voice notes)
3. **Pair with ie-SRS ADMIN** — Scan QR code in ADM-10 (CMDR Mobile) or manually enter pairing code
4. **Set Display Name** — Your name as it appears to other commanders
5. **Configure Notifications** — Choose alert sound, vibration, notification method
6. **Ready to Go** — Home screen shows status, quick actions, and active alerts

2. HOME SCREEN & NAVIGATION

The Home Screen

When you open CMDR Hub, the home screen displays:

Status Bar (Top): Shows connection status (green dot = connected), your display name, and pairing info. A red dot indicates connection lost.

Hero Alert Card: If an active SONAR alert exists, it displays prominently with timeline, affected facilities, and quick action buttons (Acknowledge / Dismiss / Details).

Quick Action Tiles: 5-icon grid for common tasks:

- SONAR Composer — Create & send custom SONAR alerts
- Live Map — Real-time installation map with outage markers
- Mission Impact — View affected assets & impact timeline
- Comms — Message other commanders & view comms log
- Scenarios — Build & replay incident training scenarios

Tab Navigation

Bottom of screen shows 5 tabs (swipe or tap to switch):

1. **Home** — Dashboard with alerts & quick actions
2. **Map** — Live Leaflet map, zoom/pan, threat overlays
3. **Impact** — Mission impact timeline, asset health, criticality filter
4. **Comms** — Mobile-to-mobile encrypted messaging with team
5. **Settings** — Pairing, display name, notification prefs, transport mode

3. SONAR ALERT COMPOSER & NOTIFICATION CENTER

Receiving a SONAR Alert

When an outage is detected at a naval base:

1. Your phone vibrates & buzzes (configurable in Settings)
2. A banner notification appears at top of home screen (red for critical, amber for warning)
3. If app is closed, notification appears on lock screen
4. Tapping notification opens CMDR Hub & scrolls to alert card

The alert card shows:

- Facility name & location (with map marker)
- Outage severity (P1 critical, P2 major, P3 minor, Test)
- Time since outage began (elapsed duration)
- Affected equipment count & asset types
- Suspected cause (if available from SONAR analysis)

Acknowledging an Alert

Click the **ACKNOWLEDGE** button on the alert card. This:

- ✓ Sends your acknowledgment back to ie-SRS ADMIN platform
- ✓ Records your name & acknowledgment time in the comms log
- ✓ Notifies ADMIN team that you have seen the alert
- ✓ Alert card remains visible but changes color to indicate acknowledged status

Composing a SONAR Alert

Click **SONAR Composer** tile to create an alert to send to other commanders:

1. **Select Facility** — Choose from dropdown list of naval bases
2. **Choose Severity** — P1 (critical/red), P2 (major/amber), P3 (minor/blue), Test (cyan)
3. **Enter Title** — Brief description (e.g., "Shore Power Loss – Building 47")
4. **Write Message** — Detailed description of outage & impact
5. **Set Affected Assets** — Equipment count, asset types (AMI, FRCS, UPS, etc.)
6. **Send** — Alert is routed to all paired commanders' devices instantly

Alerts sent from CMDR Hub are logged in Comms Log (ADM-09) on ie-SRS ADMIN.

4. LIVE MAP & REAL-TIME OPERATIONS

Using the Live Map

Tap the **Live Map** tab to view real-time locations of active outages:

Map Features:

- Leaflet interactive map centered on San Diego region (Naval Base San Diego, NASNI Coronado, MCAS Miramar)
- Installation markers (color-coded by status): Green (nominal), Amber (alert), Red (critical), Gray (offline)
- Tap marker → see facility name, address, current status, affected asset count
- Zoom in/out with pinch gesture or +/- buttons
- Pan by dragging map with two fingers

Map Overlays (tap to toggle):

- Storm Threat — Real-time weather overlay (if weather feed available)
- FRCS Zones — Facility cybersecurity exposure areas
- Convoy Routes — Logistics routes (Harbor Drive, Coronado Bridge, I-15)
- Microgrid Boundaries — Smart grid sector boundaries

Isometric Facility View

Tap the **ISO Map button** (bottom left) to switch to isometric 3D view of selected facility:

- Shows building layout, equipment positions, power distribution
- Tap & drag to rotate view
- Pinch to zoom in/out
- Hover over equipment icons to see status
- Useful for detailed facility planning & post-incident analysis

5. MISSION IMPACT & ACKNOWLEDGMENT SYSTEM

Understanding Mission Impact

The **Mission Impact** tab shows a timeline of how an outage affects critical assets:

Timeline View:

- Outage starts → $t=0$ (red marker on timeline)
- As time elapses, impact expands (more systems affected, cascading failures)
- Shows which assets fail first, which are most critical
- Estimated recovery time (if repair work is underway)

Asset Health Scores:

- Green (healthy): Equipment nominal, power stable
- Amber (stressed): Equipment operating in degraded mode
- Red (critical): Equipment offline or failing

Filters:

- View by asset type: AMI (smart meters), FRCS (control systems), UPS, Generators
- View by facility: Switch between different bases
- View by criticality: Show only mission-critical assets

Acknowledgment Timeline

As you & other commanders acknowledge alerts, a separate timeline appears showing:

- Commander name & timestamp of acknowledgment
- Response time (how long after outage alert was acknowledged)
- Number of acknowledged vs. unacknowledged commanders
- Useful for measuring command response & readiness

6. MOBILE MESSAGING & COMMS LOG

Secure Mobile-to-Mobile Messaging

Tap the **Comms** tab to send encrypted messages to other paired commanders:

1. **Select recipient** from list of connected commanders
2. **Type message** in compose box at bottom
3. **Send** — Message appears as blue bubble on your screen, green on theirs
4. Messages are routed through ie-SRS event bus (GitHub or same-browser, see Settings)

Message Types:

- One-on-one — Direct messages between commanders
- Broadcast — Message all connected commanders at once
- System messages — Alerts, status updates from ie-SRS platform

All messages are logged & timestamped for compliance, incident review, & training.

Reviewing Comms Log

The **Comms Log** (visible in ie-SRS ADMIN, ADM-09) includes:

- All SONAR alerts sent/received
- All commander acknowledgments & timestamps
- All mobile-to-mobile messages with full transcript
- System messages & alerts from ie-SRS platform

Export log as CSV or PDF for:

- After-action reviews (AARs)
- FISMA compliance documentation
- Incident investigation & forensics
- Command training & readiness assessment

7. SCENARIO BUILDER & PLAYBACK

Building Training Scenarios

Tap **Scenario Builder** to create custom training scenarios:

1. **Name the scenario** — e.g., "Hurricane Sandy Simulation"
2. **Set initial facility state** — Select facility, choose initial outage severity
3. **Define timeline events** — Add key events (repair begins, equipment restored, etc.)
4. **Configure cascading failures** — Which systems fail if power not restored by T+X minutes
5. **Set message sequence** — Pre-write alerts & messages to be sent at specific times
6. **Save & test** — Scenario is saved locally; tap "Play" to run simulation

Scenarios can be:

- Run offline (for personal training)
- Shared with other commanders (for group exercises)
- Broadcast from ie-SRS ADMIN (for base-wide drills)

Playing a Scenario

When you play a scenario:

- Timeline auto-advances, showing alerts at scheduled times
- Map updates dynamically as facilities' status changes
- Messages appear in Comms feed as if real outage occurring
- Your acknowledgments are logged (for after-action review)
- Full playback can be paused, resumed, or replayed

Use scenarios for:

- Training new commanders on response procedures
- Testing command & control communication chains
- Validating alert routing & notification systems
- Conducting exercises without affecting real systems

8. SETTINGS & CONFIGURATION

Critical Settings

Tap the **Settings** tab to configure:

Pairing & Identity:

- Display Name — How you appear to other commanders
- Pairing Code — QR code or manual code to link with ie-SRS ADMIN
- Device ID — Unique identifier for this mobile device

Notifications:

- Alert Sound — Choose notification sound or silent
- Vibration — Enable/disable haptic feedback
- Lock Screen Alerts — Show notifications on lock screen
- Do Not Disturb — Quiet hours (e.g., 22:00-06:00)

Transport & Sync:

- Mode: "Same Browser" (for testing) or "GitHub" (for cross-device)
- If GitHub: Requires GitHub personal access token & thompson-collab/ie-SRS org access
- Sync Status: Shows last sync time & any pending messages

Privacy & Advanced:

- Location Sharing — Allow map to show your location (optional)
- Clear Comms Cache — Delete local message history
- Reset App — Clear all settings & unpair from ie-SRS

9. FIELD WORKFLOWS & BEST PRACTICES

Typical Field Response (Outage Notification)

T+0:00 (Outage Detected)

1. Phone buzzes — SONAR alert received
2. Open CMDR Hub → read alert card (facility, severity, affected assets)
3. Tap ACKNOWLEDGE → sends acknowledgment to ie-SRS ADMIN

T+0:30 (Situational Awareness)

1. Switch to Map tab → locate affected facility on live map
2. Zoom & pan to see surrounding bases, convoy routes, weather threat overlay
3. Check Impact tab → review mission-critical assets affected, estimated recovery time

T+2:00 (Coordination)

1. Open Comms → send message to adjacent base commander ("Standby for mutual aid")
2. Receive response → reply with ETA for repair crew
3. All messages logged for after-action review

T+4:00 (Resolution)

1. Receive "Outage Resolved" message from ie-SRS ADMIN
2. Alert card disappears; status returns to green
3. Tap Impact tab to review timeline of events & command response

Field Best Practices

- **Acknowledge Quickly:** Acknowledge alerts within 30 seconds to show readiness
- **Use Map Before Messaging:** Check live map first to understand geographic context
- **Broadcast Messages to Group:** For facility-wide updates, use broadcast feature
- **Test Alerts Weekly:** Send test SONAR alerts to verify notification settings
- **Review Comms Log Weekly:** Check ie-SRS ADMIN ADM-09 for compliance & audit trail
- **Run Monthly Scenarios:** Use scenario builder for ongoing commander training
- **Keep Device Charged:** Mobile CMDR Hub only works if battery alive; charge overnight
- **Verify Pairing Regularly:** Check Settings to ensure CMDR Hub is still paired with ie-SRS

10. TROUBLESHOOTING & EMERGENCY PROCEDURES

Common Issues

No alerts received: Check connection dot in top nav (should be green). Verify Settings → Pairing Code is valid. Restart app. Check ie-SRS ADMIN to see if alerts are being sent.

Messages not sending: Check Status dot (red = offline). Verify GitHub token if using GitHub transport mode. Check Sync Status in Settings.

Map not loading: Requires internet. Check WiFi or cellular. Try zooming in/out. Clear app cache in iOS Settings.

Scenarios won't play: Verify at least one scenario is saved (tap Scenario Builder). Restart app if stuck on loading.

Notifications silenced: Check Settings → Notifications (toggle on). Check iOS Do Not Disturb (device-level, not app-level). Verify alert sound is not set to None.

Emergency Procedures

If app crashes:

1. Force close app (Settings → Apps → ie-SRS → Force Close)
2. Clear app cache (Settings → Apps → ie-SRS → Storage → Clear Cache)
3. Relaunch app
4. If still broken: Delete & reinstall from App Store

If disconnected from ie-SRS (red dot in nav):

1. Check WiFi/cellular connection
2. Verify GitHub token is valid (if using GitHub transport)
3. Try toggling Settings → Transport Mode (switch to "Same Browser" to test)
4. Restart mobile device
5. Contact ie-SRS ADMIN team on separate phone/radio

If device lost/stolen:

1. Contact ie-SRS ADMIN immediately (ADM-01)
2. Admin revokes your CMDR device from ie-SRS (removes pairing)
3. Request new device & pairing code
4. Comms log is retained on ie-SRS ADMIN (not deleted)

Support & Resources

In-App Help: Tap ? (question mark) in top nav for quick tips & keyboard shortcuts

ie-SRS ADMIN Support: Contact your base's ie-SRS platform administrator (ADM-01)

Field Support Radio: Use tactical radio to reach ie-SRS Command Center (COMM #2)

Version: ie-SRS v1.0 (SONAR • BLACKSTART • Grid Resilience)

This guide reflects ie-SRS CMDR Hub as of {datetime.now().strftime('%B %Y')}. App features and workflows subject to change with platform updates.