

SmartBrew 3000 Manual

SmartBrew Coffee Maker - User Manual

The SmartBrew 3000 supports three brewing modes: Standard, Bold, and Cold Brew.

To descale the machine, run the descaling cycle every 60 brew cycles using the descale button on the top panel.

Troubleshooting

If the machine displays Error 4, this indicates the water reservoir is not seated correctly. Remove and reinsert the reservoir firmly until it clicks.

If brewing takes longer than 5 minutes, the machine may need descaling.

Warranty Information

The SmartBrew 3000 comes with a 2-year limited warranty covering manufacturing defects.

The warranty does not cover damage caused by using non-filtered water or third-party descaling agents.