

Once you've selected the disk you want to install System 6 on, move the arrow to the "Easy Update" button and click the mouse button. Installation will begin. You'll be prompted to switch disks a few times—just remove the disk the computer is finished with, and insert the next disk. The IIGS will automatically detect that you've inserted the new disk and continue—there's no need to press Return or click the on-screen "Ok" button.

 Note!

If the Easy Update button is "dimmed" (i.e., the words "Easy Update" are displayed in gray instead of in black), you're probably trying to install System 6 on the disk you started up from. Start up from the Installer disk (or from the System disk containing the Vulcan driver, if you have a Vulcan hard drive) and try again.

After installation is complete, set the Startup Slot back to its usual value ("Scan" or "Slot 7" in most systems) using the Control Panel. Hold down ⌘ and Control while you press and release Reset to restart the computer and enter the world of System 6.

If you have an AE Vulcan hard drive, an AE High Density 3.5" drive, a RamFAST/SCSI card, or any other third-party device requiring a driver (such as Hewlett-Packard printers) install their drivers according to the directions that came with the device. (If the driver software is old, it might be a good idea to contact the manufacturer to make sure the driver is compatible with System 6 before installing it.)

You *can* install additional system software features right away, as well, but we suggest you get used to System 6's basic features before you add any other features, especially if you're fairly new to the IIGS. Read through this manual (particularly the chapter on the Finder) and then, when you're comfortable with System 6, install additional features like Macintosh disk compatibility, networking, sounds, and drivers for your other peripherals like CD-ROM.

Installing Additional Features

As we mentioned in the last section, the Installer can install many System 6 updates, not just the "Easy Update." Once you're familiar with the basic System 6 features, you can install additional features as easily as you installed the original system software.

Remember, each additional feature you install needs more memory and more disk space. If you plan to use all of System 6's features, we suggest a minimum of 2 megabytes of RAM—and the more, the better.

To install additional System 6 features, get into the Installer as described in the section above and choose a disk using the "Change Disk" button. Then click the "Customize" button. A list of available system updates (Figure 2B) will appear. Use the scroll bar to the right of the list to look at the entire list of updates; select the updates you want to install from the list.

To select more than one update to be installed at once, hold down the ⌘ key while selecting the second and subsequent updates. (The same maneuver can also be used to unselect an update that you selected accidentally.)