

General

The General control panel (Figure 9D) allows you to change a number of IIGS system settings, all of which are controlled by a pop-up menu. (The default, or normal, settings are displayed in *italic type* in the menu.)




Figure 9D—General Control Panel

- *Menu Blinking*: Controls how many times an item in a pull-down menu flashes after you select it.
- *Cursor Flash*: Controls how quickly the insertion point flashes. Also controls the flashing cursor in some (but not all) older, 8-bit programs, especially BASIC ones.
- *System Speed*: We suggest keeping this set to “Fast” at all times.
- *Mouse Speed*: Controls how far you have to move the mouse to move the pointer across the screen. The faster the Mouse Speed, the *less* you have to move it. (ROM 01 IIGS owners can choose two settings here; ROM 03 owners have more choices.)
- *Double Click*: Controls how fast you must click the mouse for the computer to recognize two clicks as a double-click instead of two separate click. Set this too fast, and the computer may not recognize your double-clicks; set it too slow, and the computer may recognize a double-click when you really intended two single clicks.
- *Monitor*: Determines the display language for the screen. Most of you are ‘murricans, so the default setting of “U.S.A.” should be fine.
- *Keyboard*: Determines the keyboard layout. “U.S.A.” should be fine for most of you.
- *Translation*: Controls keyboard translation (for foreign and special characters). If a program isn’t responding properly to Option keystrokes, set this option to “None.”