

A Quick Guide to Semiconductors: From Silicon to Circuits

1. MATERIALS CLASSIFIED BY CONDUCTIVITY

CONDUCTORS:
The Electron Superhighways

These materials, like copper and aluminum, have abundant free electrons that allow electric current to flow easily.

SEMICONDUCTORS:
The Smart Gates

Temperature Control:
OK Room (Conductor)

Their conductivity is between conductors and insulators. They act as insulators at 0 Kelvin but conduct at room temperature. Examples include Silicon (Si) and Germanium (Ge).


INSULATORS:
The Electrical Roadblocks

Materials such as wood, plastic, and rubber do not have free electrons, effectively blocking the flow of current.

2. TYPES OF SEMICONDUCTORS: PURE VS. DOPED

INTRINSIC (Pure) SEMICONDUCTORS

These are made of a single, pure element like Silicon. Current is generated when heat provides enough energy to break covalent bonds, creating an equal number of free electrons and "holes".




EXTRINSIC (Impure) SEMICONDUCTORS

N-TYPE: Creating Excess Electrons
Formed by adding pentavalent impurities (5 valence electrons), like Phosphorus, to Silicon. This creates a surplus of free electrons, which become the majority charge carriers.




P-TYPE: Creating "Holes"
Formed by adding trivalent impurities (3 valence electrons), like Aluminum, to Silicon. This results in a deficit of electrons, creating positively charged "holes" which act as majority charge carriers.




3. THE ENERGY BAND THEORY

Understanding Electron Energy Levels:
Electrons in a crystal exist in energy ranges called bands.






Understanding Electron Energy Levels:
Electrons in a crystal exist in energy ranges called bands.

Energy Gaps Determine Conductivity:
The "Forbidden Energy Gap" between these bands dictates if a material conducts.




4. THE PN JUNCTION: HEART OF THE DIODE

Formation of the Depletion Layer:
When P-type and N-type materials are joined, electrons and holes diffuse across the junction, creating a central region with no mobile charge carriers called the depletion layer. This layer establishes a "Barrier Potential".



5. APPLICATION: RECTIFIERS - CONVERTING AC TO DC

What is a Rectifier? An electronic circuit that converts alternating Alternating Current (AC) into one-directional Direct Current (DC), using the one-way current property of diodes.



-DC-