

SMARTPHONE AUTO CLICKER

USER MANUAL

The WINDIN Smartphone Auto Clicker adopts Capacitive Air Mapping Technology, operates completely silently with a maximum tapping speed of up to 99 times per second; its built-in battery supports 10 hours of continuous working time and features a 180° rotatable design to free your hands and efficiently finish repetitive tapping operations.

CONTENTS

1. WHAT’S INSIDE 3

2. TECHNICAL SPECIFICATIONS 4

3. GETTING STARTED 5

4. CHARGING THE CLICKER 6


5. USER & AFTER-SALES GUIDE 7

6. LEGALESE 8

1. WHAT'S INSIDE


WHAT'S INSIDE

- AUTO CLICKER DEVICE



- A. USB Type-C Port: For charging the battery.
- B. Gear+/-: Adjust tapping speed; "+" to increase speed, "-" to decrease speed.
- C. Digital LED: Shows the current gear level and corresponding tapping speed.
- D. Power On/Off: Press briefly to switch the device on or off.
- E. Start/Pause: Press briefly to start operation; press again to pause tapping.
- F. Clicker Head: The core component, designed for silent tapping on the screen.

- USB Type-C Power Cable




- Important Product Information Guide

2. TECHNICAL SPECIFICATIONS

- Capacitive mapping technology, electrostatic click
- Ultra-fast click speed, up to 99 times/second
- Built-in battery, works for over 10 hours
- With LED display, intuitive and clear
- Click head can rotate 180 degrees
- Rechargeable for repeated use
- Simple operation, plug and play
- Universal Type-C port


3. GETTING STARTED

1. Open the Fixing Clip and clamp it on the device to be clicked, Rotate the clicking head to the desired position.



After fixing it to your phone, the tapping head can rotate 180 degrees, allowing you to position the tapping tip over the area that needs clicking.


2. Press the **Power On/Off** Button to turn on the device, and the Digital Display will show an Arabic numeral indicating the current speed gear. If needed, long-press the **Gear + / -** Button to quickly adjust to the desired clicking speed, then press the **Start/Pause** Button to make the device start clicking.



When not in use, press the Power On/Off Button to turn off the device. Once turned on, the device will automatically load the last used memory gear and enter the standby state.

4. CHARGING THE CLICKER

The clicker features a built-in 120mAh Li-Po battery for extended runtime and supports simultaneous use while charging. When battery power is low, the battery indicator flashes red; during charging, the red light stays steadily on; once fully charged, the light turns off.



5. USER & AFTER-SALES GUIDE

Thank you for choosing our Auto Screen Tapper. To ensure an optimal experience and smooth operation, please read through this guide carefully before use.

Troubleshooting & FAQ

If you encounter any issues during operation, please try the following troubleshooting steps:

Device Fails to Power On:

Please ensure the device has sufficient power. We recommend charging it for 1–2 hours using the standard charging cable included in the package before trying again.

No Response to Tapping:

1. Check if the tapping head is securely and flatly attached to the screen.
2. Ensure your phone screen is clean and free of water stains or dust.
3. Some smartphone models have a slight lag in registering inputs. If the tapping speed is set too high, it may result in missing clicks. Simply lower the speed to resolve this.

Connection Disruption / Unresponsive Device:

Make sure the device is fully powered on. Try disconnecting and reconnecting it to your phone, or perform a quick restart on the tapper itself.

Warranty & After-Sales Support

We are committed to providing you with premium after-sales service and support:

12-Month Warranty: We offer a 12-month warranty covering any non-artificial quality defects starting from the date of purchase.

30-Day Return & Replacement Policy: If your product arrives damaged, defective, or with missing accessories, please contact us within 30 days of delivery for a hassle-free replacement or refund.

Customer Support: If you have any questions or require technical assistance during use, please feel free to reach out to us at any time via Amazon Buyer-Seller Messages ("Contact Seller"). Our dedicated support team will respond within 24 hours.

Friendly Reminder: Please keep your Amazon Order ID and the original product packaging safely, as they serve as your proof of purchase for warranty claims. Thank you for your continued support and trust!

6. LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2026 WINDIN. All rights reserved. WINDIN and the WINDIN logo are trademarks or registered trademarks of WINDIN and/or affiliated companies. All other trademarks mentioned in this guide are the property of their respective owners.

WINDIN may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the Smartphone Auto Clicker (the “Product”). Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Product may differ from pictures whether on packaging or otherwise. WINDIN assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

The Product is covered by a 12-month limited warranty against non-artificial quality defects, starting from the date of purchase. If your product arrives damaged, defective, or with missing accessories, you may contact us within 30 days of delivery for a replacement or refund. For warranty claims, please contact us via Amazon Buyer-Seller Messages (“Contact Seller”) with your Amazon Order ID.

LIMITATION OF LIABILITY

WINDIN shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall WINDIN’s liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. WINDIN reserves the right to amend any term at any time without notice.