


# Screen Auto Clicker

## User Manual



# Function Description

1

## Click Head

Core component for tapping the screen.

2

## Type-C Charging Port

Connect the charging cable to recharge the device.

3

## Speed Adjustment

Press [+] to increase clicking speed, press [-] to decrease.

4

## Digital Display Screen

Displays current click rate. Max: 99 clicks/s, Min: 1 click/9s.

5

## Power On / Off

Press once to turn the device on or off.

6

## Start / Pause

Press to start clicking; press again to pause.

7

## Working Indicator

Flashing means the device is working. The faster the clicking speed, the quicker the light flashes.

# Operating Steps

- 1 Open the Fixing Clip and clamp it on the phone you want to click.
- 2 Rotate the Click Head to the desired clicking position.
- 3 Press the Power On/Off Button to turn on the device. The Digital Display will show the current gear speed.
- 4 Long-press Gear [+] / [-] to quickly adjust to your desired clicking speed.
- 5 Press the Start/Pause Button — the device begins clicking.
- 6 When not in use, press the Power Button again to turn off. Next time you boot, the last used gear is automatically loaded.
- 7 Built-in battery, supports charging while in use. When the battery is low, the indicator flashes red; solid red while charging; off when fully charged.

## Tip

- The device automatically remembers the last gear setting on reboot.
- Each click is accompanied by a working indicator light flash.
- Charge fully before first use to ensure optimal battery performance.

# Specifications / Cautions / Maintenance

## Specifications

|                           |                  |
|---------------------------|------------------|
| <b>Net Weight</b>         | 20 g             |
| <b>Package Weight</b>     | 49.6 g           |
| <b>Product Dimensions</b> | 89 × 18 × 33 mm  |
| <b>Package Dimensions</b> | 126 × 85 × 27 mm |
| <b>Battery Capacity</b>   | 120 mAh          |
| <b>Battery Life</b>       | 10 – 12 hours    |
| <b>Input Voltage</b>      | 5V / 1A          |
| <b>Power Consumption</b>  | 2.5 W            |
| <b>Charging Port</b>      | Type-C           |

## Cautions

- Do not use in humid environments to avoid short-circuit damage.
- Keep away from children to prevent swallowing small parts or improper use.

## Maintenance

- Wipe with a dry, soft cloth; avoid chemical cleaners.
- For long-term storage: fully charge before storing, and recharge periodically to extend product life.

## Packing List

- Auto Clicker × 1
- Type-C Charging Cable × 1
- User Manual × 1

# Frequently Asked Questions

**Q Why cannot the device be powered on?**

**A** If the device fails to power on, connect the data cable and charger to charge the clicker. It takes 30 minutes to fully charge.

**Q Why isn't the clicker working after turning it on?**

**A** Two possible reasons: (1) It will only start working after you tap the Start button once setup is complete. Check the indicator light above the click head — flashing means the device is running. (2) If the light is flashing but no action appears on your phone, the clicking speed may be set too fast. Some phones have slow screen response; just reduce the clicking speed.