


Jan -28-2026

Recap: Unsteady state mass transfer

$$\frac{\partial C_A}{\partial t} = r_A - \frac{\partial N_A}{\partial z} \quad (1D)$$

Last lecture we solved evaporation into stagnant B (Arnold problem)  
 We will see examples of reaction

Example 1 Reactive wall in a conduit



I. Note difference in areas

$$A_{tube} N_A \Big|_z - A_{tube} \frac{\partial N_A}{\partial z} \Big|_{z=0} + A_{wall} \cdot r_A = A_{tube} \Delta z \cdot \frac{\partial C_A}{\partial t}$$

$$A_{tube} = \frac{\pi D^2}{4}$$

$$A_{wall} = \Delta z \cdot \pi D$$

$$\left. \begin{array}{l} A_{tube} \\ A_{wall} \end{array} \right\} \Rightarrow M.B. \text{ becomes} \quad \frac{\pi D^2}{4} \cdot \left( - \frac{\partial N_A}{\partial z} \right) + \frac{4 \pi D \cdot r_A}{D^2} = \frac{\partial C_A}{\partial t} \cdot \frac{\pi D^2}{4}$$

$$-\frac{\partial N_A}{\partial z} + \frac{4}{D} r_A = \frac{\partial C_A}{\partial t}$$

$$-\frac{\partial N_A}{\partial z} + \frac{4k}{D} (C_{As} - C_A) = \frac{\partial C_A}{\partial t}$$

## II. Link with flux eq

$$N_A = -D_{AB} \frac{\partial C_A}{\partial z} + C_A \cdot v_m$$

$$\frac{\partial N_A}{\partial z} = -D_{AB} \frac{\partial^2 C_A}{\partial z^2} + \cancel{C_A \frac{\partial v_m}{\partial z}} + \frac{\partial C_A}{\partial z} \cdot v_m$$

Const  $v_m$

## III Combine I & II

$$\frac{\partial C_A}{\partial t} = D_{AB} \frac{\partial^2 C_A}{\partial z^2} - v_m \cdot \frac{\partial C_A}{\partial z} + \frac{4k}{D} (C_{As} - C_A)$$

B.C.

$$z=0 \quad C_A = C_{A0} \quad z=L \quad C_A = C_A(z) \quad (\text{to be determined})$$

Practically, question is: given  $k, v_m, D$ , how to determine Length of tube so that  $C(z=L)$  lower than threshold?

To solve we need simplifications

- ①  $v_m \gg v_{Ad}$  Convection  $\gg$  diffusion
- ② Steady state (long-term  $\text{CO}_2$  removal)

$$v_m \frac{dC_A}{dz} = -\frac{4k}{D} (C_{As} - C_A) \quad \text{Solve ODE}$$

$$-\frac{dC_A}{C_{As} - C_A} = \frac{4k}{v_m D} dz$$

↖ diameter, not  $D_{AB}$

Integrate

$$\int_{C_{A0}}^{C_A(z)} -\frac{dC_A}{C_{As} - C_A} = \int_0^z \frac{4k}{v_m D} dz'$$


$$\Rightarrow C_A(z) = C_{A,s} - (C_{A,s} - C_{A0}) \exp\left(-\frac{4k}{v_m D} \cdot z\right)$$

Insights: With reaction

1) At the end of pipe  $\rightarrow C_0 \geq C_{A,S}$

$C_{A,S}$  must be low to allow efficient absorption

2) Concentration decays exponentially




$$\text{decay length} \approx \frac{Dv_m}{4k} \quad \frac{m \cdot m/s}{4 \cdot k} \Rightarrow m$$

What is unit of  $k$ ?  $k$  in unit  $[m]/[s]$

3)  $N_A = C_A \cdot v_m \neq \text{constant} !$

Example 3 . Catalyst conversion  $D \rightarrow E$  in a well

Instantaneous conversion  $\rightarrow x_{D0} = 0$



① M, B in control vol

In - Out + Gen = Acc


$$-\frac{\partial N_D}{\partial z} = \frac{\partial C_D}{\partial t}$$

We don't have [gen] in control volume (reaction only at bottom)

② Flux eqn

$$N_D = -D_{DE} \frac{\partial C_D}{\partial z} + \frac{C_D}{C_T} (N_D + N_E)$$

### ③ Relation between $N_D$ & $N_E$



Instantaneous reaction

Instantaneous = Reaction rate controlled by diffusion

Complete = Conversion between D & E follow  
Stoichiometry



$$N_E = -\frac{n}{m} N_D$$