


1 Driving

The X40 is a dual shaft Stepper Motor, where the two shafts are driven independently.

The two shafts are driven by X27 compatible mechanics. Please refer to X27 Specifications for any information not mentioned below.



1.1 X40 pinout




Figure 1: X40 front contacts, top view







Figure 2: X40 front contacts, bottom view

Basics (same as X27):



Signals to drive the X40:

		Coil 1		Coil 2		Coil 1		Coil 2	
		Pin 1(+)	Pin 2 (-)	Pin 4(+)	Pin 3(-)	Pin 5(+)	Pin 6 (-)	Pin 8(+)	Pin 7(-)
EXTERNAL shaft	Clockwise rotation	coil current sequence 							
	Counter Clockwise rotation	Achieved by reversing the above sequence							
INTERNAL shaft	Clockwise rotation					coil current sequence 			
	Counter Clockwise rotation	Achieved by reversing the above sequence							