А	Adress	Instruction			Mnmonics			
АН	AL	byte 1	byte 2	byte 3	LABEL	OPCODE	Operand	
						ORG	0000h	
00	00	CD	XX	XX		CALL	NOME	
00	03	CD	XX	XX		CALL	IREL	
00	06	06	30			MVI B	30	
00	08	0E	30			MVI C	30	
00	Α	16	30			MVI D	30	
00	С	1E	30			MVI E	30	
00	E	2E	30			MVI L	30	
00	10	26	30			MVI H	30	
00	12	0C			:INICIO	INR C		
00	13	79				MOV A	С	
00	14	FE	3A			CPI 3Ah		
00	16	CC	SEC2			CZ SEC2		
00	18	78				MOV A	В	
00	19	FE	36			CPI 36h		
00	1B	СС	SEC1			CZ SEC1		
00	1D	7B				MOV A	Е	
00	1E	FE	3A			CPI 3Ah		
00	20	СС	MIN2			CZ MIN2		
00	22	7A				MOV A	D	
00	23	FE	36			CPI 36h		
00	25	СС	MIN1			CZ MIN1		
00	27	7D				MOV A	L	
00	28	FE	34			CPI 34h		
00	2A	СС	HR2			CZ HR2		
00	2C	7D	1			MOV A	L	
00	2D	FE	3A			CPI 3Ah	_	
00	2F	СС	HR1			CZ HR1		
00	31	CD	XX	XX		CALL ESCR		
00	34	C3	XX	XX		JMP INICIO		
00	37	0E	30		:SEC2	MVI C	30h	
00	39	04				INR B		
00	3A	C9				RET		
00	3B	06	30		:SEC1	MVI B	30h	
00	3D	1C				INR E		
00	3E	C9		1		RET		
00	3F	1E	30		:MIN2	MVIE	30h	
00	41	14				INR D		
00	42	C9		1		RET	1	
00	43	16	30	1	:MIN1	MVI D	30h	
00	45	2C		1		INR L		
00	46	C9		1		RET	1	
00	47	24			:HR1	INR H		
00	48	2E	30			MVIL	30h	
00	4A	C9				RET	3311	
00	4B	7C			:HR2	MOV A	Н	
00	4C	FE	32		2	CPI 32h	- ''	

00	4E	СС	XX	XX		CZ RST	
00	51	C9				RET	
00	52	3E	02		:NOME	MVI A	02h
00	54	D3				OUT 00h	
00	55	3E	07			MVI A	07h
00	57	D3				OUT 01h	
00	58	3E	46			MVI A	46h
00	5A	D3				OUT 01h	
00	5B	3E	52			MVI A	52h
00	5D	D3				OUT 01h	
00	5E	3E	41			MVI A	41h
00	60	D3				OUT 01h	
00	61	3E	4E			MVI A	4Eh
00	63	D3				OUT 01h	
00	64	3E	43			MVI A	43h
00	66	D3				OUT 01h	
00	67	3E	49			MVI A	49h
00	69	D3				OUT 01h	
00	6A	3E	53			MVI A	53h
00	6C	D3				OUT 01h	
00	6D	3E	13			MVI A	43h
00	6F	D3				OUT 01h	
00	70	3E	4F			MVI A	4Fh
00	72	D3				OUT 01h	
00	73	C9				RET	
00	74	3E	14		:ESCR	MVI A	14h
00	76	D3	00			OUT 00h	
00	78	7C				MOV A	Н
00	79	D3	01			OUT 01h	
00	7B	7D				MOV A	L
00	7C	D3	01			OUT 01h	
00	7E	3E	3A			MVI A	3Ah
00	80	D3	01			OUT 01h	
00	82	7A				MOV A	D
00	83	D3	01			OUT 01h	
00	85	7B				MOV A	Е
00	86	D3	01			OUT 01h	
00	88	3E	3A			MVI A	3Ah
00	8A	D3	01			OUT 01h	
00	8C	78				MOV A	В
00	8D	D3	01			OUT 01h	
00	8F	79				MOV A	С
00	90	D3	01			OUT 01h	
00	92	C9				RET	
00	93	3E	14		:IREL	MVI A	14h
00	95	D3	00			OUT 00h	
00	97	3E	30			MVI A	30h
00	99	D3	01			OUT 01h	
00	9B	D3	01			OUT 01h	
00	9D	3E	3A			MVI A	3Ah

00	9F	D3	01		OUT 01h	
00	A0	3E	30		MVI A	30h
00	A2	D3	01		OUT 01h	
00	A4	D3	01		OUT 01h	
00	A6	3E	3A		MVI A	3Ah
00	A8	D3	01		OUT 01h	
00	AA	3E	30		MVI A	30h
00	AC	D3	01		OUT 01h	
00	AE	D3	01		OUT 01h	
00	В0	C9			RET	
00	B1	3E	30	:RST	MVI B	30h
00	В3	0E	30		MVI C	30h
00	B5	16	30		MVI D	30h
00	В7	1E	30		MVI E	30h
00	B9	26	30		MVI H	30h
00	ВВ	2E	30		MVI L	30h
00	BD	C9			RET	-