

Hint/Warning: The Plus symbol "+" is at the silk screen AND copper layer, too! This may cause some problems with isolations or shortcuts, because a grafical line at a copper layer is NOT recognised by the DRC! If you want to avoid this problems, choose the modules with the suffix "_CopperClear" in the name. There the "+" symbol is only at the silk screen layer. But if you get boards without silk screen layer,



Elko_vert_DM16_RM7-5_CrossMark

Experimental Footprint with "cross-marked" +.

> For suggestions and improvements please contact me at bernd.wiebus@gmx.de

KiCAD Footprints of some vertical mounted through hole electrolytic capacitors from the file Elko_ThroughHole_RevB-3_30Dec2011.mod

Author: Oliver Kirsch + Bernd Wiebus / Uedem / Germany / 07 Feb 2011 GNU-GPL NO WARRANTY!

Licence: CC-Zero / Public Domain NO RESTRICTION! NO WARRANTY! http://creativecommons.org/

File: Elka_ThroughHole_RevB-3_30Dec2011.kicad_pcb Sheet:				
Title:				
Size: A4	Date:			Rev:
KiCad E.D.A.				ld: 1/1

