Wm 1)

To To

5

Support the motorcycle in its center bracket. Remove the fin pin (D and slathe shaft nut (2).

Yearn the lock nuts O)

Turn the right and left sliders E) to get the right right job. At the same time time, line both. regulators doing use of reference marks ()

Tighten the shaft nut firmly and place a new fin pin.